


Operations

Cycle	Description	Icon
Drum Clean (applicable models only)	<ul style="list-style-type: none">• Cleans the drum by removing dirt and bacteria from it.• Cleans the rubber door gasket by removing dirt from the gasket.• Perform once every 40 washes with no detergent or bleach applied. Notification message appears after every 40 washes.• Make sure the drum is empty.• Do not use any cleaning agents for cleaning the drum.	
Drum Clean (applicable models only)	<ul style="list-style-type: none">• Cleans the drum by removing dirt and bacteria from it.• Perform once every 40 washes with no detergent or bleach applied. Notification message appears after every 40 washes.• Make sure the drum is empty.• Do not use any cleaning agents for cleaning the drum.	

Cycle	Description	Icon
Drum Clean (applicable models only)	<ul style="list-style-type: none">• Cleans the drum by removing dirt and bacteria from it.• Perform once every 40 washes with no detergent or bleach applied. Notification message appears after every 40 washes.• Make sure the drum is empty.• Do not use any cleaning agents for cleaning the drum.	

English 43

Maintenance

Emergency drain	Description
	<p>In case of a power failure, drain the water inside the drum before taking out the laundry.</p> <ol style="list-style-type: none">1. Power off and unplug the washing machine from the electrical outlet.2. Open the filter cover (A).<ul style="list-style-type: none">- TYPE I: Gently press the top area of the filter cover (A) to open. (WW1206****)- Open the filter cover (A) by using the spanner provided in accessories. (WW1206****)3. Place an empty, spacious container around the cover, and stretch the emergency drain tube to the container while holding the tube cap (B).4. Open the tube cap and let water in the emergency drain tube (C) flow into the container.5. When done, close the tube cap, and reinsert the tube. Then, close the filter cover. <p>NOTE</p> <ul style="list-style-type: none">• Use a spacious container because the water in the drum may be more than expected.





English 35



Troubleshooting

Code	Action
Redistribute unbalanced load and restart	<ul style="list-style-type: none">• Spinning does not work.• Make sure laundry is spread out evenly.• Make sure the washing machine is on a flat, stable surface.• Redistribute the load. If only one item of clothing needs washing, such as a bathrobe or pair of pants, the final spin result might be unsatisfactory, and "Redistribute unbalanced load and restart" check message will be shown in the display.
Close the washer door and try again	<p>Operating the washing machine with the door open</p> <ul style="list-style-type: none">• Make sure the door is properly closed.• Make sure laundry is not caught in the door.
OC	<p>Water has overflowed</p> <ul style="list-style-type: none">• Restart after spinning.• If the information code remains on the display, contact a local Samsung service centre. <p>Check the drain hose</p> <ul style="list-style-type: none">• Make sure the end of the drain hose is not placed on the floor.• Make sure the drain hose is not clogged.• If the information code remains, contact a customer service centre.
LC, LCI	<p>Check the drum motor for operation.</p> <ul style="list-style-type: none">• Try restarting the cycle.• If the information code remains, contact a customer service centre.
3C	<p>The electronic control needs to be checked.</p> <ul style="list-style-type: none">• Try restarting the cycle.• If the information code remains, contact a customer service centre.

English 40

Ironing

	Iron at maximum sole plate temperature of 200°C.	Professional dry-cleaning (heavy fabrics/heavy benzines) with normal process.
	Iron at maximum sole plate temperature of 150°C.	Professional dry-cleaning (heavy fabrics/heavy benzines) with gentle process.
	Iron at maximum sole plate temperature of 110°C.	Professional dry-cleaning (heavy fabrics/heavy benzines) with gentle process.
	Do not iron.	Do not wet-clean.

Professional care	Description
	<p>Professional dry-cleaning in perchloroethylene and/or hydrocarbons (heavy benzines) with normal process.</p> <ul style="list-style-type: none">• The letters in a circle indicate the solvent (P/F) used in dry cleaning or wet-cleaning (W).• Generally, the line under the symbol indicates a milder treatment (e.g. gentle cycle for easy-care items). The double line indicates care levels with particularly gentle treatment.
	<p>Professional dry-cleaning in perchloroethylene and/or hydrocarbons (heavy benzines) with gentle process.</p> <ul style="list-style-type: none">• The letters in a circle indicate the solvent (P/F) used in dry cleaning or wet-cleaning (W).• Generally, the line under the symbol indicates a milder treatment (e.g. gentle cycle for easy-care items). The double line indicates care levels with particularly gentle treatment.


English 33

Options

Using Options	Description
1. Tap ☰ .	
2. Turn the Navigation dial to select the desired additional function.	
3. Tap ☑ to change the selected function's settings or start the function.	
NOTE	<ul style="list-style-type: none">• To return to the main screen, tap ☰ again or turn the Navigation dial to select Back and tap ☑.• If the selected function is not supported, the "Currently not supported" message is displayed, and the ☑ button is not activated.• When you select an additional function, a brief help message appears for the first ten times of use.
Preshw	<p>You can add a preliminary washing cycle before the main wash cycle.</p> <ol style="list-style-type: none">1. Select a cycle and change the cycle settings as necessary.2. Tap ☑.3. Turn the Navigation dial to select Preshw, and then tap ☑.4. Tap and hold ☑.
Intensive	<p>For badly soiled laundry. The operation time for each cycle is longer than normal.</p> <ol style="list-style-type: none">1. Select a cycle and change the cycle settings as necessary.2. Tap ☑.3. Turn the Navigation dial to select Intensive, and then tap ☑.4. Tap and hold ☑.


English 44

Operations

Bubble Soak	Description
	<p>This function helps remove a wide variety of stubborn stains. With Bubble Soak selected, laundry is thoroughly soaked in water bubbles for effective washing.</p> <ol style="list-style-type: none">1. Select a cycle and change the cycle settings as necessary.2. Tap ☑.3. Turn the Navigation dial to select Bubble Soak, and then tap ☑. <p>Bubble Soak is available with and adds up to 30 minutes to these cycles: Cotton, Super Speed, Synthetics, Towels, Bedding, Shirts, Hygiene Steam, Activewear, Jeans / Denim, Baby Care, Silent Wash, and Cloudy Day.</p> <p>Tap and hold ☑</p> <ul style="list-style-type: none">• Status shows in the display and the washing machine tumbles the drum to sense the weight of the load if load sensing is preset for the selected cycle). When load sensing is complete, the display shows the remaining time until the end of the wash cycle.• To cancel Delay End, tap ☑ to restart the washing machine.
NOTE	<ul style="list-style-type: none">• The Drum Clean/Drum Clean cycles cannot be removed from the control list.• You can also edit My Cycles in the SmartThings app.

English 45

Maintenance

Debris filter	Description
	<p>It is advisable to clean the debris filter every 2 months to prevent its clogging. A clogged debris filter may reduce the bubble effect.</p> <ol style="list-style-type: none">1. Turn off the washing machine, and unplug the power cord.2. Drain the remaining water inside the drum. See the Emergency drain section.3. Open the filter cover.<ul style="list-style-type: none">- TYPE I: Gently press the top area of the filter cover to open.- Open the filter cover (A) by using the spanner provided in accessories.4. Turn the debris filter knob to the left, and drain off the remaining water.5. Clean the debris filter using a soft brush.<ul style="list-style-type: none">- Make sure to discard the debris into the waste bin.6. Rinse the filter and make sure the drain pump propeller inside the filter is unclogged.7. Reinsert the debris filter, and turn the filter knob to the right. <p>NOTE</p> <ul style="list-style-type: none">• Some debris filters feature a safety knob that is designed to prevent accidents by children. To open the safety knob of the debris filter, push in and turn anticlockwise. The spring mechanism of the safety knob helps open the filter.• To close the safety knob of the debris filter, turn it clockwise. The spring makes a rattling sound, which is normal.

English 57

Troubleshooting

Code	Action
DC1	<p>The Main Door lock/unlock is not working properly.</p> <ul style="list-style-type: none">• Turn the machine off, and restart the cycle.• If the information code remains, contact a customer service centre.
UC	<p>Low voltage detected.</p> <ul style="list-style-type: none">• Check if the power cord is plugged in.• If the information code remains, contact a customer service centre.
HC	<p>High temperature heating check.</p> <ul style="list-style-type: none">• If the information code remains, contact a customer service centre.
1C	<p>The Water Level sensor is not working properly.</p> <ul style="list-style-type: none">• Turn the machine off, and restart the cycle.• If the information code remains, contact a customer service centre.
AC	<p>Check communications between main and sub PCBs.</p> <ul style="list-style-type: none">• Turn the machine off, and restart the cycle.• If the information code remains, contact a customer service centre.
BC	<p>The MEKO sensor is not working properly.</p> <ul style="list-style-type: none">• Turn the machine off, and restart the cycle.• If the information code remains, contact a customer service centre.
AC6	<p>Check communications between the main and the inverter PBA.</p> <ul style="list-style-type: none">• Depending on the state, the machine may automatically return to normal operation.• Turn the machine off, and restart the cycle.• If the information code remains, contact a customer service centre.

English 60

Specifications


Type	Front loading washing machine
Model name	WW1206**** WW1206****
Dimensions	Width 600 mm 600 mm Height 850 mm 850 mm Depth 600 mm 600 mm
Water pressure	50-80 kPa
Net weight	72.5 kg 71.0 kg
Maximum load capacity	Washing and spinning 12.0 kg
Power consumption	Washing AC 220V 1900-2300 W Wet-cleaning AC 220V 1400-1800 W
Spin revolutions	1400 RPM

NOTE

- The design and specifications are subject to change without notice for quality improvement purposes.
- The dimensions stated here may differ slightly from the actual measurements depending on the measuring method.
- The energy label specifications have been determined by using the following program according to IEC 60456.
 - The program is "COTTON Cold+Intensive".


English 73

Operations

Child Lock	Description
	<p>Prevent children or infants from accidentally starting or setting the washing machine. Child Lock locks all buttons except for ☑ and ☰.</p> <ol style="list-style-type: none">1. Tap ☑.2. Turn the Navigation dial to select Child Lock, and then tap ☑.3. Tap ☑ to select On or Off.<ul style="list-style-type: none">- The default setting is Off. Set it to Off if you do not want to use this function. <p>NOTE</p> <ul style="list-style-type: none">• When Child Lock is on, all buttons are disabled except for ☑ and ☰. The washing machine door also locks.• Tapping a button while Child Lock is on triggers an alarm with the "Child Lock On" message.• You cannot open the door after a wash cycle when the Child Lock is on. Turn the function off before opening the door to take out the laundry.
NOTE	<ul style="list-style-type: none">• The drum rotates clockwise and anticlockwise for about 3 minutes.

English 47

Maintenance

Real-life case	Description
	<p>You want to finish a two-hour cycle 3 hours later from now. For this, you can use the Delay End option to the current cycle with the 3-hour setting, and press Start/Pause at 2:00 p.m. Then, what happens? The washing machine starts operating at 3:00 p.m. and ends at 5:00 p.m. Provided below is the time line for this example.</p> <p>2:00 pm Set Delay End to 3 hours 3:00 pm Start 5:00 pm End</p>

Problem	Action
Does not drain	<ol style="list-style-type: none">1. Clean the drawer recess using a soft brush.2. Reinsert the release lever and the liquid detergent guide to the drawer.3. Slide the drawer inward to close it.

NOTE

- Make sure the washing machine is running with sufficient water pressure.
- Make sure the detergent is added to the centre of the detergent drawer.
- If using granular detergent, make sure the detergent selector is in the upper position.
- Remove the rinse cap and clean the detergent drawer.

NOTE

- Make sure the washing machine is installed on a level, solid floor that is not slippery. If the floor is not level, use the leveling feet to adjust the height of the washing machine.
- Make sure the shipping bolts are removed.
- Make sure the washing machine is not in contact with any other object.
- Make sure the laundry load is balanced.
- Check the fuse or reset the circuit breaker.
- Check if power is supplied properly.
- Low voltage detected.
 - Check if the power cord is plugged in.
 - Make sure laundry is not caught in the door.
- Fully open the water tap.
- Make sure the door is properly closed.
- Make sure the water supply hose is not kinked or clogged.
- Make sure there is sufficient water pressure.
- Make sure that the cold water tap and the hot water tap are properly connected.
- Clean the mesh filter as it may be clogged.

English 48

Specifications

Code	Action
DC1	<p>The Main Door lock/unlock is not working properly.</p> <ul style="list-style-type: none">• Turn the machine off, and restart the cycle.• If the information code remains, contact a customer service centre.

NOTE

- The numbers in a circle identify the maximum washing temperatures in degrees Celsius that must not be exceeded.
- The dryer indicates the type and place of the dryer.

English 58

Specifications


Type	Front loading washing machine
Model name	WW1206**** WW1206****
Dimensions	Width 600 mm 600 mm Height 850 mm 850 mm Depth 600 mm 600 mm
Water pressure	50-80 kPa
Net weight	72.5 kg 71.0 kg
Maximum load capacity	Washing and spinning 12.0 kg
Power consumption	Washing AC 220V 1900-2300 W Wet-cleaning AC 220V 1400-1800 W
Spin revolutions	1400 RPM

NOTE

- The design and specifications are subject to change without notice for quality improvement purposes.
- The dimensions stated here may differ slightly from the actual measurements depending on the measuring method.
- The energy label specifications have been determined by using the following program according to IEC 60456.
 - The program is "COTTON Cold+Intensive".

English 58

Operations

Wi-Fi	Description
	<p>You can turn the washing machine's Wi-Fi on or off.</p> <ol style="list-style-type: none">1. Tap and hold ☑ for 3 seconds.2. Turn the Navigation dial to select Wi-Fi, and then tap ☑.3. Tap ☑ to select On or Off.<ul style="list-style-type: none">- The default setting is Off. Set it to Off if you do not want to use this function. <p>NOTE</p> <ul style="list-style-type: none">• When you turn off the function, all the saved data resets.<ul style="list-style-type: none">- The Child Lock icon turns on when the function is on.
NOTE	<ul style="list-style-type: none">• The washing machine's Wi-Fi is off as a factory default setting. However, the washing machine's Wi-Fi turns on automatically when you turn on the washing machine for the first time. Then, the final Wi-Fi setting maintains regardless of the washing machine power status.• The network you turn on the washing machine's Wi-Fi and connect to a network, the washing machine remains connected to the network even when you turn off the power.• The Wi-Fi on the washing machine's Wi-Fi icon is connected to the router through the Wi-Fi connection.

English 49

Troubleshooting

Problem	Action
Does not drain and/or spin.	<ul style="list-style-type: none">• Close the door and tap and hold ☑ for your safety, the washing machine will not tumble or spin unless the door is closed.• Make sure the drain hose is not frozen or clogged.• Make sure the drain hose is not connected to a drain system that is not clogged.• If the washing machine is not supplied with sufficient power, the washing machine will temporarily not drain or spin. As soon as the washing machine regains sufficient power, it will operate normally.• Make sure the drain hose is positioned correctly, depending on the connection type.• Clean the debris filter as it may be clogged.
Excessive or makes noise.	<ul style="list-style-type: none">• Tap and hold ☑ to stop the washing machine.• It may take a few moments for the door lock mechanism to disengage.• The door will not open until 3 minutes after the washing machine has stopped the power has been drained.• Make sure all the water in the drum is drained.• The door may not open if water remains in the drum. Drain the drum and open the door manually.• Make sure the door lock light is off. The door lock light turns off after the washing machine has drained.• Make sure you use the recommended types of detergent as appropriate.• Use high efficiency (HE) detergent to prevent overloading.• Make sure the drain hose is straightened all the way to the drain system. If you encounter a drain problem, call for service.• Make sure the debris filter is not clogged.

English 61

Operations

Problem	Action
Cannot add additional detergent.	<ul style="list-style-type: none">• Reduce the detergent amount for soft water, and use the correct detergent.• Non-HE detergent is not recommended.• Make sure the remaining amount of detergent and fabric softener is not over the limit.
Stops.	<ul style="list-style-type: none">• Plug the power cord into a live electrical outlet.• Check the fuse or reset the circuit breaker.• Make sure the end of the drain hose is correctly inserted and secured to the drain system.• Make sure the door is properly closed.• Make sure all the water connections are tight.• Make sure the end of the drain hose is correctly inserted and secured to the drain system.• Avoid overloading.• Use high efficiency (HE) detergent to prevent overloading.• Fully open both taps.• Make sure the temperature selection is correct.• Make sure the hoses are connected to the correct taps. Flush water lines.• Make sure the water heater is set to supply a minimum of 49°C hot water at the tap. Also, check the water heater capacity and recovery rate.

English 63

Operations

Problem	Action
Does not drain and/or spin.	<ul style="list-style-type: none">• Close the door and tap and hold ☑ for your safety, the washing machine will not tumble or spin unless the door is closed.• Make sure the drain hose is not frozen or clogged.• Make sure the drain hose is not connected to a drain system that is not clogged.• If the washing machine is not supplied with sufficient power, the washing machine will temporarily not drain or spin. As soon as the washing machine regains sufficient power, it will operate normally.• Clean the debris filter as it may be clogged.
Excessive suds.	<ul style="list-style-type: none">• Tap and hold ☑ to stop the washing machine.• It may take a few moments for the door lock mechanism to disengage.• The door will not open until 3 minutes after the washing machine has stopped the power has been drained.• Make sure all the water in the drum is drained.• The door may not open if water remains in the drum. Drain the drum and open the door manually.• Make sure the door lock light is off. The door lock light turns off after the washing machine has drained.• Make sure you use the recommended types of detergent as appropriate.• Use high efficiency (HE) detergent to prevent overloading.• Make sure the drain hose is straightened all the way to the drain system. If you encounter a drain problem, call for service.• Make sure the debris filter is not clogged.

English 63

Operations

Special features	Description
Smart Control (applicable models only)	<p>You can connect the SmartThings app and control your washing machine remotely.</p> <p>Connecting your washing machine</p> <ol style="list-style-type: none">1. Download and open the SmartThings app on your smartphone or tablet (Android & iOS).2. Tap ☑ to tap on the washing machine.3. Tap and hold ☑.<ul style="list-style-type: none">a. The washing machine enters AP mode and connects to your smartphone or tablet.b. Tap ☑ to authenticate your washing machine.c. Once the authentication process is complete, your washing machine is successfully connected to the app.- You can use various features available in the SmartThings app. <p>NOTE</p> <ul style="list-style-type: none">• If your washing machine fails to connect with the SmartThings app, try again.• Check your router if you experience any internet connection problem after connecting your washing machine with the SmartThings app.• If the Wi-Fi is off, tap and hold ☑ for 3 seconds to enter the Settings menu, and select Wi-Fi to turn it on.• Turning the washing machine's Wi-Fi on allows you to connect to the washing machine via SmartThings app on your smartphone or tablet, regardless of the power status of the washing machine. However, the washing machine appears offline on the SmartThings app if the washing machine's Wi-Fi is off.• Close the door before setting the Smart Control function.• If you use your washing machine for a while without connecting it to SmartThings, the washing machine may appear as Smart Control will show for 3 seconds.• If the washing machine's Wi-Fi is not connected to an AP (Access Point), the Wi-Fi will turn off again when you turn off the power.


English 59

Troubleshooting

Problem	Action
Does not drain and/or spin.	<ul style="list-style-type: none">• Close the door and tap and hold ☑ for your safety, the washing machine will not tumble or spin unless the door is closed.• Make sure the drain hose is not frozen or clogged.• Make sure the drain hose is not connected to a drain system that is not clogged.• If the washing machine is not supplied with sufficient power, the washing machine will temporarily not drain or spin. As soon as the washing machine regains sufficient power, it will operate normally.• Make sure the drain hose is positioned correctly, depending on the connection type.• Clean the debris filter as it may be clogged.
Excessive or makes noise.	<ul style="list-style-type: none">• Tap and hold ☑ to stop the washing machine.• It may take a few moments for the door lock mechanism to disengage.• The door will not open until 3 minutes after the washing machine has stopped the power has been drained.• Make sure all the water in the drum is drained.• The door may not open if water remains in the drum. Drain the drum and open the door manually.• Make sure the door lock light is off. The door lock light turns off after the washing machine has drained.• Make sure you use the recommended types of detergent as appropriate.• Use high efficiency (HE) detergent to prevent overloading.• Make sure the drain hose is straightened all the way to the drain system. If you encounter a drain problem, call for service.• Make sure the debris filter is not clogged.

English 62

Operations

Stay Connect	Description
	<p>Set up the Stay Connect function in your SmartThings app to keep Smart Control turned on at the end of a cycle. Your washing machine gets connected to the app to send additional instructions, whether you are at home or away.</p> <ol style="list-style-type: none">1. You turn on the Stay Connect function in the SmartThings app, the washing machine will stay in standby power saving mode after completing a cycle.<ul style="list-style-type: none">- The Stay Connect function will remain active for up to 7 days if the door remains closed.2. When the Stay Connect function is active, the Smart Control, Door Lock, and Wi-Fi icons are illuminated on your washing machine display.3. You can conveniently control your washing machine, adding time, spin or dry cycles using the SmartThings app. <p>NOTE</p> <ul style="list-style-type: none">• The washing machine switches to standby power saving mode when operation is paused even if the door is not connected to the SmartThings app.• In some circumstances, only the Door Lock icon may be illuminated.


English 51

Troubleshooting

Problem	Action
Cannot add additional detergent.	<ul style="list-style-type: none">• Reduce the detergent amount for soft water, and use the correct detergent.• Non-HE detergent is not recommended.• Make sure the remaining amount of detergent and fabric softener is not over the limit.
Stops.	<ul style="list-style-type: none">• Plug the power cord into a live electrical outlet.• Check the fuse or reset the circuit breaker.• Make sure the end of the drain hose is correctly inserted and secured to the drain system.• Make sure the door is properly closed.• Make sure all the water connections are tight.• Make sure the end of the drain hose is correctly inserted and secured to the drain system.• Avoid overloading.• Use high efficiency (HE) detergent to prevent overloading.• Fully open both taps.• Make sure the temperature selection is correct.• Make sure the hoses are connected to the correct taps. Flush water lines.• Make sure the water heater is set to supply a minimum of 49°C hot water at the tap. Also, check the water heater capacity and recovery rate.

English 63

Operations

Log In	Description
	<p>You must first log into SmartThings with your Samsung account. To create a new Samsung account, follow the instructions on the app. You don't need a separate app to create your account.</p> <p>NOTE</p> <ul style="list-style-type: none">• If you have a Samsung account, use the account to log in. A registered Samsung smartphone or tablet user automatically logs in.• To register your appliance to SmartThings<ul style="list-style-type: none">1. Make sure your smartphone or tablet is connected to a wireless network. If not, go to Settings and turn on the wireless connection and select an AP (Access Point).2. Open SmartThings on your smartphone or tablet.3. If a message of "A new device is found", select Add.4. If no message appears, select + and select your appliance in a list of devices available. If your appliance is not listed, select Device Type > Specific Device Model, and then add your appliance manually.5. Register your appliance to the SmartThings app as follows.<ul style="list-style-type: none">a. Add your appliance to SmartThings. Make sure your appliance is connected to SmartThings.b. When registration is complete, your appliance appears on your smartphone or tablet.

English 52

Troubleshooting

Problem	Action
Leaks water.	<ul style="list-style-type: none">• Disconnect the mesh filter and clean the mesh filter. The mesh filter may be clogged.• While the washing machine fills, the water temperature may change as the automatic temperature control feature checks incoming water temperature. This is normal.• While the washing machine fills, you may notice just hot and/or just cold water going through the dispenser when cold or warm temperatures are selected. This is a normal feature of the automatic temperature control feature as the water temperature determines the water temperature.• Use the High or Extra High spin speed.• Use high efficiency (HE) detergent to reduce oversudsing.• Load is too small. Small loads (one or two items) may become unbalanced and not spin completely.• Make sure the drain hose is not kinked or clogged.
Fills with the wrong water temperature.	<ul style="list-style-type: none">• Use the High or Extra High spin speed.• Use high efficiency (HE) detergent to reduce oversudsing.• Load is too small. Small loads (one or two items) may become unbalanced and not spin completely.• Make sure the drain hose is not kinked or clogged.
Load is wet at the end of a cycle.	<ul style="list-style-type: none">• Make sure the door is properly closed.• Make sure all the hose connections are tight.• Make sure the end of the drain hose is correctly inserted and secured to the drain system.• Avoid overloading.• Use high efficiency (HE) detergent to prevent oversudsing.• Clean the mesh filter as it may be clogged.• Make sure the end of the drain hose is not placed on the floor.<ul style="list-style-type: none">- Make sure the drain hose is not clogged.• Check if there is something stuck between the door and the diaphragm.

English 64

Operations

Open Source Announcement	Description
	<p>The software included in this product contains open source software. You may obtain the complete corresponding source code for a period of three years after the last shipment of this product by contacting our support team via https://open source.samsung.com (Please use the "Inquiry" menu).</p> <p>It is also possible to obtain the complete corresponding source code in physical medium such as a CD-ROM; a minimal charge will be required.</p> <p>The following URL (https://open source.samsung.com/open source/) leads to the open source license information as related to this product. This offer is valid to anyone in receipt of this information.</p> 

English 53