# Printing Specification

1. Specification				1.1	Folding /	Cover
	1. Model Name:	UR/QNED/NANO				
Models	2. Suffix:	TR				
Models	3. Part No:	MFL70265973				
	4. REV	REV00				
	5. Number of pages	12				
	6. Folded/Unfolded	Unfolded				
SIZE	7. Trim size (W x H)_Unfolded (mm)	148 x 210 (+/-5)	Fr	ront	2	3
SIZE	8. Trim size (W x H)_folded (mm)	-				
	9. Bindery	Saddle stitching				
	10. Color (Cover)	1				
COVER	11. Paper (Cover)	Wood free				
	12. Weight (cover) (g/m)	70 (+/-10)		r		
	13. Color (inner)	1				
INNER	14. Paper (inner)	Wood free		4	5	Back
	15. Weight (inner) (g/m)	70 (+/-10)		- I	5	
	16. Coating	No				
	17. Thomson	No				
	18. Sub-material	No				
	19. Languages	ENG/HINDI				

# 2. Origin Notification

			[Country Name	] (ENG/FRE)
			LGERS / LGEMX :	Printed in Mexico Imprimé au Mexique
		Changes the Country name.	LGEKR :	Printed in Korea Imprimé en Corée
Convright @ 2021 LG Electronics Inc. Al	Printed in Korea	Printed in [Country Name in English]	LGEMA :	Printed in Poland Imprimé en Pologne
Copyright © 2021 LG Electronics Inc. All Rights Reserved. Imprimé en Corée Copyright © 2021 LG Electronics inc. Tous droits réservés. www.lg.com		- Imprimé en(au) [Country Name in French]	LGEND :	Printed in China Imprimé en Chine
			LGEIN :	Printed in Indonesia Imprimé en Indonésie
			Others :	Each Country name.
Hazardous su Especially, Pa (1) Hazardou (2) Especially INK REQUIR (1) The amou * MOAH	[Restriction of Hazardous Substances ]         Hazardous substances on this product should be satisfied by substance regulation of Level A-I, A-II, SVHC according to LG(52)B-5011 standard.         Especially, Part should be followed and controlled the following specification.         (1) Hazardous substances test report should be submitted when part certification test and first mass production.         (2) Especially, Don't use or contain lead (Pb) and cadmium (Cd) in ink.         INK REQUIREMENT FOR EU         (1) The amount of MOAH/MOSH must be less than 0.1% of the weight of the INK used.         * MOAH(Mineral Oil Aromatic Hydrocarbons) : Consisting of 1 to 7 aromatic cycles         * MOSH(Mineral Oil Saturated Hydrocarbons) : Consisting of 16 to 35 carbon atoms			

# 3. History

5.11150	ory				
REV07					
REV06					
REV05					
REV04					
REV03					
REV02					
REV01	Γ				_
REV00	03/20/2023	_	_	Checked	Nitin.H
112000	03,20,2023			Approved	Santosh.C
Rev. Number	Date	Description	ECO Number	Owner	Aditya.K





www.lq.com

Copyright © 2023 LG Electronics Inc. All Rights Reserved.

# LED TV\* OWNER'S MANUAL

Safety and Reference

\* LG LED TV applies LCD screen with LED backlights.

Please read this manual carefully before operating your set and retain it for future reference.

The model and serial number of the product are located on the back and on one side of the product. Record them below in case you ever need service.

Model

۲

Serial No.



# Before reading this manual

- Read this manual thoroughly before operating your TV, and keep it for future reference.
- On the website you can download the manual including installation, using, troubleshooting, specifications, license etc and view its contents on your PC or mobile device.
- User Guide : For more information about this TV, read the USER GUIDE embedded in the product. (Depending on model)
  - To open the USER GUIDE (())  $\rightarrow$  [())]  $\rightarrow$  [Support]  $\rightarrow$  [User Guide]

### **Separate Purchase**

- Separate purchase items can be changed or modified for quality improvement without any notification. Contact your dealer to buy these items. These
  devices only work with certain models.
- The model name or design may be changed depending on the upgrade of product functions, manufacturer's circumstances or policies.
- Magic Remote Control :

Check whether your TV model supports Bluetooth in the Wireless Module Specification to verify whether it can be used with the Magic Remote.

• A cable to connect antennas and external devices must be purchased separately.

#### 🔊 Note

- Product specifications or contents of this manual may be changed without prior notice due to upgrade of product functions.
- The items supplied with your product may vary depending on the model.
- Image shown may differ from your TV.

# Warning! Safety instructions







CAUTION : TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL.

This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

۲

This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying this apparatus.

WARNING : TO REDUCE THE RISK OF FIRE AND ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

- TO PREVENT THE SPREAD OF FIRE, KEEP CANDLES OR OTHER ITEMS WITH
   OPEN FLAMES AWAY FROM THIS PRODUCT AT ALL TIMES.
- Do not place the TV and/or remote control in the following environments:
  - Keep the product away from direct sunlight.
  - An area with high humidity such as a bathroom.
  - Near any heat source such as stoves and other devices that produce heat.
  - Near kitchen counters or humidifiers where they can easily be exposed to steam or oil.
  - An area exposed to rain or wind.
  - Do not expose to dripping or splashing and do not place objects filled with liquids, such as vases, cups, etc. on or over the apparatus (e.g., on shelves above the unit).

- Near flammable objects such as gasoline or candles, or expose the TV to direct air conditioning.
- Do not install in excessively dusty places.

Otherwise, this may result in fire, electric shock, combustion/explosion, malfunction or product deformation.

- Ventilation
  - Install your TV where there is proper ventilation. Do not install in a confined space such as a bookcase.
  - Do not install the product on a carpet or cushion.
  - Do not block or cover the product with cloth or other materials while unit is plugged in.
- Take care not to touch the ventilation openings. When watching the TV for a long period, the ventilation openings may become hot.

- Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the device.
- Do not move the TV whilst the Power cord is plugged in.
- Do not use a damaged or loosely fitting power cord.
- Be sure to grasp the plug when unplugging the power cord. Do not pull
  on the power cord to unplug the TV.
- Do not connect too many devices to the same AC power outlet as this could result in fire or electric shock.
- Disconnecting the Device from the Main Power
- The power plug is the disconnecting device. In case of an emergency, the power plug must remain readily accessible.
- Do not let your children climb or cling onto the TV. Otherwise, the TV may fall over, which may cause serious injury.
- Outdoor Antenna Grounding (Can differ by country):
  - If an outdoor antenna is installed, follow the precautions below.
     An outdoor antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can come in contact with such power lines or circuits as death or serious injury can occur.
- Never touch this apparatus or antenna during a lightning storm. You may be electrocuted.
- Make sure the power cord is connected securely to the TV and wall socket if not secured damage to the Plug and socket may occur and in extreme cases a fire may break out.
- Do not insert metallic or inflammable objects into the product. If a foreign object is dropped into the product, unplug the power cord and contact the customer service.
- Do not touch the end of the power cord while it is plugged in. You may be electrocuted.
- If any of the following occur, unplug the product immediately and contact your local customer service.
  - The product has been damaged.
  - If water or another substance enters the product (like an AC adapter, power cord, or TV).
  - If you smell smoke or other odors coming from the TV.

- When lightning storms or when unused for long periods of time. Even the TV is turned off by remote control or button, AC power source is connected to the unit if not unplugged in.

- Do not use high voltage electrical equipment near the TV (e.g., a bug zapper). This may result in product malfunction.
- Do not attempt to modify this product in any way without written authorization from LG Electronics. Accidental fire or electric shock can occur. Contact your local customer service for service or repair. Unauthorized modification could void the user's authority to operate this product.
- Use only an authorized attachments / accessories approved by LG Electronics. Otherwise, this may result in fire, electric shock, malfunction, or product damage.
- Never disassemble the AC adapter or power cord. This may result in fire or electric shock.
- Handle the adapter carefully to avoid dropping or striking it. An impact could damage the adapter.
- To reduce the risk of fire or electrical shock, do not touch the TV with wet hands. If the power cord prongs are wet or covered with dust, dry the power plug completely or wipe dust off.

#### Batteries

- Store the accessories (battery, etc.) in a safe location out of the reach of children.
- Do not short circuit, disassemble, or allow the batteries to overheat.
   Do not dispose of batteries in a fire. Batteries should not be exposed to excessive heat.
- Caution : Risk of fire or explosion if the battery is replaced by an incorrect type.

#### Moving

- When moving, make sure the product is turned off, unplugged, and all cables have been removed. It may take 2 or more people to carry larger TVs. Do not press or put stress on the front panel of the TV. Otherwise, this may result in product damage, fire hazard or injury.
- Keep the packing anti-moisture material or vinyl packing out of the reach of children.
- Do not allow an impact shock, any objects to fall into the product, and do not drop anything onto the screen.
- Do not press strongly upon the panel with a hand or a sharp object such as a nail, pencil, or pen, or make a scratch on it. It may cause damage to screen.
- Cleaning
  - When cleaning, unplug the power cord and wipe gently with a soft/ dry cloth. Do not spray water or other liquids directly on the TV. Do not clean your TV with chemicals including glass cleaner, any type of air freshener, insecticide, lubricants, wax (car, industrial), abrasive, thinner, benzene, alcohol etc., which can damage the product and/ or its panel. Otherwise, this may result in electric shock or product damage.

# Installation

### Lifting and moving the TV

Please note the following advice to prevent the TV from being scratched or damaged and for safe transportation regardless of its type and size.

- It is recommended to move the TV in the box or packing material that the TV originally came in.
- Before moving or lifting the TV, disconnect the power cord and all cables.
- When holding the TV, the screen should face away from you to avoid damage.
- Hold the top and bottom of the TV frame firmly. Make sure not to hold the transparent part, speaker, or speaker grill area.
- When transporting a large TV, there should be at least 2 people.
- When transporting the TV, do not expose the TV to jolts or excessive vibration.
- When transporting the TV, keep the TV upright, never turn the TV on its side or tilt towards the left or right.
- Do not apply excessive pressure to cause flexing / bending of frame chassis as it may damage screen.
- When handling the TV, be careful not to damage the protruding buttons.

#### A

- Avoid touching the screen at all times, as this may result in damage to the screen.
- When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.

### Mounting on the Table

- 1 Lift and tilt the TV into its upright position on a table.
- Leave a 10 cm (minimum) space from the wall for proper ventilation.
- 2 Connect the power cord to a wall outlet.

### ⚠

- Do not apply foreign substances (oils, lubricants, etc.) to the screw parts when assembling the product. (Doing so may damage the product.)
- Do not use any unapproved items to ensure the safety and product life span.
- Any damage or injuries caused by using unapproved items are not covered by the manufacturer's warranty.
- If you install the TV on a stand, you need to take actions to prevent the product from overturning. Otherwise, the product may fall over, which may cause injury.
- When assembling the stand, ensure that all of the provided screws are attached. If the screws are not fully tightened, the product may tilt or tip over, resulting in damage. Tightening the screws with excessive force may cause them to come off due to abrasion of the screw joint.
- If a television is not positioned in a sufficiently stable location, it can be potentially hazardous due to falling. Many injuries, particularly to children. can be avoided by taking simple precautions such as:
  - Using cabinets or stands recommended by the manufacturer of the television.
  - Only using furniture that can safely support the television.
  - Ensuring the television is not overhanging the edge of the supporting furniture.
  - Not placing the television on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the television to a suitable support.
  - Not standing the televisions on cloth or other materials placed between the television and supporting furniture.
  - Educating children about the dangers of climbing on furniture to reach the television or its controls.

### Securing TV to the Wall

۲

- Insert and tighten the eye-bolts, or TV brackets and bolts on the back of the TV.
  - If there are bolts inserted at the eye-bolts position, remove the bolts first.
- 2 Mount the wall brackets with the bolts to the wall. Match the location of the wall bracket and the eye-bolts on the rear of the TV.
- 3 Connect the eye-bolts and wall brackets tightly with a sturdy rope. Make sure to keep the rope horizontal with the flat surface.
- Use a platform or cabinet that is strong and large enough to support the TV securely.
- Brackets, bolts and ropes are not provided. You can obtain additional accessories from your local dealer.

### Mounting to the Wall

Attach an optional wall mount bracket at the rear of the TV carefully and install the wall mount bracket on a solid wall perpendicular to the floor. When you attach the TV to other building materials, please contact qualified personnel. LG recommends that wall mounting be performed by a qualified professional installer. We recommend the use of LG's wall mount bracket. LG's wall mount bracket is easy to move with cables connected. When you do not use LG's wall mount bracket, please use a wall mount bracket where the device is adequately secured to the wall with enough space to allow connectivity to external devices. It is advised to connect all the cables before installing fixed wall mounts.

### $\wedge$

( )

- Remove the stand before installing the TV on a wall mount by performing the stand attachment in reverse.
- For more information of screws and wall mount bracket, refer to the Separate purchase.
- If you intend to mount the product to a wall, attach VESA standard mounting interface (optional parts) to the back of the product. When you install the set to use the wall mounting bracket (optional parts), fix it carefully so as not to drop.
- When mounting a TV on the wall, make sure not to install the TV by hanging the power and signal cables on the back of the TV.
- Do not install this product on a wall if it could be exposed to oil or oil mist. This may damage the product and cause it to fall.
- When installing the wall mounting bracket, it is recommended to cover the stand hole using tape, in order to prevent the influx of dust and insects. (Depending on model)

# Antenna/Cable

Connect the TV to a wall antenna socket with an RF cable (75  $\Omega$ ).

- Use a signal splitter to use more than 2 TVs.
- If the image quality is poor, install a signal amplifier properly to improve the image quality.
- If the image quality is poor with an antenna connected, try to realign the antenna in the correct direction.
- An antenna cable and converter are not supplied.
- For a location that is not supported with Ultra HD broadcasting, this TV cannot receive Ultra HD broadcasts directly. (Depending on model)

# Satellite dish

Connect the TV to a satellite dish to a satellite socket with a satellite RF cable (75  $\Omega$ ). (Depending on model)

# **Starting TV**

### Turning on the TV

You can simply operate the TV functions, using the button. (Image may differ from your TV)





Power On (Press) Power Off<sup>1)</sup> (Press and Hold) Menu Control (Press<sup>2)</sup>) Menu Selection (Press and Hold<sup>3)</sup>)

- All running apps will close, and any recording in progress will stop. (Depending on country)
- 2) You can access and adjust the menu by pressing the button when TV is on.
- 3) You can use the function when you access menu control.

#### 🔿 Note

( )

- If the TV is turned on for the first time after it was shipped from the factory, initialization of the TV may take a few minutes.
- Your TV's OSD (On Screen Display) may differ slightly from that shown in this manual.
- The device must be easily accessed to a location outlet near the access. Some devices are not made by turning on / off button, turning off the device and unplugging the power cord.

# Connections

Connect various external devices to the TV and switch input modes to select an external device. For more information of external device's connection, refer to the manual provided with each device.

### HDMI

- When connecting the HDMI cable, the product and external devices should be turned off and unplugged.
- Supported HDMI Audio format (Depending on model): True HD (48 kHz),
   Dolby Digital / Dolby Digital Plus (32 kHz / 44.1 kHz / 48 kHz),
   PCM (32 kHz / 44.1 kHz / 48 kHz / 96 kHz / 192 kHz),
   DTS (44.1 kHz / 48 kHz / 88.2 kHz / 96 kHz),
- DTS-HD (44.1 kHz / 48 kHz / 88.2 kHz / 96 kHz / 176.4 kHz / 192 kHz)

#### Note

- If the device connected to Input Port also supports HDMI Deep Colour, your picture may be clearer. However, if the device doesn't support it, it may not work properly. In that case, change the TV's [HDMI Deep Colour] setting to off. (Depending on model)
- (③) → [General] → [External Devices] → [HDMI Settings]
   → [HDMI Deep Colour] (Depending on model)
- Use a certified cable with the HDMI logo attached.
- If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- Recommended HDMI Cable Types

   Ultra High Speed HDMI<sup>®</sup>/<sup>™</sup> cable (3 m or less)

### USB

Some USB Hubs may not work. If a USB device connected using a USB Hub is not detected, connect it to the USB port on the TV directly. (Depending on model)

#### Note

 For an optimal connection, HDMI cables and USB devices should have bezels less than 10 mm thick and 18 mm width. Use an extension cable that supports USB 2.0 if the USB cable or USB memory stick does not fit into your TV's USB port. (Depending on model)

#### **IR Blaster**

Control the set-top box (cable/satellite/IP/OTT), Blu-ray/DVD player, soundbar, game consoles, etc., using the IR Blaster. (Depending on country) (Depending on model)

#### Note

- · Connect the IR Blaster cable to the TV's IR Blaster port.
- Use universal control settings to control the device.
- Secure the IR Blaster with the 3M tape provided.

### **External Devices**

Available external devices are: Blu-ray player, HD receivers, DVD players, VCRs, audio systems, USB storage devices, PC, gaming devices, and other external devices.

#### 🔿 Note

 $( \bullet )$ 

- · The external device connection may differ from the model.
- In PC mode, there may be noise associated with the resolution, vertical
  pattern, contrast or brightness. If noise is present, change the PC output
  to another resolution, change the refresh rate to another rate or adjust
  the brightness and contrast on the [Picture] menu until the picture is
  clear.
- In PC mode, some resolution settings may not work properly depending on the graphics card.
- If Ultra HD content is played on your PC, video or audio may become disrupted intermittently depending on your PC's performance. (Depending on model)
- When connecting to a wired LAN, use a CAT 7 cable with high-speed Internet transmission. (Only when LAN port is provided.)

# **Specifications**

**Power requirement** 

AC 100-240 V~ 50/60 Hz

(Depending on country)(Depending on model)

		Broadcasting Specifica	ations	
		Digital TV		Analogue TV
Television system		DVB-T/T2, DVB-C, DVB-S/S2		PAL B/B, PAL B/G, PAL D/K, PAL-I, SECAM B/G, SECAM D/K, NTSC-M
	DVB-S/S2 <sup>1)</sup>	DVB-C <sup>1)</sup>	DVB-T/T2 <sup>1)</sup>	
Programme coverage	950 ~ 2,150 MHz	46 ~ 890 MHz	VHF III : 174 ~ 230 MHz UHF IV : 470 ~ 606 MHz UHF V : 606 ~ 862 MHz S Band II : 230 ~ 300 MHz S Band III : 300 ~ 470 MHz	46 ~ 862 MHz
Maximum number of storable programmes	6,000		3,000	
External antenna impedance			75 Ω	

1) Only DVB-T2/C/S2 support models.

Certain 8K input/decoding standards may not be supported. An additional device may be necessary to support certain 8K standards. Upscaled and enhanced 8K images will vary depending on the source content. (Depending on model)

Environment Condition				
Operating Temperature         0 °C to 40 °C         Storage Temperature         -20 °C to 60 °C				
Operating Humidity	Less than 80 %	Storage Humidity	Less than 85 %	

Conditions for Wall Mount Installation		
Tilt Angle	0° - 15°	
lilt Angle	0° - 15°	

( )

\* This specification applies only to products with an adjustable wall mount angle.

• The energy information provided with the product is indicated in accordance with the regulations of each country. (Depending on country)

- The Energy consumption is measured in accordance with IEC 62087.
- The recommended 'home viewing' picture mode is initial default picture mode.

• Actual Energy consumption may vary depending on factors such as the type of video content being played and TV settings.

• For information of the power supply and power consumption, refer to the label attached to the product. (Depending on country)

- The typical power consumption is measured in accordance with IEC 62087 or each country's energy regulations.

\* On some models, the label is inside the external device connection terminal cover.

\* Depending on the model or country, the typical power consumption may not be on label.

# **Product Information**

(Only QNED86\*, QNED85\*, 86QNED83\*, 86QNED81\*, 86QNED80\*, 86NAN077\*, 86UR90\*, 86UR81\*, 86UR80\*)

Wireless module(LGSBWAC95)Specifications				
Wireless LAN (IEEE 802.11a/b/g/n/ac)				
Frequency range Output Power (Max.)				
2,400 to 2,483.5 MHz	19 dBm			
5,150 to 5,725 MHz	18 dBm			
5,725 to 5,850 MHz 13.5 dBm				
Bluetooth				
Frequency range Output Power (Max.)				
2,400 to 2,483.5 MHz	9 dBm			

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

#### (Only 55/65/75QNED83\*, 50/55/65/75QNED81\*, 50/55/65/75QNED80\*)

Wireless module(LGSBWAC97)Specifications			
Wireless LAN (IEEE 802.11a/b/g/n/ac)			
Frequency range Output Power (Max.)			
2,400 to 2,483.5 MHz 19 dBm			
5,150 to 5,725 MHz 18 dBm			
5,725 to 5,850 MHz 13.5 dBm			
Bluetooth			
Frequency range Output Power (Max.)			
2,400 to 2,483.5 MHz	9 dBm		

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

#### (Only ONED75\*)

Wireless module(LGSBWAC03)Specifications				
Wireless LAN (IEEE 802.11a/b/g/n/ac)				
Frequency range	Output Power (Max.)			
2,400 to 2,483.5 MHz	18.5 dBm			
5,150 to 5,725 MHz	19.5 dBm			
5,725 to 5,850 MHz	11.5 dBm			
Bluetooth				
Frequency range Output Power (Max.)				
2,400 to 2,483.5 MHz	9 dBm			

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

(Only 70/75NAN077\*, 70/75UR81\*, 70/75UR80\*, 75/86UR78\*, 43UR77\*, 70/75/86UR75\*) Wireless module(LGSBWAC02)Specifications

Wireless LAN (IEEE 802.11a/b/g/n/ac)				
Frequency range	Output Power (Max.)			
2,400 to 2,483.5 MHz	17 dBm			
5,150 to 5,725 MHz	19 dBm			
5,725 to 5,850 MHz 10.5 dBm				
Bluetooth				
Frequency range	Output Power (Max.)			
2,400 to 2,483.5 MHz	8.5 dBm			

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

(Only 43/50/55/65NAN077\*, 55/65/75UR91\*, 43/50/55/65/75UR90\*, 43/50/55/65UR81\*, 43/50/55/60/65UR80\*, 43/50/55/65UR78\*, 43/50/55/65UR75\*, LR65\*, LR68\*)

Wireless module(LGSBWAC23)Specifications			
Wireless LAN (IEEE 802.11a/b/g/n/ac)			
Frequency range	Output Power (Max.)		
2,400 to 2,483.5 MHz	16 dBm		
5,150 to 5,725 MHz 16 dBm			
5,725 to 5,850 MHz	16 dBm		
Bluetooth			
Frequency range	Output Dower (May )		

 Frequency range
 Output Power (Max.)

 2,400 to 2,483.5 MHz
 8 dBm

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

 $( \bullet )$ 

# Open Source Software Notice Information

To obtain the source code that is contained in this product, under GPL, LGPL, MPL, and other open source licenses that have the obligation to disclose source code, and to access all referred license terms, copyright notices and other relevant documents please visit *https://opensource.lge.com*. LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid to anyone in receipt of this information for a period of three years after our last shipment of this product.

# Licenses

( )

۲



HIGH-DEFINITION MULTIMEDIA INTERFACE

**QUICKSET** 

(Magic Remote supported models only)





### 

# Troubleshooting

In TV / HDMI input, press the 🛞 button on the remote control three times to display the model name and serial number on the screen.

Cannot control the TV with	Check the remote control sensor on the product and try again.
the remote control.	<ul> <li>Check if there is any obstacle between the product and the remote control.</li> </ul>
	<ul> <li>Check if the batteries are still working and properly installed (⊕ to ⊕, ⊝ to ⊝).</li> </ul>
No image display and no	Check if the product is turned on.
sound is produced.	<ul> <li>Check if the power cord is connected to a wall outlet.</li> </ul>
	Check if there is a problem in the wall outlet by connecting other products.
The TV turns off suddenly.	Check the power control settings. The power supply may be interrupted.
	<ul> <li>Check if the auto-off function is activated on the settings related time.</li> </ul>
	<ul> <li>The auto-off function may have worked. This product is equipped with an auto-off function that automatically turns off the power if the remote control is not used for 15 minutes without an input signal.</li> </ul>
When connecting to the	Turn the TV off/on using the remote control.
PC (HDMI), no signal is	Reconnect the HDMI cable.
detected.	Restart the PC with the TV on.
Abnormal Display	<ul> <li>If the product feels cold to the touch, there may be a small "flicker" when it is turned on. This is normal, there is nothing wrong with product.</li> </ul>
	<ul> <li>This panel is an advanced product that contains millions of pixels. You may see tiny black dots and/or brightly coloured dots (red, blue or green) at a size of 1 ppm on the panel. This does not indicate a malfunction and does no affect the performance and reliability of the product. This phenomenon also occurs in third-party products and is not subject to exchange or refund.</li> </ul>
	<ul> <li>You may find different brightness and colour of the panel depending on your viewing position(left/right/ top/down). This phenomenon occurs due to the characteristic of the panel. It is not related with the product performance, and it is not malfunction.</li> </ul>
	<ul> <li>Avoid touching the screen or holding your finger(s) against it for long periods of time. Doing so may produce some temporary distortion effects on the screen.</li> </ul>
	<ul> <li>Displaying a still image for a prolonged period of time may cause image sticking. Avoid displaying a fixed image on the TV screen for a long period of time.</li> </ul>
Generated Sound	<ul> <li>"Cracking" noise: A cracking noise that occurs when watching or turning off the TV is generated by plastic therma contraction due to temperature and humidity. This noise is common for products where thermal deformation is required.</li> </ul>
	<ul> <li>Electrical circuit humming/panel buzzing: A low level noise is generated from a high-speed switching circuit, which supplies a large amount of current to operate a product. It varies depending on the product. This generated sound does not affect the performance and reliability of the product.</li> </ul>

۲

## $\triangle$

۲

• When cleaning the product, be careful not to allow any liquid or foreign objects to enter the gap between the upper, left or right side of the panel and the guide panel. (Depending on model)

- Make sure to wring any excess water or cleaner from the cloth.
- Do not spray water or cleaner directly onto the TV screen.
- Make sure to spray just enough of water or cleaner onto a dry cloth to wipe the screen.

# Regulatory

۲

### WARNING! (STABILITY HAZARD)

A television set may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

- ALWAYS use cabinets or stands or mounting methods recommended by the manufacturer of the television set.
- ALWAYS use furniture that can safely support the television set.
- ALWAYS ensure the television set is not overhanging the edge of the supporting furniture.
- ALWAYS educate children about the dangers of climbing on furniture to reach the television set or its controls.
- ALWAYS route cords and cables connected to your television so they cannot be tripped over, pulled or grabbed.
- NEVER place a television set in an unstable location.
- NEVER place the television set on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the television set to a suitable support.
- NEVER place the television set on cloth or other materials that may be located between the television set and supporting furniture.
- NEVER place items that might tempt children to climb, such as toys and remote controls, on the top of the television or furniture on which the television is placed.

If the existing television set is going to be retained and relocated, the same considerations as above should be applied.

### Symbols

۲

$\sim$	Refers to alternating current (AC).
	Refers to direct current (DC).
	Refers to class II equipment.
Ψ	Refers to stand-by.
	Refers to "ON" (power).
4	Refers to dangerous voltage.

#### India region only.

\* For BEE energy label applied models only.

#### ATTENTION:

This product is qualified for the BEE Star rating in the 'Home' Mode. The Objectives of Star Labeling Program is designed to promote energy efficient products and practices.

When the television is initially set up, it is designed to meet the BEE Star Labeling requirements while maintaining optimum picture guality.

- Changes to certain functionalities of this television (TV Guide, Picture/sound etc) may change the power consumption.
- Depending on such changed setting (eg., Retail mode), the power consumption may vary which possibly could exceed the stated energy consumption.

To reset the television to Star rating qualified settings, select 'Home' mode from the initial set-up procedure in 'factory settings' under the 'Set-up' menu.



(Only India)

### **Environmental information**



Disposal of your old appliance (as per e-waste Rules)

1. When this crossed out wheeled bin symbol is depicted on the product and its operator's manual, it means the product is covered by E-Waste Management Rules India published by MoEF & CC, Govt, of India and are meant to be recycled, dismantled, refurbished or disposed off.

#### 2 Do's :

- a. The product is required to be handed over only to the authorized recycler for disposal.
- b. Keep the product in isolated area, after it becomes non-functional/ unrepairable so as to prevent its accidental breakage.

#### Don'ts •

( )

- a. The product should not be opened by the user himself/herself, but only by authorized service personnel.
- b. The product is not meant for re-sale to any unauthorized agencies/scrap dealer/kahariwalah
- c. The product is not meant for mixing into household waste stream.
- d. Do not keep any replaced spare part(s) from the product in exposed area.
- 3. Any disposal through unauthorized agencies/person will attract action under Environment (Protection) Act 1986.
- 4. This product is complied with the requirement of Hazardous Substances as specified under E-Waste Management Rules India published by MoEF & CC. Govt. of India.
- 5. To locate a nearest collection centre or call for pick-up (limited area only) for disposal of this appliance, please contact No. 08069379999, Toll Free No. 1800-315-9999 for details. All collection centre and pick up facilities are done by third parties with LG Electronics India Pvt. Ltd. Merely as a facilitator. For more detailed information, please visit : http://www.lg.com/in.

#### Battery



- 1. This symbol may be combined with chemical symbols for mercury(Hg), cadmium(Cd) or lead(Pb) if the battery Contains more that 0.0005% of mercury, 0.002% of cadmium or 0.004% of lead.
- 2. All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 3. The correct disposal of Your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.

## पर्यावरणीय जानकारी



अपने पराने निपटान के उपकरण ( ई-अपशिष्ट नियम के अनसार )

जब इस काटे गए पहिये वाले बिन का चिन्ह किसी उपकरण और इसके ओपेस्टर की पुस्तिका के साथ संलय्न होता है तो इसका मतलब है कि इसे "ई-अपिश्चर"(प्रबंधन और हथालन ) नियम के अंतर्गत सम्मिलित किया गया है , और इसे नवीनीकरण, विधदन और निपटान के लिए बनाया गया है।

MoEF & CC भारत सरकार दवारा प्रकाशित (भारतीअ ई अपशिष्ट "(प्रबंधन और हथालन )) 

-----क . उपकरण को सिर्फ अधिकृत पनः नवीनीकरणकर्ता को ही निपटारन करने हेत हस्तांतरित करें । ख. जब उपकरण कार्यरत न हो इसे अलग क्षेत्र में रखें ताकि उपकरण से होने वाली

दुर्घटनाओं से बचा जा सके | न करें

<u>ा कर</u> क. इस उपकरण को स्वयं/खुद नहीं खोलना चाहिए ! उपकरण को केवल अधिकृत अधिकारी के द्वारा ही खोला जाना चाहिए । ख. इस उपकरण को पुनः बिक्री के लिए किसी भी कबाड़ीवाला / भंगार-वाला / अनाधिकृत

संस्थाको न दें।

राप्या भग ग ५। ग. इस उपकरण को किसी घरेलू अपशिष्ट सामान के साथ मिलाकर न रखें । घ. उपकरण के बदले हुए या आतरिक पूरजो को खुले क्षेत्र में न रखें ।

3. यदि किसी अनाधिकृत विभाग या व्यक्ति के द्वारा निपटारन किया जाता है तो यह पर्यावरण (सरक्षा) धार १९८६ के अंतर्गत आता है |

4. यह उत्पाद ई-अपशिष्ट (प्रबंधन और हथालन) नियम के तहत निर्दिष्ट खतरनाक पदार्थो की आवश्यकता का पालन करता है।

भा जावरप्रपत्ता पत्र पालन भारता हु। MOEF & CC भारत सरकार दवारा प्रकाशित (भारतीय ई- अपशिष्ट "(प्रबंधन और हथालन )) 5 उपरोक्त पदार्थों के निपटारन के लिए नजदीकी निपटारन संसथान (संकीर्ण क्षेत्र )में कॉल

5. उर्भवत पदाया का निपटारन का लिए नजदाका निपटारन संसंधान (संकाण तक) में काल करों। अधिक जानकारी के लिए हमारे 08069379999 / टोल फ्री नंबर 1800-315-9999 पर करॉल करों. सभी संग्रहण केंद्र व पिक-अप की सुविधाएं किसी यर्ड- पार्टी जो "LG Electronics India PVL Ltd. "को अपनी सेवाएं प्रदान कर रही हों, से करवाएं । ज्यादा जानकारी के लिए देखें वेब:साईट - http://www.lg.com/in

۲

बैटरी

 $( \bullet )$ 



क . इस प्रतीक को पारा (Hg), कैडमियम (Cd) या सीसा (Pb) के लिए रासायनिक प्रतीकों के साथ जोड़ा जा सकता है यदि बैटरी में 0.0005% पारा, 0.002% कैडमियम या 0.004% सीसा हो।

ख. सभी बैटरियों/संचयकर्ताओं को सरकार या स्थानीय अधिकारियों दवारा नियुक्त निर्दिष्ट संग्रह सुविधाओं के माध्यम से नगरपालिका अपशिष्ट धारा से अलग से निपटाया जाना ु चाहिए।

ग. आपकी पुरानी बैटरियों/संचायकों का सही निपटान पर्यावरण, पशु और मानव स्वास्थ्य के लिए संभावित नकारात्मक परिणामों को रोकने में मदद करेगा।