Buds VS102 Neo



TABLE OF CONTENTS

Safety

· Package Contents and Features

Specifications	02
Power and Pairing	03
Reset and Sizing	04
Charging	05
• Controls	06
Warranty	08

01

09

PACKAGE CONTENTS



Noise Buds VS102 Neo x 1





Charging case x 1

User manual x 1



Thank you card x 1

SPECIFICATIONS

- · Earbud weight: 4.2 g each earbud
- · Speaker driver size: 11 mm
- · Supported profiles: A2DP/AVRCP/HFP/SPP/AVDTP
- · Bluetooth version: 5.3
- · Earbud charging time: Up to 30 minutes
- · Working voltage: 5V
- · Standby time: Up to 500 hours
- Buds Playtime: Up to 7 hours at 70% Volume
- · Bluetooth range: 15 m
- Waterproof rating: IPX5
- · Working temperature: 0-45°C

CHARGING CASE SPECIFICATIONS

- · Charging case weight: 28 g
- · Charging port: Type-C
- The number of earbud charges from the case: 5 times
- · Case charging time: Up to 90 minutes
- · Total playtime with charging case: Up to 40 hours

POWER ON

The earbuds will automatically turn on when you open the charging case.

POWER OFF

The earbuds will automatically turn off once placed inside the charging case with the lid closed.

PAIRING

- Open the charging case.
- · Turn on the Bluetooth of your device.
- Select 'Add Device', and from the list of devices, select 'Noise Buds VS102 Neo'.
- Your Noise Buds VS102 Neo are now paired with your device and ready to use.

Note: Your Noise Buds VS102 Neo will automatically connect to the last paired device as soon as you take them out of the charging case.



RESET

- · Make sure your earbuds are fully charged.
- On your paired devices, delete/remove Noise Buds VS102 Neo from the list of paired devices in the Bluetooth menu.
- · Take out the earbuds from the charging case.
- · Tap either earbud 6 times.
- The LED will blink 3 times and a voice prompt saying "reset"
 will indicate earbuds have been reset.
- Place the earbuds inside the charging case and repeat the pairing process.

CHOOSING YOUR EART-TIP SIZE

Earbuds are fitted with medium-sized tips. However, if you find that they don't fit perfectly, please remove them and try the small and large ear-tips.



Follow the images and chart to learn how to wear earbuds in the right manner.

CHARGING

Earbuds

Place both earbuds inside the charging case to charge them.

Indication (on case)

Solid White LED = Charging



Case

Charge the case via the supplied Type-C charging cable, preferably from any PC or laptop as compared to a USB charger.

Indication (on case)

Flashing red LED = Charging

4 Charging

- Solid red LED = Fully Charged
- IIII Fully Charged

CONTROLS





Answer Call
Tap either earbud twice



Tap twice



Tap twice



End Call
Tap either earbud twice



Tap twice



o o Tap twice



Reject Call
Touch and hold either earbud for
2 seconds

Touch and hold the left earbud for



Touch and



Touch and hold



Voice Assistant
Tap right earbud four times



Touch and





Gaming Mode

2 seconds.

WARRANTY

The warranty covers your Noise product, including accessories, against manufacturing defects (if any) for 1 year from the date of purchase.

Things that are not covered in the warranty are listed below:

- Unauthorized tampering, modifications or repairs of the product.
- Physical damage of the product on the account of abuse, handling, storage, installation or testing including any use that is not by the product manual or documentation, or any other instruction provided along with the Noise product.

For further information on product replacement/refund-related queries, please refer to the terms and conditions mentioned in our online return policy section on www.gonoise.com.

REGISTER YOUR WARRANTY

www.gonoise.com/pages/ warranty-registration





SCAN ME

CUSTOMER QUERY

For any assistance, please reach out to us at support.gonoise.in

SAFETY FOR YOU AND YOUR NOISE BUDS VS102 NEO

Follow these tips to get the best out of your new Noise Buds VS102 Neo:



Do not expose the earbuds to liquids, moisture or humidity as they have electronics and batteries inside.



Do not try to disassemble your earbuds. There are no userserviceable parts inside it.



Don't use abrasive cleaning solvents to clean your new earbuds.
Wipe them down with a slightly damp cloth if and when necessary.



Try not to drop the earbuds and keep them away from sharp objects such as keys in your pockets.



Remove and clean the earbud tips regularly to ensure that you always enjoy the best sound possible.



Only charge your earbuds from 5V USB ports such as phone chargers and laptops or PC chargers.



Do not expose the earbuds to extremely high or low temperatures as this may damage the battery or even deform the plastic parts.



Never listen to music at a high volume or you may permanently damage your hearing.



Do not throw the earbuds in a fire to dispose them. The internal battery may explode.



Pay attention to your surroundings and never wear any earbuds while riding, driving or walking in traffic.

