



BOULT AUDIO

**PROBASS RANGER
USER MANUAL**

Watch the VIDEO tutorial at
boultaudio.com/howto6

OR

Call us at **+91 8595516267**
& enter code **06** for a personalized
training session or queries

Please refer to the **Safety Precautions** mentioned on the last page of this manual before operating this device.

Pairing for the first time

Step 1: Make sure the product is fully charged.

Step 2: Press and hold the multi-function button for 3-4 seconds (approximately) to power-on the headphones and it will indicate with flashing red & blue LED light.
Now, the headphones is in pairing mode & ready to connect with your device.

Step 3: Turn-on the bluetooth on your device & scan until you see "Boult Audio Probass"

Step 4: Click on "Boult Audio Probass" and pair your device with the headphones. Once paired, the headphones will indicate with flashing blue LED light every 2 seconds.
Now, you can enjoy your music & calls.

Auto-pairing Mode (Re-pairing with your device)

Step 1: Turn-on the bluetooth on your device.

Step 2: Press and hold the multi-function button for 3-4 seconds (approximately) to power-on the headphones.

Step 3: The headphones will connect to your same device automatically and it will indicate with blue LED light on the headphones.

If not, connect to "Boult Audio Probass" in the bluetooth settings on your device.

Charging the headphones

- Use only 5V/1A USB charger to charge this product.
- This product or the bluetooth functions cannot/should not be used during charging.
- This headphone will indicate with quick flashing red LED light every 4 seconds when the headphone's battery needs to be charged.
- Solid red LED light will indicate on the headphones while charging.
- Solid red LED light will turn-off on the headphones while charging when the charging is complete.

Functions

- **Play/Pause music**
Single click on the multi-function button to play/pause the music.
- **Answer/End/Reject calls**
Single click on the multi-function button to answer/end a call.
Press & hold the multi-function button for 2 seconds to reject the incoming call.

- **Change music track**

Press & hold the (-) button for 2 second to change the music track to the previous track.

Press & hold the (+) button for 2 second to change the music track to the next track.

- **Increase/Decrease volume**

Single click on the (-) volume button to decrease the volume.

Single click on the (+) volume button to increase the volume.

- **Switch ON/OFF**

Press and hold the multi-function button for 3 seconds (approximately) to power-on the headphones.

Flashing red & blue LED light will indicate on the headphones when powered-on and not connected.

Blue LED light will indicate on the headphones once it is paired with your device.

Press and hold the multi-function button for 3 seconds (approximately) to power-off the headphones.

Red LED light will flash and the headphones will get switched-off.

Safety Precautions

Please make sure to follow the instructions provided in this manual for your safety and to extend the life of the headphones.

- Please keep this device away from extreme heat, humidity or corrosive environment.
- Please don't over-charge the headphones as it will decrease the service life of battery.
- Please use only a good quality phone charger (5V/1A) or USB charging port to charge the headphones.
- This product or the bluetooth function should not be used during charging.