






BOULT AUDIO

BOULT AUDIO VERVE USER MANUAL

For better sound quality experience, suggest use
IOS 8.0/ Android 4.3 or above operating system.

Package Introduction



Instructions

1. Track back
2. On/off /Play/Pause
Press and hold for Power On/Off.
In USB/TF/Bluetooth mode, click to play/pause
3. Mode
Click for source selection
4. Track forward
5. Charging port
6. TF card input slot
7. AUX Input port
8. USB input slot
9. Volume +
Volume -

Main Function

Voice Prompt. USB.TF.Bluetooth.AUX .Voice call

Parameters:

Speaker: 57mm "4 Ω X2

Output power: 5W x2

Frequency Response:100Hz~20K Hz

Bluetooth:

Version: 5.0 BT name: 2107A

Transmission distance no obstacles:10M

Battery:

Capacity: 1200mAh

Charging interface: Micro USB

Charging Voltage:5V/1000mA