



# BEATPODS



## USER MANUAL

### Introduction

Welcome to the Wings True Wireless Generation with the all new Wings Beatpods. We hope you are as excited as us to feel and flaunt your latest soundwear.

But before you dive right in, we strongly recommend going through this user manual thoroughly as it contains important technical information to ensure you have a seamless audio experience with us. Once you are done reading the manual, we are sure you will be all set to.

**FEEL IT! FLAUNT IT!**

②

### What's In The Box

- 2x Bluetooth Earphones
- 1x Portable Charging Case
- 6x Ear Cushions
- 1x User Manual
- 1x Type-C Charging Cable



③

### How To Pair

**Step 1:** Make sure your charging case is charged up. Simply open the lid of the charging case and take the earbuds out of case. Now the earbuds are powered on and will automatically enter the pairing mode. The earbuds are ready to pair with your device.

**Step 2:** Go to the Bluetooth setting of your device. Tap "Wings BeatPods" from the smartphone's bluetooth menu. There's voice prompt after successful connection. This indicates earbuds are connected to your device.

**Step 3:** Congratulations! You are now connected and can start playing media.

**Note:** In case you do not connect to any device within 5 minutes of entering pairing mode, then both earbuds will be automatically powered off. Please put the earbuds back into the case and repeat the process to pair.

④

### Touch Controls Usage

**Play/Pause:** Single Touch the sensor on any one earbud to pause music. Single Touch on any sensor again on any one earbud to resume playing music.

**Adjusting Volume:** Triple Touch the sensor on the right earbuds to increase volume. Triple Touch the sensor on the left earbud to decrease volume.

**Changing Songs:** Double tap on right earbuds to change to next song. Double tap on left earbuds to change to previous song.

**Siri/Google Assistant:** Hold and press any buds for 2 seconds to wake up assistant. Hold and press any buds for 2 seconds to turn off assistant.

### Call Controls

**Answer Incoming Call:** Single Touch on any earbud to answer an incoming call.

**Hang Up Ongoing Call:** While on call, Single Touch again on any earbud to hang up the call.

**Reject Incoming Call:** Long touch and hold for 2 seconds to reject phone call.

⑤

### Charging Function

**Note:** Please only use a 5V adapter to charge the case as higher voltage adapters can destroy the battery of case and earbuds.

**Charging The Case:** When charging the charge case with 5V input, the light is on in a flashing pattern. this indicates that the case is charging. Ones the case is completely charged, the flashing light will get switched to continuous on.

**Charging The Case:** Place the earbuds inside the charging case. The light on the earbuds will be on, this indicates that the buds are being charged. Once the earbuds are completely charged the light on the earbuds will automatically switch off.

### Resetting The Device

For resetting the earbuds, simply put them inside the charging case. The earbuds will automatically reset.

⑥

### Technical Specifications

- Earbuds Charging: 4.8-5.2v/0.5-2A
- Earbuds Working Voltage: 3.2- 4.2V
- Earbuds Charging Current: 5V/200mA
- Charging Case Work Voltage: 3.7-4.2V
- Charging Case Charging Current: 300mA
- Charging Case Turn Off Charging Current: 9uA
- Charging Case Max Discharge Current: 0.8A
- Charging Case Cut Off Current: 5mA
- Recharging Automatically : 60mA

⑦

### Safety And Maintenance

Please read below suggestions in order to helping prolong the product lifespan and clearly understand the warranty clauses:

- Keep the product dry, do not put it in humid conditions to avoid short circuit.
- Do not expose it to the peak sun or high heat for extended period of time as this will short lifespan of electronic components, damage battery and deform some plastic parts.
- Do not put it in cold circumstance to avoid damage to PCB board.
- Do not attempt to dismantle the product, as it maybe unsafe especially for non-professionals.
- Do not use chemical products, detergent, oily liquids to clean the item.
- Do not scratch the surface with sharp items to avoid damaging the case and appearance.
- Do not charge the case for more than 5 hours to avoid loss in battery life.
- Avoid hearing music at maximum volume for long periods of time as this can affect your hearing and is not advisable.

**Note:** Any damage to the product that is not manufacturing defect will lead to warranty being rendered null and void. Therefore, please take utmost care of your product.

⑧