



switch to smart

Warranty



Orient Electric Limited (the Company) warrants to the customer/purchaser of this product that for a period of 12 months from the date of purchase, the Company will repair or replace free of charge any part of the product, should the Company be fully satisfied in its sole discretion that the defect/s is/are due to faulty material or defective workmanship only. The warranty will be subject to the following clauses:

- The warranty is valid only if this card is duly signed and stamped by our authorised dealers and is produced along with the original customer's invoice copu.
- 2. Warranty starts from the date of purchase from our authorised dealers/retailers only.
- The Company or their authorised service agent /dealer will repair /replace all parts failing due to faulty material or defective workmanship pertaining to the product.
- 4. Only the Company or their authorised service agents/dealers can service/repair/attend to/ install/reinstall the product.
- 5. All expenses incurred in collecting the units or parts thereof from the Company's authorised service stations or the dealers of the Company as well as expenses incurred in connection with deputing of service personnel/technicians towards to and fro travel conveyance and other incidentals, etc., will be borne by the customer/purchaser.
- 6. The warranty extended herein is in lieu of all implied conditions and warranties under the law and is confined to the repair or replacement of defective part and does not cover any consequential or resulting liability, damage or loss, whether direct or indirect, arising from such defects. Furthermore, the warranty, in no case shall extend to the payment or any monetary consideration whatsoever for the replacement or return of the product.
- 7. This warranty does not cover corrosion or replacement of plastic or glass components which add decorative value to the product.
- 8. The decision of the Company is final and binding on all matters arising out of this warranty.
- 9. The warranty is issued at Delhi, and the courts at Delhi shall have exclusive jurisdiction over the matters in this warranty.
- 10. The warranty stands null and void in case the product is struck by a force majeure event, which shall include but not be limited to acts of God, including flood, earthquakes, any other natural calamity, accidents, war, fire, or any act of government or other competent authoritu.
- 11. This warranty is applicable in India only.

In addition to the terms and conditions stated above, this warranty is not valid in case of any of the following event:

- 1. The machine is not used according to the instruction given in the instruction manual.
- 2. The warrantu specificallu excludes any problems arisina out of mishandlina, wilful damage, improper storage of the product/its parts.
- 3. If the electrical power supply voltages are not within the stipulated norms (Supply Voltage 230V AC 50Hz).
- 4. Any repair work/installation carried out by a person other than Orient Electric Authorised Service Centre / Service Agent.
- 5. Normal wear and tear of the product.
- 6. Damage due to chipping, peeling, plating or denting.
- 7. The serial number is deleted, defaced or altered.
- 8. If the original purchase receipt/ invoice is not available

9	
5	

(Please retain for your personal record)

			J 1	,
Serial No.				
_				
		Ph. No		
		Ph. No		
-	,	Date of Purchase		
5				

BRANCH OFFICES

North Region

Head Office: 240, Okhla Industrial Estate Phase III, New Delhi 110020

Delhi: 62, Okhla Industrial Estate Phase III, New Delhi 110020

Chandigarh: 840, First Floor, NAC Manimajara, UT Chandigarh 160101

Rajasthan: C-176 Road Number 9J, V.K.I. Area Jaipur 302013

Uttar Pradesh: 607, 6th Floor, Ratan Square Marg, Lucknow 226001

Noida: C-130, Sector 63, Noida 201301

East Region

Assam: Nilakshi Talukdar Campus, Opp Vodafone Head Office, NH-37, Katabari, Guwahati 781035

Bihar: 4th Floor, Sai Tower, Beside Hotel Utsav, New Dak Bunglow Road.Patna 800001

Jharkhand: Modi Heights, Phase 1, 4th Floor, Office No 401, Ratu Road, Near Durga Mandir Ranchi 834001

Odisha: Badadhanpur, Puri Bypass Road, Bhubaneswar 751002

West Bengal: 6, Ghore Bibi Lane, Behind Swabhumi, Kolkata 700054

South Region

 $\textbf{Telangana:} \ 6\text{-}3\text{-}1090 \ \ \textbf{C, R K Plazs, 2}^{\text{nd}} \ \ \textbf{Floor, Raj Bhawan Road, Somajiguda, Hyderabad 500082}$

Chennai: Heavitree' 2nd Floor, Unit B, No 47, Spur Tank Road, Chetpet, Chennai 600031

Karnataka: SY No 73, Harokyathanahalli Dasanapura Hobli, Makali Post Tumkur Main Road Bangalore 562162

Kerala: Kollamkuzhi Business Square, 5th Floor, NH Bypass, Vytila, Cochin 682019

West Region

Chhattisgarh: G.D. Warehousing, Opp. Reliance Petrol Pump Ring Road No. 2, Gondwara, Raipur, Chhattisgarh, 493221

Gujarat: Survey No 107 Village Jetalpur, Near Gokulesh Rice Milltaluka Dascroi N.H. 8 Ahmedabad 382426

Madhya Pradesh: Survey No 275 1 1, Kelodhala, SDA Compound, Dewas Naka Indore 452010 Mumbai: 604, 6th Floor, Dev Corpora, Cadbury Junction, Eastern Express Highway, Thane (West),

Mumbai 400601

Pune: Gat No 173 Wade Bolhai Road Vill Kesnand Tal Gaveli Dist Pune 412207

Nagpur: Shriyash Heights, Block No 402, 4th Floor, Plot No 95, Lendra West Precinct, Ramdaspeth,

Nagpur 440010



FANS | HOME APPLIANCES | LIGHTING | SWITCHGEAR



orient





switch to smart

USER MANUAL

ORIENT AVANTE 90 & 105 | DESERT AIR COOLER CD9001H | CD1051H







Orient Helpline no.: 1800 103 7574 (Toll Free)



switch to smart

((CCK BIRLA GROUP



switch to smart

orient

switch to smart

ORIENT AVANTE 90 & 105 | DESERT AIR COOLER

To begin with, thank you for choosing Orient Avante 90 & 105.

This desert cooler is a durable and high performance cooler that enables quick cooling and ensures a constant supply and circulation of fresh air. Its tank capacity enables uninterrupted cooling for long hours. Its superior finish and specially designed knob panels are nothing less than revolutionary.

Avante cools up sto 37 sqmts. Estimated area based on 3 mtrs of ceiling height and all-sides-covered room.

Avante is perfect for your living room, party hall, shops, gums, restaurants, closed outdoor etc.

Some of the keu features*

Air Deliveru: Orient air coolers have specially designed 4 leaf blade with silent noise feature.


Lower Power Consumption: Low power consumption air coolers helps to cool the room by trading the possibly minimum power. So, they are the perfect solution to have during summers. Avante gir cooler consumes less power. saves money on electricity and provides a cool environment.

Cooling medium: Thanks to DenseNest® Technologu in the honeucomb pads. Orient air coolers have a smaller aap between the cooling flutes, which helps them in retaining more water and leads to better cooling. Orient provides Himalayan pine wood wool cooling media option to its customers that has efficient evaporation of water and ensures effective cooling.

Even Water Distribution System: One of the key features of an Orient air cooler is its even water distribution sustem. This unique water sustem delivers water to the cooling pads in no time, which results in faster cooling. But that's not all. You also get maintenance-free operations for months with no hole cloaging, and of course, cool gir.

Three Speeds: You can set the speed of the fan to any of the three levels: high, medium and low, and enjoy the desired air delivery.

Water Level Indicator: An easy way to view the water level is the indicator in the front panel, which allows you to keep a check.






Inverter Compatibility: Orient air coolers have an inverter compatible fan and pump motor that ensures an uninterrupted cooling during power cuts.

Orient air coolers are designed to have modern aesthetics and are made of thermoplastic material having an excellent finish and corrosion-free life.

#Features may vary from product to product; refer the technical specifications table for more clarity.


Know Your Cooler



This image is for reference only. Actual product might differ.

- 1. Filling of Water: Fill the tank though the garden pipe or Mug to ensure no slippage.
- 2. Power Supply: Plug in the mains cord of your air cooler to the wall socket. Ensure the plug is properly earthed & is in the 'OFF' position while plugging. Ensure that your cooler is plugged into the specified voltage & frequency outlet. Switch 'On' the power supply.
- 3. Pre Soaking: Before switching on the cooler fan, it is advisable to run the pump for a few minutes to ensure uniform soaking of water by the cooling media and avoiding sprinkling of water, if anu.


Circuit Diagram



SM- Swing motor, M - Fan motor, P - Pump


S2. S3 - ON/OFF switch

Control Panel Functions



- SPEED KNOB: Rotate the knob to choose different speed
- 2. **OFF**: Rotate the knob to **OFF** to switch off the fan.
- 3. HIGH: Rotate the knob to HIGH to choose maximum speed of fan.
- 4. MED: Rotate the knob to MED to choose medium speed of fan.
- 5. **LOW**: Rotate the knob to **LOW** to choose minimum speed of fan.
- 6. COOL KNOB: Rotate the knob to OFF to switch off the $\operatorname{\mathsf{DUMD}}$ function or to $\operatorname{\textbf{ON}}$ to switch on the $\operatorname{\mathsf{PUMP}}$ function.
- 7. **SWING**: Rotate the knob to **OFF** to switch off the swing function or to $\mathbf{O}\mathbf{n}$ to switch on the swing function.

Installation - Indoor



Technical Specification

Model IIo.		CD9001H	CD1051H	
Mode of Operation		Manual	Manual	
Cooling Medium		Denseflest® Honeycomb	DenseNest® Honeycomb	
Water Tank Capacity (Litres upto brim)		90 Ltrs	105Ltrs	
Power Consumption	(Wattage)**	190W	190 W	
Air Delivery (Cu	.m./hr)**	4500	4500	
Air Throw Distance (Meters)**		18	18	
Auto Fill		По	По	
Water Level Indicator		Yes	Yes	
Speed Control - 3		H,M,L	H,M,L	
Fan Type		Fan/ 16 inch	Fan/ 16 inch	
Wheels		5 costor wheels	5 castor wheels	
Vertical Louvre Movement		Motorised	Motorised	
Horizontal Louvre Movement		Manual	Manual	
	L	70.5	70.5	
Dimensions With Packaging (cm)	W	51	51	
	Н	124	133	
Net Weight (KG)		17.7	19.2	
Gross Weight (KG)		23.4	24.8	
Product Warranty*		12 Months	12 Months	

Specification of DenseNest® honeycomb may vary from product to product.

Supply Voltage 230V AC - 50Hz

As product upgradation is a continuous process, design and specifications are subject to change without prior notice.

- *Applicable in India only.
- **All the technical parameters are as per Orient testing standard.

Safety Precautions

((CK BIRLA GROUP



- Water and electricity don't like each other. Disconnect the mains supply before filling water in the tank.
- Do not fill the water manually into the cooler when it is in operation mode. Like never ever.
- Unless you want a baby swimming pool, do not move the cooler rapidlu when the tank is filled with water.
- Always disconnect the electric mains before opening the side and back arills. Else, be arilled.
- Keep the cooler at a safe distance from fire, kerosene or other inflammable materials. You know whu.
- Close supervision is required while using the cooler near children. Theu are children, after all.
- For efficient cooling, ensure that the sides of the cooler are away from air blockages. • Do not cover or block any air inlet or outlet. Else, no cool
- air. No sound sleep. Kindly ensure you have appropriate voltage that matches
- the specifications required for your cooler model. • This is very important. Read it twice. Place the cooler on
- This is even more important. Read it thrice. Power supplu to the cooler must have proper earthing.
- The product is not to be used by people (including children) with reduced phusical, sensory or mental capabilities or a lack of experience and knowledge, unless they have been given supervision or instructions.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent in order to avoid a

Care



- off all the electric switches and water supply. • Operate the knob panel gently. The cooler won't function
- even if one goes missing.
- Do not wipe the cooler with harsh chemical, scrubbing powder or thinner. It will leave a spot on the cooler.
- No matter who tells you never add bleaching chemicals or other additives into the water tank.
- Before moving or relocating the cooler, ensure that the mains cord is unplugged, and the water tank is emptu.
- Just like you, this cooler also doesn't like heavy load to be kent on its head.
- Kindly do not cover the air cooler with cloth/plastic cover even if you bought specially for it.

Maintenance



- pads simultaneouslu, every month, Remember Swaach Bharat.
- Replace the cooling pads once in two years.
- After the summer season, ensure that the water is drained. off completelu.
- Clean the DenseNest® honeucomb pads using a water hose or directly under the tab until the dust is removed. Cleaner cooling pads help in efficient cooling.

Trouble Shooting

levelled flooring/base.



