



switch to smart

Warranty



Orient Electric Limited (the Company) warrants to the customer/purchaser of this product that for a period of 12 months from the date of purchase, the Company will repair or replace free of charge any part of the product, should the Company be fully satisfied in its sole discretion that the defect/s is/are due to faultu material or defective workmanship only. The warranty will be subject to the following

- 1. The warranty is valid only if this card is duly signed and stamped by our authorised dealers and is produced along with the original customer's invoice copy.
- 2. Warranty starts from the date of purchase from our authorised dealers/retailers only.
- 3. The Company or their authorised service agent /dealer will repair /replace all parts failing due to faulty material or defective workmanship pertaining to the product.
- 4. Only the Company or their authorised service agents/dealers can service/repair/attend to/ install/reinstall the product.
- 5. All expenses incurred in collecting the units or parts thereof from the Company's authorised service stations or the dealers of the Company as well as expenses incurred in connection with deputing of service personnel/technicians towards to and fro travel conveyance and other incidentals, etc., will be borne by the customer/ purchaser.
- 6. The warranty extended herein is in lieu of all implied conditions and warranties under the law and is confined to the repair or replacement of defective part and does not cover any consequential or resulting liability, damage or loss, whether direct or indirect, arising from such defects. Furthermore, the warranty, in no case shall extend to the payment or any monetary consideration whatsoever for the replacement or return of the product.
- 7. This warranty does not cover corrosion or replacement of plastic or glass components which add decorative value to the product.
- 8. The decision of the Company is final and binding on all matters arising out of this warranty.
- 9. The warranty is issued at Delhi, and the courts at Delhi shall have exclusive jurisdiction over the matters in this warranty.
- 10. The warranty stands null and void in case the product is struck by a force majeure event, which shall include but not be limited to acts of God, including flood, earthquakes, any other natural calamity, accidents, war, fire, or any act of government or other competent authoritu.
- 11. This warranty is applicable in India only.

In addition to the terms and conditions stated above, this warranty is not valid in case of any of the following event:

- 1. The machine is not used according to the instruction given in the instruction manual.
- 2. The warranty specifically excludes any problems arising out of mishandling, wilful damage, improper storage of the product/its parts.
- 3. If the electrical power supply voltages are not within the stipulated norms (Supply Voltage 230V AC 50Hz).
- 4. Any repair work/installation carried out by a person other than Orient Electric Authorised Service Centre / Service Agent.
- 5. Anti Mosquito Breeding kit is a consumable part and not covered under warranty.
- 6. Normal wear and tear of the product.
- 7. Damage due to chipping, peeling, plating or denting.
- The serial number is deleted, defaced or altered.
- 9. If the original purchase receipt/ invoice is not available

7	5)		
) 4	1	5		

(Please retain for your personal record

Serial No	
Name and address of Customer	
	Ph. No
Email id	
	Ph. No
Bill No	Date of Purchase

BRANCH OFFICES

NORTH REGION

Head Office: 240. Okhla Industrial Estate Phase III. Dew Delhi - 110020

Delhi: 62. Okhla Industrial Estate Phase III. New Delhi - 110020

Chandigarh: 840, First Floor, NAC Manimajara, UT Chandigarh - 160101 Uttar Pradesh: 607, 6th Floor, Ratan Savare Mara, Lucknow - 226001

Noida: C-130, Sector 63, Noida - 201301

EAST REGION

Bihar: 4th Floor, Sai Tower, Beside Hotel Utsav, New Dak Bunglow Road Patna - 800001 Jharkhand: Modi Heights, Phase-1, 4th Floor, Office No-401, Ratu Road, Near Durga Mandir Ranchi - 834001 West Bengal: 6, Ghore Bibi Lane, Behind Swabhumi, Kolkata - 700054

SOUTH REGION

Telanaana: 6-3-1090/C, R K Plazs, 2nd Floor, Rai Bhawan Road, Somaiiauda, Huderabad - 500082 Chennai: Heavitree' 2nd Floor, Unit - B, No-47, Spur Tank Road, Chetpet, Chennai - 600031 Kerala: Kollamkuzhi Business Square, 5th Floor, NH Bypass, Vytila, Cochin - 682019

WEST REGION

Chhattisgarh: G.D. Warehousing, Opp. Reliance Petrol Pump Ring Road No. 2, Gondwara, Raipur, Chhattisgarh, India - 493221

Gujarat: Survey No 107 Village Jetalpur, Near Gokulesh Rice Milltaluka Dascroi, N.H. 8, Ahmedabad - 382426

Madhya Pradesh: Survey No 275/1/1, Kelodhala, SDA Compound, Dewas Naka, Indore - 452010

Mumbai: 604, 6th Floor, Dev Corpora, Cadbury Junction, Eastern Express Highway, Thane (West),

Mumbai - 400601

Naapur: Shriuash Heights, Block No. 402, 4th Floor, Plot No. 95, Lendra West Precinct, Ramdaspeth,

Naapur - 440010



FANS | HOME APPLIANCES | LIGHTING | SWITCHGEAR



orient

Fans • Home Appliances • Lighting • Switchgear

switch to smart

Orient Electric Limited





switch to smart

Orient Helpline no.: 1800 103 7574 (Toll Free)

USER MANUAL

Premia 26, 36 & 45 | PERSONAL AIR COOLER CP2601H | CP2602H CP3602H | CP3603H CP4501H | CP4502H orient ecore

(CK BIRLA GROUP

switch to smart

CP2601H CP3602H CP4501H

switch to smart

switch to smart

ORIENT PREMIA 26, 36 & 45 | PERSONAL AIR COOLER

To begin with, thank you for choosing Orient Premia. This personal gir cooler has been specially designed for those who have space issues. With castor wheels it can be easily moved around the house.

Premia cools upto 14 sqmts. Estimated area based on 3 mtrs of ceiling height and all-sides-covered room.

Premia is perfect for your bedroom, study room, kid's room, dining area, small offices, small shops etc.

Some of the keu features#

Air Deliveru: Orient air coolers have specially designed fans and blowers that ensure maximum air deliveru.

DenseNest® Honeucomb Pads: Thanks to DenseNest® Technology, Orient air coolers have a smaller gap between the cooling flutes, which helps them in retaining more water and leads to better cooling.

Even Water Distribution Sustem: One of the keu features of an Orient air cooler is its even water distribution sustem. This unique water system delivers water to the cooling pads in no time, which results in faster cooling. But that's not all. You also get maintenance-free operations for months with no hole cloaging, and of course, cool gir.

Three Speeds: You can set the speed of the fan to any of the three levels: high, medium and low, and enjoy the desired air deliveru.

Dust Filter: Orient Air coolers have dust filters that ensure you only get cool gir, minus dust and pollen.

Ice Chamber: A compartment where you can pour ice cubes/blocks for quick cooling.

Drain Plug: Orient air coolers have a drain plug that ensures hassle-free drainage of dirtu water, making it simpler for

Water Level Indicator: An easy way to view the water level is the indicator in the front panel, which allows you to keep a

Castor Wheels: The cooler is mounted on four castor wheels, which make it convenient to wheel it around from one place to another.




Inverter Compatibility: Orient air coolers have an inverter compatible fan and pump motor that ensures an uninterrupted cooling during power cuts.

Orient air coolers are designed to have modern aesthetics and are made of thermoplastic material having an excellent finish and corrosion-free life.

#Features may vary from product to product; refer the technical specifications table for more claritu.

Know Your Cooler






Wheels

1. The cooler should be placed near the window/door to allow fresh air circulation in your room.

Indicator


- 2. Filling of Water: It is advisable to use garden pipe / Mug to ensure no spillage from Ice chamber.
- 3. Power Supply: Plug in the mains cord of your air cooler to the wall socket. Ensure the plug is in the 'OFF' position while plugging. Ensure that your cooler is plugged into the specified voltage & frequency outlet. Switch 'ON' the power supplu.
- 4. Pre Soaking: Before switching on the cooler fan, it is advisable to run the pump for a few minutes to ensure uniform soaking of water by the cooling media and avoiding sprinkling of water, if any.

Circuit Diagram



Legend S1- speed switch S2 - Function switch SM - swing motor BM - Blower motor PM - Pump motor


Control Panel Functions



- 1. **SPEED KNOB**: Rotate the knob to choose different speed
- OFF: Rotate the knob to OFF to switch off the blower.
- 3. HIGH: Rotate the knob to HIGH to choose maximum speed of blower.
- 4. **MED**: Rotate the knob to **MED** to choose medium speed of plomer
- 5. **LOW**: Rotate the knob to **LOW** to choose minimum speed of blower.
- 6. **FUNCTION KNOB**: Rotate the knob to choose different functions. 7. **OFF**: Rotate the knob to **OFF** to switch off swing and
- 8. **PUMP**: Rotate the knob to **PUMP** to switch **ON** the pump
- function only. 9. SWING/PUMP: Rotate the knob to SWING/PUMP to
- switch on the pump and swing functions together. 10. SWING: Rotate the knob to SWING to switch ON the

SWING function onlu.

Installation - Indoor



Technical Specification

Model De

Model F	CP2602H	CP3603H	CP4502H				
Mode of Ope	Manual	Manual	Manual				
Cooling Me	DenseNest® Honeycomb	DenseNest® Honeycomb	DenseNest® Honeycomb				
*Water Tank Capacity (26 Ltrs	36 Ltrs	45 Ltrs				
*Power Consumpti	140W	140W	140W				
*Air Delivery (1500	1500	1500				
*Air Throw Distor	7.6	7.6	7.6				
Water Level In	Yes	Yes	Yes				
Speed Contr	H,M,L	H,M,L	H,M,L				
Blower / Far	Blower	Blower	Blower				
Castor wheel		4 Castor Wheels					
Dust Filte	Yes	Yes	Yes				
Ice Cham	Yes	Yes	Yes				
Vertical Louvres	Motorised	Motorised	Motorised				
Horizontal Louvre	Manual	Manual	Manual				
	L	53.5	53.5	53.5			
Dimensions With Packaging (cm)	W	42	42	42			
r dekaging (cin)	Н	81	90	98			
Net Weight	9	10	11				
Gross Weigh	11	12	13.5				
Product Warr	12 Months	12 Months	12 Months				
*All the technical parameters are as per Orient testing standard							

*All the technical parameters are as per Orient testing standard. Specification of DenseNest® honeycomb may vary from product to product.

Supplu Voltage 230V AC - 50Hz As product upgradation is a continuous process, design and specifications are subject to change without prior notice. #Applicable in India onlu.

Safety Precautions



- Water and electricity don't like each other. Disconnect the mains supply before filling water in the tank.
- Do not fill the water manually into the cooler when it is in operation mode. Like never ever.
- Unless you want a baby swimming pool, do not move the cooler rapidly when the tank is filled with water.
- Always disconnect the electric mains before opening the side and back grills. Else, be grilled.
- Keep the cooler at a safe distance from fire, kerosene or other inflammable materials. You know whu.
- Close supervision is required while using the cooler near children. They are children, after all.
- For efficient cooling, ensure that the sides of the cooler are away from air blockages.
- Do not cover or block any air inlet or outlet. Else, no cool gir. No sound sleep. • Kindly ensure you have appropriate voltage that matches
- the specifications required for your cooler model. • This is very important. Read it twice. Place the cooler on
- levelled flooring/base. • The product is not to be used by people (including children) with reduced physical, sensory or mental capabilities or a lack of experience and knowledge, unless they have been
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent in order to avoid a hazard.

Care



- off all the electric switches and water supply. • Operate the knob panel gently. The cooler won't function
- even if one goes missing.
- Do not wipe the cooler with harsh chemical, scrubbing powder or thinner. It will leave a spot on the cooler.
- No matter who tells you never add bleaching chemicals or other additives into the water tank.
- Before moving or relocating the cooler, ensure that the mains cord is unplugged, and the water tank is emptu.
- Just like you, this cooler also doesn't like heavy load to be kept on its head.
- Kindlu do not cover the air cooler with cloth/plastic cover even if you bought specially for it.

Maintenance



- It is recommended to drain the water in the cooler and clean the cooling pads simultaneously, every month.
- Replace the cooling pads once in two years.
- After the summer season, ensure that the water is drained off completelu.
- Clean the DenseNest® honeycomb pads using a water hose or directly under the tab until the dust is removed. Cleaner cooling pads help in efficient cooling.
- It is recommended to clean the dust filter monthlu bu removing the honeucomb strip & honeucomb from the respective arill to

separate the 🕡 dust filter for washing/cleaning.



Trouble Shooting

given supervision or instructions.



