

pTron

Bassbuds Duo

True Wireless Stereo Earbuds



User Manual

Control Buttons Descripton:



Touch Sensitive Area (TSA)

Smart Power On & Pairing:

1. Open the charging case Or Touch TSA on both the earbuds for 3 seconds.
2. Wait for 2-3 seconds until L & R earbuds pair to each other.
3. Turn on the Bluetooth on your phone & search "pTron TWS" to connect with the device.

Note: TSA stands for Touch Sensitive Area

Smart Power Off:

Touch TSA on both the earbuds for 3 seconds Or Keep both the earbuds into the charging case and close it properly.

Note: TSA stands for Touch Sensitive Area

Connectivity Bluetooth - Automatic:

Just turn on the Bluetooth earbuds. They will automatically connect to the last connected device (Instant wake & pair technology).

Calling or Music through Mono & Dual Buds:

Mono Bud Use - Just place the right or left earbud back into the charging case.

Dual Buds Use - Use left & right earbuds together.

Voice Assistant Activation:

Touch TSA on either earbud for 2-3 seconds.

Call & Music Functions:

Answer/Hangup a Phone Call - Touch TSA on either earbud once.

Reject a Phone Call - Touch TSA on either earbud for 2 seconds.

Music Play/Pause - Touch TSA on either earbud once.

Next Song - Touch TSA on right earbud twice.

Previous Song - Touch TSA on left earbud twice.

Redial - Touch TSA on right earbud thrice.

Note: TSA stands for Touch Sensitive Area

Charging the Earbuds:

1. Place both the earbuds into the charging case properly. The earbuds will power off automatically when placed into the case.
2. Earbuds LED will start glowing red, which means it is on charging. After full charge earbuds LED light will stop blinking.
3. Charging case LED light will be blue during charging the earbuds. It will turn off when earbuds are fully charged.

Charging the Case:

1. Connect the C-Type cable to the case and the USB end to a 5V power source.
2. The Red light indicator in the front of the charging case will start blinking.
3. When the case is fully charged, Red light will be steady. Remove the charging case from the power supply.

Caution

Using incompatible USB cable or high voltage chargers can damage the product & void the product warranty.

We strongly recommend using DC5V-1A chargers & the USB cable included in the package.

Troubleshooting

Scenario 1: One Earbud is Not Working

1. Place both the earbuds in the charging case.
2. Take out both the earbuds together from the charging case.
3. Wait until L & R earbud pair to each other. After successful matching, only 1 earbud will flash Blue & Red light.
4. Turn ON the Bluetooth on your phone, search for "pTron TWS" & connect.

roubleshooting

Scenario 2: Earbuds Not Connecting/Scanning

1. Place both the earbuds in the charging case.
2. Take out both the earbuds together from the charging case.

3. Restart your Bluetooth device or phone.
4. Now, search for "pTron TWS" on your Bluetooth device & connect.

Troubleshooting

Scenario 3: Earbuds Disconnecting During a Phone Call

1. Charge earbuds 100% before use.
2. Restart the earbuds and reconnect with your device

Disclaimer:

The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purposes only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.