



**BOULT AUDIO**

# **XCHARGE USER MANUAL**

For better sound quality experience, suggest use  
IOS 8.0/ Android 4.3 or above operating system.



## Product Introduction

---



### Button illustration:

1. Multi-function Button
2. USB TYPE-C
3. LED indicator
4. Volume-/Previous Track
5. Volume+/Next Track
6. MIC



## **CHARGING YOUR EARPHONE**

---

Your Bluetooth earphone come with a built-in rechargeable battery and a Type-C charging cable

### **Charge fully before use**

Using the charging cable through the corresponding port to charge the battery, the LED Indicator will show red, while charging, and show blue once fully charged. Charging time is approximately 1 hrs.

## **GETTING STARTED**

---

To use your Bluetooth earphones, Please follow the steps below.

1. Ensure your Bluetooth earphones are fully charged.
2. Pair your Bluetooth earphones to a Bluetooth- enabled device prior to use. (See Pairing Instructions)

### **Powering On the Earphone**

Press and hold the Multi- Function Button for 3 seconds until blue light on

### **Powering Off the Earphone**

Once powered on, press and hold the Multi- Function Button for 3 seconds until red lights on and out.

## PAIRING YOUR EARPHONE

---

1. Power on your bluetooth earphones and it will enter pairing mode automatically after 6 seconds, if it is not already paired with any devices. If it already gets connected to a paired device, please disconnect it from that paired device to enter pairing mode again.
2. Activate the bluetooth function of your devices and start to search.
3. Select "BOULT AUDIO XCHARGE" from the listed devices and connect.
4. The indicator will flash blue every 10 seconds once successfully paired/connected.

### **Note:**

1. The earphones should be with in 30ft range from your Bluetooth devices while pairing/playing.
2. The earphones will automatically power off without connection for 5 minutes

## MUSIC MODE

---

### **Adjust Volume:**

Short press the Volume+ to raise the volume or Volume- to lower the volume by your Bluetooth devices.

### **Play/Pause Music:**

Once connected, short press the Multi- Function Button to play or pause music.

### **Previous Track:**

Press and hold the Volume- 1 second to the Previous Track.

### **Next Track:**

Press and hold the volume+ 1 second to the next track.

## CALL MODE

---

### Answering a Call:

short press the Multi-Function Button to answer an incoming call, or answer the call normally via your mobile phone.

### Rejecting a Call:

Press and hold the Multi-Function Button for 2 seconds to reject the incoming call.

### Ending a Call:

Short press the Multi-Function Button to end the call or end the call directly from your mobile phone.

### Voice Assistant:

Once connected, Double click the Multi-Function Button for 2 second to access voice assistant of your smart phone.

LED INDICATOR	
STATUS	INDICATOR
Power On	Blue (slow flash)
Power Off	Red (solid and out)
Charging	Red (solid)
Fully Charged	Blue (solid)
Pairing	Blue/Red (quick flash)
Connected	Blue (slow flash)
Low Power	Red (quick flash)