

PROBASS BUSTER USER MANUAL

For better sound quality experience, suggest use S 8.0/ Android 4.3 or above operation system. Please refer to the **Safety Precautions** mentioned on the last page of this manual before operating this device.


Pairing for the first time

- Step 1: Make sure the product is fully charged.
- Step 2: Press and hold the multi-function button for 5-6 seconds (approximately) to power-on the neckband. The neckband will indicate with red & blue flashing LED light. Now, the neckband is in paring mode & ready to connect with your device.
- Step 3: Turn-on the bluetooth on your device & scan until you see "Boult Audio Probass"
- Step 4: Click on "Boult Audio Probass" and pair your device with the neckband. Once paired, the neckband will indicate with blue flashing LED light.

Now, you can enjoy your music & calls.

Auto-pairing Mode (Re-pairing with your device)

Step 1: Turn-on the bluetooth on your device.
Step 2: Press and hold the multi-function button for 3-4 seconds (approximately) to power-on the Neckband.
Step 3: The neckband will connect to your same device automatically. If not, connect to "Boult Audio Probass" in the bluetooth settings on your device.



Charging the neckband

- Use only 5V/1A USB charger to charge this product.
- This product or the bluetooth functions cannot/should not be used during charging.
- This neckband will indicate with quick flashing red LED light when the neckband's battery need to be charged.
- Solid red LED light will indicate on the neckband while charging.
- Solid blue LED light will indicate on the neckband once charging is complete.

Functions

- Voice assistance
 Click on the multi-function button for 2 seconds to activate
 the Google assistant/Siri.
 Google assistant/Siri will pop up on your phone screen.
- Play/Pause music
 Single click on the multi-function button to play/pause the music.
- Answer/End/Reject calls

Single click on the multi-function button to answer/end a call.

Press & hold the multi-function button for 2 seconds to reject the incoming call.

Redialing the last call

Double click on the multi-function button to redial the last phone number on your mobile phones dialing list.

Change music track

Press & hold the (-) volume button for one second to change the music track to the previous track.

Press & hold the (+) volume button for one second to change the music track to the next track.

Increase/Decrease volume

Single click on the (-) volume button to decrease the volume.

Single click on the (+) volume button to increase the volume.

Switch ON/OFF

Press and hold the multi-function button for 3-4 seconds (approximately) to power-on the neckband. Flashing blue LED light will indicate on the neckband when powered-on.

Press and hold the multi-function button for 3-4 seconds (approximately) to power-o ffthe neckband. Red LED light will flash and the neckband will get switched-off.

Safety Precautions

Please make sure to follow the instructions provided in this manual for your safety and to extend the life of the neckband.

- Please keep this device away from extreme heat, humidity or corrosive environment.
- Please don't over-charge the neckband as it will decrease the service life of battery.
- Please use only a good quality phone charger (5V/1A) or USB charging port to charge the neckband.
- This product or the bluetooth function should not be used during charging.