



USER MANUAL

WAVE PLAY

boAt WAVE PLAY

CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



Note: Once your watch is at 10% battery, it will automatically switch to power saving mode which will disable all functions.

TURNING THE WATCH ON/OFF


To turn the watch on/off, long-press the side button for 3-5 seconds. You can wake the screen by lifting your wrist.



Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times. iPhone will not prompt any information unless you complete Bluetooth pairing with WAVE Play.

CONNECTING TO THE APP

- Download the boAt Crest app on your phone. Available on both App Store (iOS 12.0 and above) and Google Play Store (Android 6.0 and above).
- Scan [QR CODE] (Also available on the watch).
- Connect the device with the boAt Crest app.
- Select Wave Play on the home screen of the app and click pair to connect.
- To use all features of your Wave Play seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.
- Turn your phone's Bluetooth and GPS on.
- Disable battery optimization.



Google Play | Download on the App Store

SYNCING YOUR SMARTWATCH TO THE APP

Heart Rate Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.



Note: Measurements are for reference only and not for medical purposes.

Guided Breathing Mode

Click on the breath training icon to regulate your breathing with the instructions given to relax.



Note: Measurements are for reference only and not for medical purposes.

NAVIGATING THROUGH THE FUNCTIONS

SWIPE UP FOR MAIN MENU



Activities: Click on the sports mode icon to choose from 10 different sports modes: Walking, Traveling, Running, Basketball, Football, Baseball, Tennis, Hike, Cycling, Motor Cycling. To start or stop the exercise, press the home button, then finish to end the exercise.

Notes: All records will be available on the app if you keep it synchronized.

Notifications



Tap on this icon to check notifications.

Activity Records



Tap to check Activity Records of the day.

Sleep Monitor



Tap on the icon to review the sleep data of the previous night. Once the asleep criteria is met, your Wave Play will start recording from 8 pm at night to 10 am in the morning the next day. Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movements. You can check the data on the app only after the asleep criteria is met. You can also track sleep scores on the boAt Crest app.

Notes: *For accurate sleep data recording, the asleep criteria has to be met which includes limited movement, wrist positions and angles, and more. *The awake criteria will be met only after it records some noticeable movement.

Stopwatch



Tap on the icon to start the stopwatch.

Flashlight



Tap on this to turn your dial into a flashlight.

WAVE PLAY

Settings

Camera Control Mode

Tap on the remote camera icon on your watch Wave Play to click a photo from your phone.



Note: Turn the camera on from your phone to use this feature.


Music Control

Tap on the remote music control icon on your watch Wave Play to play music from your phone.

*Note: Some app with different protocols might not work.

Screen Sleep

Tap on this to set screen sleep duration.



System

Do Not Disturb

Tap on this to dismiss all notifications except alerts.



Maintenance

All data will be erased if watch is reset.

Swipe down for shortcut menu

You can access DHQ, Alarms, Clock, Find My Phone, Brightness, Settings.

Swipe left to access all data

You can access daily activity and SpO2, heart rate monitor, sleep monitor, notifications from here.

FAQ

Search for the app to connect keeps failing

- Keep the boAt Crest app updated to the latest version.
- Close all the programs on the watch > Stop and restart Bluetooth and GPS > Connect again.
- Check and enable notification functions of your phone and keep the phone and watch in close contact.

Note: Make sure your phone system meets Android 6.0 and above and iOS 12.0 and above.

PRODUCT PARAMETERS:

Model	boAt Wave Play
Screen Type	1.69" HD Display
Battery Capacity	220 mAh
Net weight	46g
Bluetooth version	Bluetooth 5.0
Working temperature	0° ~ 40° Celsius
Charging time	About 2.5 hours
Working time	Up to 15 days
Maximum transmission power	7.5dBm
Frequency band	2400 - 2480 MHz

Health Warning

If you are wearing a pacemaker or other implanted electronic device, please consult your doctor before using the heart rate monitor of the watch.

The heart rate sensor will allow green, if you suffer from syncope or are sensitive to strong light sources, please consult your physician before wearing this device.

The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, heart rate and calories, but may not be completely accurate.

The device measures heart rate, blood pressure, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any disease or symptoms. The heart rate and blood pressure data is for reference only. We're not responsible for any decisions in case. Avoid wearing the watch too tightly in daily use. Keep the parts of skin touching the watch dry.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection events. With this little personal effort you contribute to recycle valuable new materials and treatment of toxic substances.

WAVE PLAY

