

SONY

Television



Setup Guide

5-048-871-01(1)

EN Setup Guide

BRAVIA

KD-65X75L / 65X74L
KD-55X75L / 55X74L



1

1.2 N-m / 1.2 N-m
{12 kgf-cm}

2

3

4

*1

5

6

M4L10

7


M4L10

8


*1 Only for limited region/country/model.




9




10



11



12



13

