





# X50

User Manual

## Know your X50



Indicator Light



Type - C  
Charging Port



Multifunctional  
Button



Indicator  
Light

## What's in the box ?

True wireless earbuds case  
2 earbuds  
Extra silicon tips  
USB Charging Cable  
User Manual  
Warranty card

## Product specification

Product Name - TWS Bluetooth Headset

Model - Boulton Audio Z40

Material - ABS+PC

Bluetooth Transmission Range >10m

Bluetooth Version V5.1

New Weight 40.6g

Power Bank Capacity 550mAh

Earbuds Battery Capacity 40mAh

Input 5V/300mA

Transmission Frequency 2402 - 2485MHz

## How to use your X50 ?

### ·Power On/Off

Power on: Press & hold on the left/right earbud for 2 seconds

Power off: Press & hold on the left/right earbud for 2 seconds

### ·Connect

The earbuds will automatically start pairing when you open the charging case, and will directly connect with your mobile

phone via Bluetooth with the name "Boulton Audio Z40". In case it does not connect automatically, go to your bluetooth settings, search for the device name "Boulton Audio Z40" and then pair your device.

### ·Play/Pause Music

Tap on the MFB (multifunction button - refer to page 1) of either earbud twice.

Play previous song: Long press the MFB on the left earbud for 2 sec.

Play the next song: Long press the MFB on the right earbud for 2 sec.

### ·Calling

Receive/End calls: Double tap on either of the earbuds.

Reject calls: Long press on either side of the earbuds for 1 sec.

### ·Voice Assistance

Tap on the MFB in either earbud three times.

### ·Low Battery Warning

When the battery of the earbuds runs low, there'll be a beep to remind you. The earbuds will automatically turn off when they run out of power.

# Exquisite Design



## Do's & Dont's

Do not use corrosive detergents to clean the product.

Store the product in a dry environment & charge the earbuds case at least once a month.

Please raise the volume to the appropriate level while using the product. High volume may cause a risk of hearing loss.

Do not dismantle or use the product near fire or in high-temperature environment. If expansion occurs, discontinue using the product.

## High Fidelity Audio



## Touch Control



**Pro+**  
Calling MIC

**IPX5** Water  
Resistant



*Vicky's Choice*