



Wireless Neckband Earphone

YOGA 90i



User manual

Dear Customer,
Thank you for purchasing **ZEB YOGA 90i** wireless neckband earphone. Please read this user manual carefully before operation & use this user manual for further reference.

Note:
Avoid the use of this product in the high-temperature and high-humidity environment.
Avoid self-heated items of product or it will result in the failure of wireless.
Please charge the product with a power adapter output rated DC 5V.

Caution:
Listening at high volumes can cause hearing impairment. Please keep your usage time at high volumes.

Features	Package Contents
Wireless BT earphone with Neckband	Accessories 1 set
Automatic Media Control	Ear Hook 2 Pairs
Magnetic Earpiece	Charging Cable 1 set
Call Function	User Manual 1 set
Voice Assistant support	
Fast Pairing	
Built-in Rechargeable Battery	
Water Resistant	

Specification	
BT Version	5.0
Supported BT Profile	HSP / HFP / A2DP / AVRCP
Driver Size	10mm
Speaker Impedance	16Ω
Playback Time	30H
Charging Time	1h
Talk Time	30H
Standby Time	120H
Net Weight	10g

Tap 50% volume

Product Representation



• Wireless charging mode

• MP3 Power Off/Play/Pause/Call/Answer

• Volume Down/Up/Stop track

Type C charging port

Charging instruction:

Connect Type C cable to the charging port of the earphones & connect the other of the cable to a 5V DC adapter.

LED Indication:

Charging indication: Red LED glow,
Full Charge Indication: RED LED turns BLUE,
BT Disconnected: Blink Red & Blue LED twice smoothly every 5s.
When connected to a phone: Blue LED will blink once in an interval of 1 sec.

Usage instruction:

Bluetooth Pairing instruction:

Step 1: Press and hold the Mic to Power On the earphones and to take them into pairing mode with the Red and Blue LED flashing alternately.

Step 2: Select on Bluetooth of your phone & search for the BT name "ZEB YOGA 90i BT".

Step 3: Once the BT name is shown on the phone, tap to connect it.

Button Usage:

MP3: Press once to Play/Pause audio during media playback.
Press once to answer an incoming call. Press it again to hang up.
Long press to reject during an incoming call.
+ Long press to go forward track, single press to increase volume.
- Long press to go to prev. track, single press to decrease volume.

Activating Smart phone's Voice Assistant:

When the earphones are connected to a smart phone, press and hold the multifunction button for 2 sec to wake up the phone's voice assistant.

NOTE: Smart phones must have an active internet connection to use the voice assistant function.

ISO 9001:2015 Certified Company
www.zebtronics.com

