



**boAt**  
**ROCKERZ ENTICER**

Thank you for choosing boAt Rockerz ENTICER. This manual is meant to guide you through to the shores of audio bliss without difficulty. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for steering this boAt. Therefore, we strongly advise that this manual is thoroughly read before use, and referred to in times of difficulty.

**PACKAGE CONTENTS**

- 1 x boAt Rockerz Enticer
- 2 x Additional Earbuds
- 1 x Type-C Charging Cable
- 1 x Warranty Card
- 1 x Catalogue
- 1 x User Manual

**OVERVIEW**

**POWER ON:**  
When switched off, long press the HFB (Multifunction Button) for 3 seconds. The blue and red LEDs start flashing alternatively after the initial low LED flash for a second.

**POWER OFF:**  
Long press the HFB for 5 seconds. Red LED blinks once to indicate the device getting switched off.

**FUNCTIONALITIES**

- Turn on the Bluetooth functionality on your phone and switch on Rockerz Enticer.
- The neckband's indicator starts blinking in blue and red alternatively to indicate that the earphones have gone into pairing mode.
- Then, select 'Rockerz Enticer' from the list of available devices; after search.
- If asked for a passkey, confirm the passkey '0000' on phone.
- Once confirmed, the neckband and phone get connected via Bluetooth indicated by a voice prompt.

Note:

- If there's a connection history between the phone and the neckband, then they automatically get reconnected in a working range whenever the neckband gets switched on when the phone's Bluetooth mode is turned on.
- If there's no pairing established in 5 minutes than the neckband gets automatically switched off.

**BASIC FUNCTIONS**

Play	Short press the HFB once to play
Pause	Short press the HFB once to pause
Volume Up	Short press the Vol + button in step 10 Increase volume
Volume Down	Short press the Vol - button in step 10 decrease volume
Next Track	Press and hold the Vol + button for 2 seconds to go to next track
Previous Track	Press and hold the Vol - button for 2 seconds to return to previous track
Answer Incoming Calls	Short press the HFB once
Hang Up/Ending Calls	Short press the HFB once
Select Calls	Double press the HFB
Wake up Smart Voice Assistant	Double press the HFB to wake up default voice assistant
Dual Device Quick-Switch	Double press the Quick-Switch button to switch between the two devices.
BEAST™ Mode	Short press the Quick-Switch button to turn on/off the BEAST™ Mode for Low Latency

Note:  
If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your mobile device settings.

**CONNECTING ROCKERZ ENTICER SIMULTANEOUSLY WITH 2 DEVICES**

- Firstly, connect the earphone to one of the devices.
- Then, switch both the earphone and the device's Bluetooth off.
- Thenafter, connect the earphone to the second device.
- Again, switch the first device's Bluetooth on. The earphone gets connected to both devices.

**QUICK-SWITCH BUTTON**

It helps in switching between two connected media devices. Double-pressing the Quick-Switch button switches active connection between different paired devices, such as between your phone and your tablet.

Short press the Quick-Switch button to activate/deactivate BEAST™ Mode for low latency.

**BEAST™ MODE**

Short press the Quick-Switch Button to switch to Low Latency mode, also known as the BEAST™ Mode. Once switched on, it gets notified via a sound prompt. Short press the Quick-Switch Button once again to turn it off and return to Music Mode.

Note: For the Game – By Gamers, BEAST™ Mode reduces the latency significantly and improves the overall gaming experience.

**CHARGING**

- Connect one end of the provided cable to the USB Type-C port on the headset and the other end to a wall adaptor or laptop.
- While charging, the indicator LED turns into steady red.
- Once the headphones get fully charged, the indicator turns off.

Note:

- Use only authorized/official chargers for the headset, as unauthorized ones may damage the same and invalidate the warranty on the headset as well.
- The earphones cannot be utilized for the purpose of listening while in a charging mode.

**ENx™ TECH**

Our ENx™ tech algorithm cancels out the background noise so that you can be heard crystal clear via voice calls. One need not activate ENx™ as the mic is equipped with the same and activated by default.

Deliver your voice without interruptions anywhere – traffic, railway stations, airports, work space, amidst apartment!

**OTHER FUNCTIONS**

- If you receive an incoming call during playing music, the music automatically disconnects. When the call is done and disconnected, the music starts to play automatically from where it left.

**ANOMALIES & SOLUTIONS**

**A. Mobile can't search the headset**

- Check if the Bluetooth headset is covered on or off (When powered on, the LEDS blink with red and blue colour alternatively).
- If it is powered on and the device still can't connect, then please reboot the headset device and the phone.

**B. After connecting the headset with the phone, disconnection or noise occurs**

- This may be due to the low power of the headset. Please charge the Bluetooth headset.
- There might be obstruction between the headset and the phone or the distance between them exceeds the maximum range for signal reception.

**C. If the Voice Assistant support doesn't respond**

- If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device's settings.

**SPECIFICATIONS**

Headphone Type	Bluetooth Neckband
Driver Size	10mm x 2
HD Sound	Yes
BEAST™ Mode	Yes
Latency	60ms
Frequency Range	20Hz-20KHz
Bluetooth Version	VS 2
Bluetooth Range	10m
Battery Capacity	220mAh
Playing Time	Up to 30 Hours (At 60% vol approx.)
Charging Time	1 hour

Charge Interface	USB Type C
Charging Voltage	5V 2A
Water Resistance	IPX4

**SAFETY PRECAUTIONS**

- This is not a toy. The children are advised to use this under adult supervision.
- Avoid exposing the device to extremely hot or cold temperatures.
- Avoid using the neckband for listening to full volumes in order to protect from hearing damage.
- Please do not use the device under thunder storms.
- Don't dismantle the product in any way.
- Please don't clean the product using oily, volatile liquid.

