



# iGear iG-1114 Keybee Wireless Keyboard and Mouse Instruction Manual

[Home](#) » [iGear](#) » iGear iG-1114 Keybee Wireless Keyboard and Mouse Instruction Manual 

## iGear iG-1114 Keybee Wireless Keyboard and Mouse Instruction Manual



### Contents

- [1 Introduction](#)
- [2 Package Contents](#)
- [3 Product Installing Instructions](#)
- [4 Multimedia Function Key](#)
- [5 Indicator Light](#)
- [6 Scroll Wheel/Middle Button](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

## Introduction

Thank you for selecting Keybee. In order to let you further understand the use of this wireless keyboard and mouse set, please read this manual carefully before using it.

## Package Contents

- Wireless Keyboard 1 Pcs
- Wireless Mouse 1 Pcs
- Nano Receiver 1 Pcs














- Instruction Manual 1 Pcs
- Alkaline battery 3 Pcs

## Product Installing Instructions

- Take out the USB receiver from the rear side of the mouse and plug it to the computer's USB port.
- Remove the battery compartment cover on the rear side of the mouse. Insert 1\* AA battery with correct polarity into the battery compartment of the mouse (observe plus/+ and minus/-). When connected, the LED on bottom will light up.
- Remove the battery compartment cover from the bottom of the keyboard. Insert 2\*AAA battery with correct polarity into the battery compartment of the keyboard (observe plus/+ and minus/-). When connected, the keyboard will start working.
- While travelling or when not in use, please take out the Nano-receiver from the USB port and insert it into receiver curve of mouse.

## Multimedia Function Key




- |   |  |   |
|---|--|---|
|  Media Player      |  Volume Up      |  Search      |
|  My Compute        |  Play/Pause     |  Volume down |
|  My Favourites     |  Previous Track |  Mute        |
|  Email             |  Next Track     |  Homepage    |
|  Lock the Keyboard |  |   |

## Indicator Light

1. NUM lock
2. Caps Lock indicator LED
3. Low battery indicator/2.4 G connection indicator LED

## Scroll Wheel/Middle Button



1. Scroll Wheel/Middle Button
2. Left Button
3. Right Button
4. DPI Button
5. The battery cover has a built-in receiver slot and battery bin

Name of Commodity: KEYBEE

Month and Year of Import: January 2021

Net Weight: 660 gms

Net Quantity: 1 unit

Dimensions: 393mm x 135mm x 41mm

Voltage: Keyboard 3V, Mouse 1.5V

Wattage (Output): 1.87W

Warranty Period: 1 Year

Made In PRC

Imported and Marketed By:

!Gear Tech Pvt. Ltd.

204, Sai Corporate Park,

Laxmi Nagar, Off Link Road,

Goregaon West, Mumbai – 400104.

In case of consumer complaints:

Toll free number -1800 22 8495

Email: [sales@igear.asia](mailto:sales@igear.asia)

(Between 10am to 5pm, Mon- Fri)





R – 41149969

[www.bis.gov.in](http://www.bis.gov.in)



## Documents / Resources

	<p><a href="#">iGear iG-1114 Keybee Wireless Keyboard and Mouse</a> [pdf] Instruction Manual iG-1114, Keybee Wireless Keyboard and Mouse</p>
	<p><a href="#">iGear iG-1114 Keybee Wireless Keyboard and Mouse</a> [pdf] Instruction Manual iG-1114, Keybee Wireless Keyboard and Mouse, Keybee Keyboard and Mouse, Wireless Keyboard and Mouse, Keyboard and Mouse, iG-1114, Mouse</p>