



ZEBRONICS
ALWAYS AHEAD

2.1 Speaker
ZEB **BT2150RUF**



User Manual

www.zebronics.com

Thank you for purchasing Zebronics Speaker. Please read this user manual carefully before Operation & save it for future reference.

Note:

- Avoid the use of this speaker at the high-temperature and high humidity environment.
- Avoid self-disassemble of speaker, or it will result in the failure of warranty.

Features

2.1 Channel speaker
Wireless BT/USB/AUX/FM
LED Display
LED Lights
Volume & Bass adjustment
Remote control
Wall mountable

Specification

Output power (RMS)

Subwoofer	: 20 Watts
Satellites	: 10 x 2 Watts
Total	: 40 Watts

Driver size

Subwoofer	: 10.16cm
Satellites	: 7.62cm x 2

Impedance

Subwoofer : 4Ω

Satellite : 4Ω

Frequency response : 40Hz - 20kHz

S/N Ratio : ≥80dB

Separation : ≥45dB

File format support

(USB) : MP3

Line input : 2ch RCA

Max supported USB

memory size : 32GB

FM frequency range : 87.5 MHz - 108 MHz

BT name : ZEBRONICS

BT Range : 10 Meters

BT version : 5.1

Product dimension (W x D x H)

Subwoofer : 150 x 287 x 205 mm

Satellite : 93 x 98 x 138 mm

Net. weight

Subwoofer : 2.54kg

Satellites : 312g x 2


Total : 3.16kg

Control description:



1. BASS Control
2. Volume Control
3. USB Port
4. Mode
5. Scan / Play / Pause
6. Prev.
7. Next

Remote control



1. MODE: to Change between different input sources
2. POWER: Switch ON/OFF the speaker
3. NEXT: to select the next song in USB/BT
4. PREV.: to select the previous song in USB/BT
5. VOL+: Increase the speaker volume
6. VOL-: decrease the speaker volume
7. MUTE: Mute the audio playback
8. Play / Pause: play / pause the audio playback and also to change the next channel in FM mode

9. EQ: To change different Equalizer modes during USB playback.
10. SCAN: For Auto-Scanning the channels in FM mode
11. REP: To enable the REPEAT ONE/ALL function
12. 0-9 : To directly select the song number / FM channel using numbers from 0-9

General instruction:

Bluetooth connectivity

Switch the Speaker to BT mode, Scan for nearby BT devices in your mobile. Tap on "ZEBRONICS" to connect.

USB mode

Insert the USB pen drive to the speaker. The speaker will detect the USB&audio from it will be played automatically.

FM Radio

Switch the speaker to FM mode. In FM Mode, Long press the Play/Pause key to scan the available FM channels. Once the scanning is done, the speaker will start playing the first scanned channel. The next and Prev. buttons can be used to change the FM channels.

AUX-IN

The speaker can be connected to an audio device using audio cable. Connect the one end of the cable to the speaker & connect the other end of the cable to an audio source. The songs from the audio source can be heard through the speaker.

