

 **BLAUPUNKT**

ATOMIK PARTY BOOMBOX

USER MANUAL




PS SERIES

Enjoy it.

Dear Customer

Thank you for choosing our product, please read all the instructions carefully and retain the manual for future use.

Control panel function



1. 【 🌟 】 : Short press, light effect 1/ 2/ 3/ 4/ 5/turn off horn light/turn off knob light; each short press changes one kind of light effect, Among them, lamp effect 3 is the changing lamp according to the rhythm of playing music, Aux mode plays music in light effect 3, the light does not change with the music.
2. 【 EQ 】 : Short press two kinds of sound effects, EQ0 (default indoor sound effect at power-on); EQ1 (outdoor sound effect).
3. 【 🎵 】 : Short press to switch the accompaniment/origin vocals.
4. 【 🔄 】 : In music mode, Short press is a single loop 【ONE】 All loops 【ALL】
5. 【V-/ V+ Volume knob】 : Rotate to the left to decrease volume, and to the right to increase volume.
6. 【 M 】:Short press mode conversion: BT mode, TF card, USB mode, FM mode conversion, long press in FM mode to automatically search for channels.
7. 【 ⏮ 】 : Short press previous song/select previous radio station, long press to rewind
8. 【 ⏭ 】 : Short press next song/select next radio station, long press to fast forward
9. 【 ▶⏪ 】 : Short press play/pause, long press in FM mode to automatically search for channels.
10. 【 AUX 】 : Insert AUX line for external power supply.
11. 【 TF 】 : Insert TF card to play MP3 music.
12. 【 Charging Indicator 】 : Red light will be on when charging, red light, will be off when it is fully charged.
13. 【 ON/OFF】 : Power on/off.
14. 【 MIC 】 : Insert microphone.
15. 【 USB 】 : Insert U disk to play MP3 music.
16. 【 DC 5V 】 The charging jack can use the dedicated USB Charging cable delivered by this machine to connect to the charger for charging.

Specifications

Speaker Size	3"x2
Built-In Rechargeable Battery	3000mAh battery
Bluetooth Version	5.0
FM Frequency Range	87.5-108MHz
Input Power	DC 5V, 1A
S/N	≥80dB
LED LIGHT	Colorful Flame Lamp
Screen	Digital Screen Display
External Music File Format	MP3
Inputs	3.5mm Aux input, 6.5mm microphone output
Functions	Bluetooth, FM radio, USB, micro SDcard, Aux-In,TWS, Microphone

Charging instructions

Connect the charging cable to the DC5V=1A adapter, plug it into the charging port after the machine is turned off; red light will be on when charging, red light will be off when it is fully charged.

Care and Maintenance

Read the following recommendations before using the wireless speaker, following these you will be able to enjoy the product for many years

- Do not expose the unit of liquid, moisture, or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the unit.
- Do not expose the unit to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts
- Don't dispose of the unit in fire as it will result in an explosion
- Don't expose the unit to contact with sharp objects as this will cause scratches and damage
- Don't let the unit fall down onto the floor, the internal circuit might get damaged
- Don't attempt to disassemble the unit as it may get damaged if you are not professional

Safety Warranty Information 1 Year

Warranty Information 1 Year*

If you have issue with our product please contact our service center Service Centre.

Authorized Service Center Blaupunkt Speakers

Address: Envent World Wide Pvt Ltd.

Khasra. No- 15/15(4-16), Village Samalkha, Tehsil Vasant

Vihar, New Delhi- 110037

E-Mail: wecare@blaupunktaudio.in

Tel. 18008434333

Please prepare & submit the following information during the telephone or e-mail notification to facilitate the process:

- Serial Number
- Date of purchase
- A copy of proof of purchase in case of warranty

Note- Important Information

Please use the original packaging or other suitable packaging to protect the unit in transit.