

pTron

## Soundster Lite

Hi-Fi Stereo Wireless Headphones




Instruction Manual

### Key Features

1. High Bass
2. Passive Noise Cancellation
3. Built-in Microphone
4. Call & Music Controls
5. 3.5mm Audio Cable Compatible

### Features/Parts



### Package Content

1. Headphones
2. Manual
3. USB Charging Cable
4. 3.5mm Audio Cable

### Button Operations:

1. Power ON: Press & Hold the Power/Call button for 3 seconds and when it gets ON, you will hear a voice prompt as "pTron Bluetooth Headset is Power ON".
2. Power OFF: Press & hold the Power/Call button for 3 seconds and before going to OFF, you will hear a voice prompt as "Power OFF".
3. Re-dial: Click the Power/Call button twice for redialing the last dialed number.
4. Answering a Call: When a call comes in, you will hear a ring tone. Press the Power/Call button for once to answer the call. Press Volume +/Volume - buttons to adjust volume on call.
5. Hangup Call: During talking, press the Power/Call button for once to end or disconnect the call.
6. Reject a Call: Long Press and hold the Power/Call button for 2 seconds to reject an incoming call.
7. Play/Pause: Press the Play/pause button once to Play/Pause music.
8. Next Song: Long press & hold the "V+" button to go to next track.
9. Previous Song: Long Press & hold the "V-" button to go to previous track.
10. Volume Up: Clicks the "V+" button to increase the volume.
11. Volume Down: Clicks the "V-" button to decrease the volume.

### Bluetooth Connection:

1. Ensure the headphones are turned OFF. If they are not, please turn OFF the headphones first before pairing.
2. Turn the headphones ON, the LED indicator will keep flashing blue and red light alternatively. This will indicated your headphones are now in pairing mode and you will hear the voice prompt as "pairing".
3. Place the headphones and the Bluetooth device to which you would like to pair it within the operating distance. We recommend keeping the two devices no further than 10 feet apart.
4. Ensure Bluetooth is enabled on your phone or music device. Refer to the Manufacturer's instructions for how to enable Bluetooth on your device.
5. Once you have activated Bluetooth on your device, select the headphones "pTron BT" from the list of available Bluetooth devices then you will hear the voice prompt as "connected" after successful connection.
6. If pairing is unsuccessful, turn off the headphones first and repeat the above mentioned steps. Once you have paired the headphones with a device, the headphones will remember this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.

**Note:** Some phones or devices request a passkey or pin, enter 1234 or 0000 as you pin or passkey.

### Charging:

1. Turn OFF the headphones before charge.
2. The headphones come with a built-in rechargeable battery. Before using it for the first time, we recommend you to charge the battery fully. Only use the supplied USB cable to charge the headphones.
3. Connect the USB cable to USB port and the USB plug to the charging input on the headset. The red LED light will illuminate while the headphones are charging.
4. When the battery is fully charged, the LED light will turn off automatically. Disconnect the headset at this point. The headphones will then be ready for use.
5. When the battery is low, it will have a warning "low battery please charge". When this happens, charge your headset.

### Listen to Music:

Once the headphones are paired to your device, you can stream music wirelessly to the headphones. Select the track you wish to listen to on your device to listen via headphones. If you encounter any problems while streaming, please refer to your device's user manual.

### Use Headphones Without Bluetooth:

Your headphones have a built-in audio input which will allow you to listen to music from devices using a 3.5mm audio cable.

1. Turn off the headphones.
2. Insert one end of the audio cable into the headphones audio input.
3. Insert the other end into your devices headphone jack.
4. Power on your device and begin playing music.

**Note:** Microphone and function key may not be supported in this mode.

### Disclaimer

The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners. Any changes or modifications or unauthorized repair to this product not explicitly approved by manufacturer could void your warranty claim.