



# Just Play!

## Manual Setup Guide




### BASIC FUNCTIONS

- Voice Assistant: Long touch the CTC on either earbud for 3 seconds to activate the voice assistant.
- Answer: Single tap the CTC on either earbud to answer an incoming call.
- Hang Up/Reject Call: Double tap the CTC on either earbud to end a rejected call.
- Play/Pause Music: Single tap on either earbud's CTC to play or pause music.
- Next Track: When playing music, double tap the right CTC to skip to the next song.
- Previous Track: When playing music, double tap the left CTC to return to the previous song.



### VOICE ASSISTANT

- Step 1: Long touch the CTC on either earbud for 3 seconds to activate the smart voice assistant.  
 Step 2: The respective voice assistant screen pops up and you may place your commands at ease.
- Tips:** You may try out the following commands.
- What is the weather?
  - Play a song
  - Set a reminder



### SMART POWER OFF

- Step 1: After usage, remove both the earbuds from your ears.  
 Step 2: Place the earbuds back into the charging case in correct orientation and close the lid.
- The earbuds automatically switch off (and enter into charging mode).



# AirDopes 148

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 148. Please consider this manual as your guiding map towards the unparallelled shores of musical bliss.

Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

### PACKAGE CONTENTS

- 1 Pair of TWS Earbuds
- 1x Charging Case
- 1x Type-C Charging Cable
- 1x User Manual
- 1x Warranty Card

### POWER ON (First Time Use)

Step 1: To switch the earbuds on (Smart Power On) simply open the lid of the charging case (without earbuds in model). Coupling via FWP™ technology, the earbuds power on automatically, get connected and enter into the connection mode.

#### ON

Long touch the CTC on both earbuds for 8 seconds to manually power on the earbuds.

Step 2: After powering on, the earbuds enter into the Connection Mode, indicated by red and white LED flashes.

### CONNECTION MODE

Step 3: Turn on the Bluetooth functionality on your phonemedia device and scan.

Step 4: Search for "Airdopes 148" and pair accordingly.

**Congratulations!** Your earbuds are now connected successfully via Bluetooth.

#### NOTE

- Pausing mode lasts for 3 minutes. If the pausing time is missed, then you will need to reconnect the earbuds and follow the above mentioned procedure.
- Airdopes 148 connects previously connected devices and switches on the earbuds automatically without connecting to the previously connected device.



### SINGLE EARBUD USAGE

Step 1: Please note that both the earbuds can be used in mono mode. Use Setup / Manual Power On for switching on the desired mode.

Step 2: The selected earbud will automatically enter the connection mode indicated by red and white LED flashes.

Step 3: Turn on Bluetooth on your phonemedia device and search for "Airdopes 148" to connect.

#### NOTE

- To switch to Mono mode, simply open the lid of the case. It will automatically power on and connect the earbuds via mono mode.
- You can still make return to the previous mode by long touch.

### QUICK GUIDE ON FUNCTIONALITY

- |             |  |
|-------------|--|
| - 3 Seconds | ○ Long touch either CTC for 3 seconds to activate voice assistant. |
| - 6 Seconds | ○ Long touch both CTC for 6 seconds to manually power on.          |
| - 8 Seconds | ○ Long touch both CTC for 8 seconds to manually power off.         |



### CHARGING THE EARBUDS

Step 1: Please insert the earbuds back inside the charging case in correct orientation.

Step 2: A solid red LED on earbuds indicates that the earbuds are being charged. Once fully charged the LED turns off.

Step 3: Once the earbuds are fully charged, the charging case automatically switches off to save power.

#### NOTE

- Before using the earbuds for the first time, it is recommended to fully charge the earbuds. Also, please keep the lid of the charging case closed while charging.
- If battery is 20% or below then the earbuds takes over 8 seconds to indicate the same.

### CHARGING THE CASE

Step 1: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/power bank, etc.

White LED blinks while the case is on charging. When the charge gets 50%, it gets indicated by solid white LED.



### Charging norms & Precautionary Guidelines

① Charger/Wall Adapter	SWQA
② Cable/Wire	Standard Cable (5ft Standard and 10ft Home charging)

Any other accessory can be paired as well. The product can be charged as long as the specifications are as per above norms.

### AUTO RESET

Airdopes 148 comes equipped with our cutting-edge FWP™ technology along with the Auto Reset feature, which means that you would not require to do the factory reset manually. Now, every time when the earbuds are kept inside the case and the lid gets opened, the earbuds reset automatically.

#### NOTE

The Auto Reset mechanism helps to switch the earbuds and earbuds back to operation mode.

### SPECIFICATIONS

Bluetooth Version	v5.0
Music Playback	Up to 8HRS per charge (Up to 40HRS additional with Case at 60% volume)
Standby Time	10H
Talktime	5HRS
Transmitter Range	10m
Driver Size	8mm²
Bluetooth Profiles	HFP HSP A2DP AVRCP
Frequency	20Hz - 20KHz
Battery	400mAh (Case) 300mAh (2 Earbuds)
Charging Time	1H (Earbuds), 2H (Case)
Charging Interface	Type-C
Water Resistance	IPX4

### WARNING

- Please follow the instructions to operate.
- Please don't use the ear-buds in extreme temperatures.
- Please don't use the product near water.
- Please keep the product away from heat sources, as the heat may damage it.
- Don't press the parts such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to prevent hearing and extend the ear-buds' service life.

