




Bassbuds Air True Wireless Stereo Earbuds - User Guide



Caution: pTron 'Bassbuds Air' earbuds are set at 50% volume level and does not support volume control function. Please control the volume level through the connected device.



Smart Power On & Pairing

1. Open the charging case Or Touch TSA on both the earbuds for 3 seconds.
2. Wait for 2-3 seconds until L & R earbuds pair to each other.
3. Turn on the Bluetooth on your phone & search "pTron TWS" to connect with the device.

Note: TSA stands for Touch Sensitive Area.

Power Off: Touch TSA on both the earbuds for 3 seconds Or Keep both the earbuds into the charging case and close it properly.

Connectivity Bluetooth - Automatic

Just turn on the Bluetooth earbuds. They will automatically connect to the last connected device (Instant wake & pair technology).

Calling or Music through Mono & Dual Buds

Mono Bud Use - Just place the right or left earbud back into the charging case.

Dual Buds Use - Use left & right earbuds together.

Voice Assistant Activation: Touch TSA on either earbud for 2-3 seconds.

Call & Music Functions

Answer/Hangup a Phone Call - Touch TSA on either earbud once.

Reject a Phone Call - Touch TSA on either earbud for 2 seconds.

Music Play/Pause - Touch TSA on either earbud once.

Next Song - Touch TSA on right earbud twice.

Previous Song - Touch TSA on left earbud twice.

Redial - Touch TSA on right earbud thrice.

Note: TSA stands for Touch Sensitive Area

Important: Some product units will have different function for the following

Next Song - Touch TSA on left earbud twice.

Previous Song - Touch TSA on right earbud twice.

Redial - Touch TSA on left earbud thrice.

Charging the Earbuds

1. Place both the earbuds into the charging case properly. The earbuds will power off automatically when placed into the case.
2. Earbuds LED will start glowing red, which means it is on charging. After full charge earbuds LED light will stop blinking.
3. Charging case LED light will be blue during charging the earbuds. It will turn off when earbuds are fully charged.

Charging the Case

1. Connect the C-Type cable to the case and the USB end to a 5V power source.
2. The Red light indicator in the front of the charging case will start blinking.
3. When the case is fully charged, Red light will be steady. Remove the charging case from the power supply.

Caution: Using incompatible USB cable or high voltage chargers can damage the product & void the product warranty. We strongly recommend using DC5V-1A chargers & the USB cable included in the package.

Troubleshooting Scenario 1 - One Earbud is Not Working

1. Place both the earbuds in the charging case.
2. Take out both the earbuds together from the charging case.
3. Wait until L & R earbud pair to each other. After successful matching, only 1 earbud will flash Blue & Red light.
4. Turn ON the Bluetooth on your phone, search for "pTron TWS" & connect.

Troubleshooting Scenario 2 - Earbuds Not Connecting/Scanning

1. Place both the earbuds in the charging case.
2. Take out both the earbuds together from the charging case.
3. Restart your Bluetooth device or phone.
4. Now, search for "pTron TWS" on your Bluetooth device & connect.

Troubleshooting Scenario 3 - Earbuds Disconnecting During a Phone Call

1. Charge earbuds 100% before use.
2. Restart the earbuds and reconnect with your device.

Safety Precautions

1. Please keep this device away from extreme heat, liquids, humidity or corrosive environment.
2. Please don't over-charge the product as it will decrease the service life of battery.
3. Using incompatible USB cable or high voltage chargers can damage the product & void the product warranty. We strongly recommend using a good quality DC5V-1A chargers & the USB cable included in the package.
4. This product or the Bluetooth function should not be used during charging.
5. Don't jam the ports such as charger port, LED port, etc.
6. It is recommended to utilize the product below the maximum volume in order to protect your hearing.
7. Please don't open/temper the product or product's battery.
8. Please keep the product out of children's reach.
9. Dispose the product responsibly and adhere to your local authority guidelines.

Customer Care Details: support@ptron.in and 040-040 - 67138888

Product Registration/Warranty Registration: <https://ptron.in/apps/product-registration>

Service Centers List: <https://ptron.in/pages/ptron-service-centers>

Disclaimer

The colors and specification shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purposes only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.