

saregama SC03-V2 Carvaan 2.0 Portable Music Player User Manual

<u>Home</u> » <u>Saregama</u> » saregama SC03-V2 Carvaan 2.0 Portable Music Player User Manual

saregama SC03-V2 Carvaan 2.0 Portable Music Player




Contents [hide

- 1 BUTTONS & PORTS ON SAREGAMA CARVAAN
- **2 SAFETY HANDLING**
- 2.1 CARE FOR PRODUCT
- 2.2 CARE FOR BATTERY
- **2.3 OTHERS**
- **3 WARRANTY OVERVIEW**
- **4 WARRANTY TYPE**
- **5 WARRANTY CARD**
- 6 Documents / Resources
- **7 Related Posts**

BUTTONS & PORTS ON SAREGAMA CARVAAN

Full battery charge time: 2-3 hours;

Battery usage: Approximately 5 hours once the battery is fully charged



To choose a mode, press the corresponding mode button on the unit/remote


To choose a mode, press the corresponding mode button on the unit/remote

- 1. **SAREGAMA:** 5000 pre-loaded evergreen songs categorized into Artistes, Moods & Geetmala; this is the default mode on first power on/reset
- 2. USB*: Plug in a USB into the USB port on Carvaan to enjoy your pe,rsonal collection of songs
- 3. FM: Listen to local FM stations.

FM frequency: 87 .5 to 108 MHZ

Note: We recommend that you do not put the unit on charge while listening to FM as it will interrupt the signal

4. **BLUETOOTH**:** Pair your mobile phone / tablet with Carvaan. Enjoy songs stored on your personal device on Carvaan speakers



*support for USB 2.0


Choose a category in Saregama Mode

- 1. **Artistes:** 20+ music stations dedicated to legends like Lata Mangeshkar, Kishore Kumar, Asha Bhosle, Mohd. Rafi, R.D. Burman, Guizar, etc.
- 2. Moods: 5+ music statiorns dedicated to moods like Romance, Ghazal, Instrumental, Sad etc.

^{**}support for BT version 4. 7


3. Geetmala: 50 years of Ameen Sayani's Geetmala spanning across 50 music stations






Voltage: 220V


Frequency: 50 Hz for input and 5V 1A for output





To replace the remote control battery:

- 1. Open the battery compartment
- 2. Insert a fresh CR2025 battery with the correct polarity (-/ +)
- 3. Close the battery compartment
- 4. Discard the used battery



SAFETY HANDLING

CARE FOR PRODUCT

- **a.** Keep Carvaan away from dust and excessive heat (heat registers, stoves etc.)
- B Prevent spillage of water or any other liquid as this can cause failure of Carvaan or could prove to be a potential fire hazard
- c. Clean the unit with a dry cloth only
- d. Do not walk on or pinch the power cord close to the plug
- e. Do not immerse Carvaan or the remote into water
- f. Remove the remote battery when it is not used for longer duratio
- g. Do not mix different brands or types of batteries in the remote

CARE FOR BATTERY

- a. Do not expose the battery to heat sources greater than 60°C
- b. Recycle or dispose the battery when essential. Please ensure proper battery handling and disposal methods

- c. Do not subject the battery pack to a mechanical shock
- **d.** In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with water and seek medical advice
- e. For prolonging battery life, avoid discharging the battery completely
- **f.** To ensure optimum battery condition, the unit should be charged for atleast 8 hours, once a month. Note: if the unit is unused for a month or more, battery will get completely discharged

OTHERS

- a. Use attachments/accessories as specified by the manufacture
- **b.** Please contact an authorized service center for any repair/ servicing requirements or call the toll free no. 1800-102-7799

WARRANTY OVERVIEW

Carvaan comes with a 1 year Warranty on all parts, excluding accessories. This includes servicing/ repair or replacement of damaged parts.

The warranty does not apply and does not cover the following:

- Liability for loss of data/content loaded in the product due to misuse or tampering.
- Damage caused due to force majeure events; events caused by fire, water, electrical disturbances etc.; events beyond the control of Saregama; acts of negligence or mishandling; usage for commercial, business, industrial, educational or rental purposes

WARRANTY TYPE

Home service and carry 1n warranty are provided.

Home service warranty requires customers to have a technician visit their home and service the product. This type of warranty can be availed by customers living in locations where there is an authorized service center. The list of authorized service centers is available on www.saregama.com/carvaan/hindi/customer-service

Carry-in Warranty service requires that the Product be brought by the Customer, at his/her sole cost and responsibility, to the Authorized Dealers along with the original invoice.

Once the Product is serviced/ repaired/ replaced, the Customer shall be responsible to pick-up the Product from the concerned Authorized Dealer.

Waste electrical products should not be disposed of with household waste. Please follow disposal and recycling instructions issued by the concerned local authority.

IMPORTANT LINKS

Station List & Song List: www.saregama.com/carvaan/songlist
Detailed Warranty: www.saregama.com/carvaan/2017/warranty

WARRANTY CARD

Customer's Address:	
Product Serial No.:	
Date of Purchase:	
Expiry Date:	
accept the terms and conditions of	the warranty.
Retai l er's Name:	
Retailer's Signature/Seal:	
	Customer's Signature

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.



Documents / Resources



saregama SC03-V2 Carvaan 2.0 Portable Music Player [pdf] User Manual SC03-V2, SC03V2, 2AMX5-SC03-V2, 2AMX5SC03V2, SC03-V2 Carvaan 2.0 Portable Music Player, Carvaan 2.0 Portable Music Player

Manuals+, home privacy