



## realme RMX3261 Smartphone User Guide

[Home](#) » [realme](#) » realme RMX3261 Smartphone User Guide 

### Contents

- [1 realme RMX3261 Smartphone](#)
- [2 Greetings from realme mobile](#)
- [3 How to use the phone](#)
- [4 How to reboot the phone](#)
- [5 Standard accessories](#)
- [6 Performance parameters](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)


# realme

## realme RMX3261 Smartphone



### Greetings from realme mobile

This guide will show you how to use the phone and its important functions. You may also visit realme official website to get more information about the phone.



### Warning

- Do not place the phone or battery near or inside the heating equipment, cooking equipment, high-pressure vessels (such as microwave ovens, induction cooker, electric oven, heater, pressure cooker, water heater, gas stove, etc.) to prevent the battery from overheating which may lead to an explosion.
- The original charger, data cable, and battery shall be used. Unapproved chargers, data cables, or batteries that are not certified by the manufacturer may result in electric shock, re, explosion, or other hazards.
- When charging, please place the device in an environment that has a normal room temperature and good ventilation. It is recommended to charge the device in an environment with temperatures ranging from 5°C~35°C.

- The back cover can't be removed.

## **How to use the phone**

Press and hold the Power Button until the realme animation is displayed to start the phone. You can use the phone by following the instructions that appeared on the screen.

For more information, please visit realme official website:

<https://www.realme.com/eu/>

## **How to reboot the phone**

Press and hold the Power Button and Volume Up Button at the same time until the realme boot animation is displayed to reboot the phone.

## **Standard accessories**

You are provided with the following standard accessories: 1 Phone, 1 Charger, 1 USB data cable, 1 Safety Guide, 1 Quick Guide, 1 SIM Ejector Tool.

## **Performance parameters**

		RMX3261
		16.5cm(6.5")
		164.5×76.0×9.1(mm)
		4880mAh/18.88Wh(Min) 5000mAh/19.35Wh(Typ)
		13Megapixels+2Megapixels +2Megapixels Rear 5Megapixels Front
		0°C-35°C
<b>SAR Values</b>	FCC SAR	0.870W/kg(Head) 1.152W/kg(Body)

Radio Waves Specifications		
Radio	Frequency	Max. Output Power

GSM	850MHz/900MHz	32.5±0.8dBm
	1800MHz	30±0.8dBm
	1900MHz	29.5±0.8dBm
WCDMA	Bands 1/2/4	23±0.8dBm
	Bands 5/8	23.5±0.8dBm
LTE FDD	Bands 1/2/3/4/6/6	23±0.8dBm
	Bands 5/8/12/17/26/28	23.3±0.8dBm
	Band 7	22.5±0.8dBm
LTE TDD	Bands 38/41	23±0.8dBm
Bluetooth	2.4-2.4835GHz	6.5±3dBm(EIRP)
2.4G Wi-Fi	2.4-2.4835GHz	15±2.5dBm(EIRP)

NFC	13.56MHz	42dBuA/m@10m
-----	----------	--------------

**Documents / Resources**

	<p><a href="#">realme RMX3261 Smartphone</a> [pdf] User Guide RMX3261, 2AUYFRMX3261, RMX3261 Smartphone, Smartphone</p>
---	---

Manuals+