

 ambrane




**STAY CHARGED WITH
GIGANTIC POWER!**

Stylo Max

50000 mAh

**POWER BANK WITH
20W BOOSTED SPEED™**

 **made in india**

USER MANUAL

Welcome

Thank you for purchasing the **Ambrane Stylo Max Powerbank**. We recommend you to read the instruction manual carefully before using the product.

Package Contents

- 1 N Stylo Max Powerbank
- 1 N User Manual Scan Card
- 1 N Charging Cable
- 1 N Welcome Note



Operating Instructions

How to Charge Devices with the Powerbank

- Connect your device to a USB or Type-C port of the Powerbank with a good quality charging cable.
- While connecting, LED indicators will turn ON displaying the remaining battery capacity and the fifth green LED indicator will turn ON while Power Delivery mode is activated.

How to Charge the Power Bank

Use a good quality USB to Type-C charging cable. Plug the Type-C connector of the cable into the Powerbank's input port and the other connector into the matching port of a USB power adapter. The LED indicator will start flashing according to the battery status.

- Use Type-C to Type-C cable for PD charging and USB to Type-C cable for QC charging.
- We recommend using the QC/PD 18W power adapter to get an enhanced charging speed.
- While charging, the fifth green LED indicator will glow and the corresponding battery capacity indicator (White LED) will blink.
- When fully charged, all four white LED indicators will turn ON and the blinking will stop.
- After the power bank is fully charged, disconnect the USB cable from the Powerbank.

Product Specifications

- Battery Capacity : 50,000mAh
- Battery Type: Lithium Polymer
- Input : DC 5V~3A, 9V~2A (18W max)
- Output Wattage: 20W Fast Charging
- Output Ports : 1 Type-C and 2 USB Ports
- Output (QC/PD): DC 5V~3A, 9V~2.22A, 12V~1.67A
- Charging Time: Up to 18-19 Hours through PD Technology
- Multi Layers of Chipset Protection

- Quick Charge 3.0
- Power Delivery Technology (PD)
- Premium Sturdy Body
- BIS Certified

LED Indicators

Charging the Powerbank

Connect with a suitable charging source. The indicators show the charging condition as follows:

Power Level	LED 1	LED 2	LED 3	LED 4	LED 5 (Green, QC/PD Mode)
0-25%	Blinking	OFF	OFF	OFF	OFF
25-50%	ON	Blinking	OFF	OFF	OFF
50-75%	ON	ON	Blinking	OFF	OFF
75-100%	ON	ON	ON	Blinking	OFF
Fully Charged	ON	ON	ON	ON	OFF

Charging Products with the Powerbank

Connect your device with the powerbank to charge. The indicators show the discharging condition as follows:

Power Level	LED 1	LED 2	LED 3	LED 4	LED 5 (Green, QC/PD Mode)
Fully Charged	ON	ON	ON	ON	ON
75-100%	ON	ON	ON	ON	ON
50-75%	ON	ON	ON	OFF	ON
25-50%	ON	ON	OFF	OFF	ON
0-25%	ON	OFF	OFF	OFF	ON
0%	Blinking	OFF	OFF	OFF	OFF

Precautions

- Some USB cables that are not compatible with the Powerbank or can't be used should be avoided, instead, choose or purchase the charging cable of the same mobile brand to get adequate speed.
- When the powerbank can't charge digital products, please check whether the charging cable and connectors are connected properly or change the cable. After digital devices are fully charged, please unplug the charging cable timely to avoid power loss.
- Because of the high charge and discharge current, please choose good quality charging cable and connectors.
- Please make sure the power bank is fully charged when using it for the first time. Make sure that the product is fully charged at least once in two or three months.
- During charging the power bank, please unplug the cable within 30 minutes when the power bank is fully charged.
- While using output through a single port, the Powerbank delivers maximum power but if dual or more ports are used at the same time, then the powerbank will divide power into two or three. For Example: Powerbank maximum current delivers 3A.
- In single port usage, the Powerbank will operate in only one parameter whether QC or PD and will provide the output ratio mentioned.
- If all the ports are used in a single phase, then the Powerbank will work on basic parameters and the current will be divided into all the ports.

Safety Alerts And Guidelines

- Keep your Powerbank dry and away from moisture and corrosive materials.
- Do not clean your Powerbank with harsh chemicals, soaps or detergents. Just wipe it with a soft, water-dampened cloth.

- To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- Do not expose this unit to extremes of temperature.
- Immediately terminate use of the product if the item bulges, smells or leaks.
- Please recharge the Power bank once a month if not in use to extend the lifetime of the battery.
- Please allow the Powerbank to deplete significantly before recharging in order to preserve the lifetime of the battery.
- Check the voltage of the USB devices and power adapters carefully before usage.
- Do not place this unit directly onto furniture surfaces with any type of soft, porous, or sensitive finish. As with any rubber compound made with oils, the rubber finish could cause marks or staining where the product resides.
- Keep your device out of reach of small children to prevent danger.
- Lithium batteries, like all rechargeable batteries, are recyclable and should not be recycled or disposed of in normal household waste. Contact your local government for disposal or recycling practices in your area.
- Keep away from fire, water and excess temperature (> 45°C) and too low temperature (< -20°C)
- Do not dismantle, crush, puncture or short circuit the power bank, or expose it to liquids, fire or an environment where the temperature is above 55°C.

Warranty Card and Terms & Conditions

NOTE: For valid warranty claim, all information on the warranty certificate has to be completed and presented along with the original invoice.

- All warranty information, product features and specifications are subject to change without prior notice.
- All matters are subject to Delhi Jurisdiction.

Customer's Name: _____

Contact Number: _____

Customer's Address: _____

Model No.: _____

Purchase Date: _____

Invoice Number: _____

Dealer's Stamp: _____

- **Ambrane Stylo Max Powerbank** comes with 180 days warranty from the date of purchase.
- Warranty can not be claimed if the product is damaged by wrong operation or force majeure.
- Accessories supplied with **Ambrane Stylo Max Powerbank** are not covered under the warranty.

CUSTOMER CARE:

Ambrane India Pvt. Ltd.

224, Second Floor, D-Mall, Netaji
Subhash Place, Delhi; India - 110034

Contact No.: +91 1145911111,

E-mail: care@ambraneindia.com

Web: www.ambraneindia.com

Join the Ambrane Ally!
[@ambraneindia](#)

