



STORM PRO

Thank you for choosing the boAt Storm Pro as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.

PACKAGE CONTAINS:

- boAt Storm Pro x1
- USB magnetic charging cable x1
- User Manual x1
- Warranty Card x1

CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes 30 minutes to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adaptor.

Note: Once your watch is at 10% battery, it will automatically switch to power saving mode which will disable all functions.

CONNECTING TO THE APP

1. Download the boAt Crest app on your phone.

Available on both App Store (iOS 13.0 and above) and Google Play Store (Android 7.0 and above)

OR

Scan [QR CODE] (Also available on the watch)

2. Connect the device directly with the mobile application. Do not connect with the phone's Bluetooth directly.
3. Select Storm Pro on the home screen of the app and click OK to connect.
4. To use all features of your Storm Pro seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.
5. Turn your phone's Bluetooth and GPS on.
6. Disable battery optimization

Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.

iPhones will not prompt any information unless you complete Bluetooth pairing with STORM PRO.

SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization

- Open the app on your phone.
- Make sure your Storm Pro is connected to the app.
- Synchronization will start automatically once you enter the app interface.

Note: Synchronize data at least once every day to avoid data loss in the watch.

Energy Score

Track your energy level throughout the day with the Energy Meter score on the app. Click on the Energy Meter value on the App Dashboard to see detailed insights as well as historical data of energy spent.

The energy meter takes into account various parameters like your age, BMI, sleep data, activities performed etc. and gives you a real time update of your energy level on a scale of 100.

NAVIGATING THROUGH THE FUNCTIONS

Changing the dial interface

Using the app

Select cloud watch faces on the app and push your preferred watch face to your smartwatch. Go to the boAt crest app -> settings -> storm pro features -> watch face

Note: Make sure your watch and phone are connected via Bluetooth. Do not exit the downloading interface until it displays 100% downloaded. It may take up to 60 secs to sync the watch face with the app.

Using the Storm Pro

Long press the home screen to select the watch face.

SHORT PRESS THE SIDE BUTTON ONCE TO ENTER THE MAIN MENU Activities

Your watch is equipped with 20 default activities from Walking, Treadmill, Running, Badminton, Football, Basketball, Tennis, Yoga, Dancing, Indoor Cycling, Cricket, Boxing, Karate, Table Tennis, Pilates, Skipping, Hiking, Hockey, Kabaddi, Bowling

You also get an array of activity mode options on the app which you can select and push to the watch.

The steps to use them are as follows.

1. Make sure your watch and app are connected. Also ensure any existing activity record on the watch is already synced to the app.
2. Select the activity category of interest
3. The screen will show you the list of activities within the category. Further select the activity within this category which you want to push to the watch.
4. You can also search for an activity from the search box.
5. Next, select the activity you want to replace.
6. Once you confirm, it will be available on your watch for use!

To pause or stop the exercise, press the home button.

Notes: *All records will be available on the app if you keep it synchronized.

Activity Records

Tap on this icon to check sports records.

Blood Oxygen Level Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes.

Sleep Monitor

Tap on the icon to review the sleep data of the previous night.

Once the asleep criteria is met, your Storm Pro will start recording from 8 pm at night to 10 am in the morning the next day.

Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movement.

You can check the data on the app only after the awake criteria is met.

You can also track sleep scores on the boAt Crest app.

Note: *For accurate sleep data recording, the asleep criteria has to be met which includes limited movement, wrist positions and angles, and more. *The awake criteria will be met only after it records some noticeable movement.

Breathing exercises

Click on the breath training icon to regulate your breathing with the instructions given to relax.

Notifications

Turn this feature on from your app to receive notifications on your watch.

You can also send quick replies on an incoming call or SMS notification.

Note: The watch can be used to reject calls only. Quick replies will work only with call and SMS notifications.

Stopwatch

Tap on the icon to start the stopwatch.

Flashlight

Tap on this icon to turn your screen into the flashlight.

Weather

Enable this feature from the app to track the weather forecast for next 6 days.

You can also track humidity, wind speed and air pressure.

Find My Phone

Tap on this icon to find your phone. Once enabled, your phone will start ringing and vibrating. Tap again to stop it.

Note: Your Storm Pro should be connected to your phone via Bluetooth and within its range for this feature to work.

Screen sleep

Tap on this icon to set screen timeout duration.

Do not disturb

This will disable all notifications except for alarms and alerts.

Download app

Tap on this icon to download the app through QR code.

About

Tap on this icon to view information about the watch.

PRODUCT PARAMETERS:

Model	boAt Storm Pro
Screen Type	1.78" AMOLED Display
Battery Capacity	200 mAh
Net weight	45g
Bluetooth version	Bluetooth 5.0
Working temperature	-20 ~ 60 degree
Charging time	about 30 mins
Working time	about 7 days
Maximum transmit power	BdBm
Frequency band	2402 ~ 2480 Mhz

Swipe up to view live cricket scores.

Enable this feature from the app to use.

Go to the home page -> tap on the cricket icon on the top right corner -> Select the match and time intervals to receive notifications on the watch.

FAQ

Search for the app to connect keeps falling

1. Keep the boAt Crest app updated to the latest version
2. Close all the programs on the watch -> Stop and restart Bluetooth and GPS -> Connect again
3. Check and enable notification functions of your phone and keep the phone and watch in close contact.

Note: Make sure your phone system meets Android 7.0 and above and iOS 13.0 and above.

My Storm Pro is receiving no alerts, texts, or phone calls

Make sure smart reminders on the app are on and synced to the Storm Pro. Also make sure your notification center of the phone is displaying messages. Only then will your smartwatch also display those notifications.

My Bluetooth keeps getting disconnected

Make sure there is not more than 7m distance between Bluetooth on the phone and the watch. There is no obstacle in between the watch and the phone.

Which functions of the Storm Pro need Bluetooth to work?

Call & Text Notifications, Find My Phone, music control, cloud and custom watch faces need Bluetooth connectivity to work.

The time displayed on my phone and on the Storm Pro are inconsistent

Make sure your watch wave Storm Pro is connected to your phone through the app and not your phone's Bluetooth feature itself.

Will it be okay to take a bath wearing the Storm Pro?

The IP68 water resistance will only work under the following conditions:

- (1) Maximum depth of water: 1.5m
- (2) Maximum time for exposure to water: 30 minutes

The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

Why is my blood oxygen level measurement not accurate?

The measurements are for reference only because there is a different way to measure your blood oxygen levels on your watch and a different way when medical equipment is used.

How do I receive live cricket scores?

Go to app home page-> click on the cricket icon top right corner-> select the match for which you want to receive notifications -> Select the time interval.

Note: Notifications can be received for 1 match at a time.

What is the average rate of fast charging?

Watch will be fully charged in 30 minutes.

SAFETY & PRODUCT INFORMATION

Battery

- Do not disassemble, bore or damage the battery.
- Do not disassemble the built in batteries of non-replaceable battery devices.
- Do not use sharp objects to remove the battery.

Health Warning

- If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.
- The optical heart rate sensor will glow green and wave Storm Pro. If you suffer from epilepsys or are sensitive to blinking light sources, please consult your physician before wearing this device.
- The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

Things to keep in mind

- Sync data every day to avoid data loss.
- Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.
- Sports modes support up to 6 hours of exercise at a time.
- Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.
- Keep your arm still while measuring data for accurate measurement.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS. Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances.

SETTINGS

Display

Watch Faces

Tap on this icon to change your watch face.

