

CLAW™



SHOOT

WIRELESS CONTROLLER FOR PC

Button Map



Change mode

The default mode on PC is X-Input (LED 1 is ON).

Switch to D-Input (Analog mode), long press the HOME button (LED 1 + 2 is ON).

Switch to D-Input (Digital mode), short press the HOME button (LED 1 is ON)

X-Input mode is used for most modern PC games. In the X-Input mode, you will see the gamepad as 'XBOX360 controller'.

In the D-Input mode, you will see 'PC controller'. *To double check the mode status, kindly visit Control Panel (Settings) > Devices.*

Charging and sleeping mode

- When the battery power is too low, the Gamepad will automatically shut down.
- When the Gamepad is not paired with a device, it shuts-off automatically if it is inactive for thirty seconds. If the Gamepad is paired, it will shut-off after five minutes of inactivity in order to conserve power.
- When the battery is low, all LED indicators will blink quickly. Connect the gamepad to a standard, active USB port for charging.
- While the gamepad is charging, all LED indicators will flash. Once the battery is fully charged, all LEDs will turn off.

Features and Specifications

Plug-N-Play: The CLAW Trigger gamepad requires no drivers, simply plug in the 2.4GHz dongle to your PC, switch on the controller and you're ready to game. The built-in 400mAh rechargeable battery provides you with up to 10 hours of game time.

Well-built Layout and Buttons: Ergonomic and streamlined layout featuring a rubberized textured grip on both handles along with 2 Analog sticks, 8 Way Directional D-Pad, 4 Action Buttons, 2 Triggers, 2 Shoulder Buttons, 4 Function Buttons, 4 LED Indicators and 2 Built-in Vibration Motors.

Dual Vibration Motors: Experience realistic gameplay with our Dual Vibration Motors which give you a thrilling experience.

Broad game support: Thanks to the dual input support (X-Input & D-Input), you can play old and new games by simply changing modes. Supports top games such as FIFA, GTA, PUBG PC, Call of Duty PC, NFS and many more.

- Connection type: 2.4GHz wireless
- Operating range: 10 meters (33 feet)
- Battery: Built-in rechargeable 400mAh
- Play time: Approx. 10 hours *Depending on usage pattern
- Charging time: Approx. 2 hours
- Weight: 211.5 grams
- Dimensions: 12 x 6.5 x 16 cm
- Platform Compatibility: Windows 10, Windows 8.1, Windows 8, Windows 7 & Windows XP

Box Contents

- SHOOT Wireless Gamepad, 2.4 Ghz USB Wireless Receiver, USB Charging Cable and User Manual

Connection setup

- Connect the receiver to any available USB port on your computer and wait for five seconds.
- Press the "HOME" button on the controller to switch ON the gamepad. All LEDs will flash during the pairing process. Once the pairing is completed, one of the LEDs will remain constant.
- To switch OFF the gamepad, Press L3 (Center of Left Analog Stick) + BACK button. All LEDs will be switched off.

Dual Vibration Function

The Gamepad has two strong vibration motors. The controls are represented more realistically with the vibration effect.

Note : Please note that the vibration works only if the game or the program supports this function and the corresponding feature has been activated in the game option.

Safety instructions

Never try to open the device to undertake any repairs or modifications. Avoid contact with the main voltage. Do not short-circuit the product. The device is not approved for outdoor use. Please use it only in dry places. Protect it from high humidity, water and snow. Keep the device away from high temperatures. Do not expose the device to sudden changes in temperature or strong vibration, as this could damage the electronic components. Do not use the device for purpose other than those described in the user manual. This product is not a toy. Please follow the normal operation of standard batteries. If the gamepad has not been used for a long period, charge for a while.

Warranty Information

1. This product comes with a 1 year warranty from date of purchase. Kindly register your product at www.myclaw.in and retain your invoice copy which will be required at the time of warranty claim.

2. CLAW will repair or replace any part of the faulty unit which may prove defective under normal use during the offered warranty period.

3. Any physical or liquid damage to the product will void the warranty.

You may contact us via the below methods to initiate a warranty claim:

Email: service@originmarketing.in

Call: 022 40224087 / 9870294946

Website: www.myclaw.in

Facebook: www.fb.com/MyClaw

We would like to take this opportunity to thank you for your purchase. We hope the gamepad enhances your gaming experience. If it does, kindly consider posting a review! This helps us to continue providing great products and helps potential buyers to make confident decisions.

Thank you in advance for your review and for being a preferred customer. Happy Gaming!