

size: 85*60mm

material: 120g 双铜

BLAUPUNKT
TRULY WIRELESS EARBUDS
BTW



Enjoy it.

Congratulations and Willkommen! You are now part of the Blaupunkt family. You have chosen German iconic brand's premium earbuds and have become a part of an elite group that enjoys and appreciates the finest audio experience.

To get the best performance from your Blaupunkt audio product please read this manual carefully and follow the instructions. This will ensure you get the most out of your Blaupunkt product. Keep the manual safely and refer to it when in doubt.

Specification

Speaker Driver	φ10mm
Battery specs	Earbuds : 40mAh Charging Case: 450mAh
BT Version	5.3
BT profile support	HFP/ HSP/ A2DP/ AVRCP
Bluetooth range	10 m / 33 ft
Frequency response	20 Hz - 20 kHz
Charging time	Approx 2 Hours
Charging Type	Type C

Operation Instructions

Power on : Take the earbuds out of the carrying case and earbuds will turn on automatically. Or press and hold the multi-function button on the earbuds for 2 seconds. They will start up at once!

Power off: Put the earbuds back in the case. They will automatically switch off and start charging. Or you can press and hold the multi-function button on the earbuds for 4 seconds to enable a full shut down.

Note: As a power saving feature the earbuds will automatically shut down after 3 mins when they are not paired with your device. To start them again follow the power on steps.

Reboot: Once paired successfully your earbuds will automatically connect to your device once they are out of the carrying case and within range of your device. A secure connection with your device will happen after you power them on for the second time.

Play/Pause : When on and connected click either the left or right multi-function button to play music. If you want to pause music that is playing then press the multi-function button on the left or right earbud.

Switch Tracks: Switching tracks is easy. To go to the previous song, press and hold the multi-function button on the left earbud until you hear a deep audio beep. To move ahead to the next song press and hold the multi-function button on the right earbud until you hear the audio beep.

Volume Control: Click the left multi-function button three times to decrease the volume. The volume will increase gradually to be gentle to your ears. To reduce the volume click the right multi-function button three times and the volume will start increasing.

Answering Calls: When you receive a call that you want to answer then click either the right or left multi-function button on your earbuds. Your call will be connected and your earbuds will be ready for the conversation. Once you have finished with the call click the multi-function button on either of the earbuds to disconnect.

Reject Calls: If you do not want to answer a call then all it takes is a long press of the multi-function button on either of your earbuds.

Low Battery Prompt: When your earbud batteries need a charge they will prompt you with a gentle tone. This tone will be repeated every 1 minute so that you can put them in the charging case and juice up immediately. If you ignore these reminders your earbuds will power off once the battery is drained of all power.

How to Pair your earbuds

Follow these simple steps to pair your earbuds with your phone. This will not take more than a few minutes.

Step 1 - Take out your earbuds and press the multi-function buttons on both the left and right earbuds for 3 seconds. This will turn on the earbuds.

Step 2 - Once on the red and blue lights will flash alternatively on your left earbud. This means your earbuds are ready to be paired.

Step 3 - Turn on your phone and open Bluetooth. On an Android phone you will need to search for a Bluetooth device. When the model number of your earbuds appears on the phones list select it. Your earbuds will be connected at once. On an IOS device open Bluetooth and search the list for available devices. Select your Earbuds by the name shown on the list.

Step 4 - Once connected only the blue light will flash on both left and right earbuds. Now you are ready to enjoy a premium German audio experience.

Stereo Sound
Your earbuds will separate the channels (left and right) so that you get superior stereo sound. Your left bud will play the left channel and the right one the right channel.

Charging your Earbuds

Step 1 - Connect the USB type C cable to the port at on the rear of the charging case. And plug it into a charger. You can do this with or without your earbuds inside the case. When the charging case is charging a LED light will let you know the status. It is best to always keep your charging case topped up so that you can charge your earbuds on the move.

Step 2 - To charge your earbuds simply slip them back into the charging case. When charging a red light will light up on the earbuds.

Step 3 - Your earbuds will be fully charged and ready to go once both the red light turn off.

Just in case you encounter a hiccup

Q. Earbuds are not charging in the charging case?

A. First check whether the charging case has any power stored. If not then connect it with the USB Type C cable to your charger. If the case is charged and the buds are still not charging then check and clean the contact points. Sometime lint or dirt can hinder a proper connection. Clean these point gently with a cotton bud.

Q. Only one bud is connected and producing sound?

A. Make sure your buds are paired with each other before you pair them with your phone. Disconnect your earbuds and then repeat the steps given earlier in this manual to reconnect your earbuds.

ATTENTION!

Please be careful while listening to music or talking on your earbuds. Blaupunkt has always ensured that every audio product is powerful and produces massive bass and other audio ranges. Please raise the volume levels slowly and do not play music at full volume levels as this could hurt your ears.

1 Year Warranty

In the unforeseen circumstance that you have issue with your TWS product please contact our Authorized Customer Care team.
Blaupunkt Authorized Service Center:

Envent World Wide Pvt Ltd.
Khasra. No- 15/15(4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi- 110037
Whatsapp Chat Support: @8860 022 600

Please submit the following information while claiming product warranty:

-Serial Number

-Date of purchase

-A copy of proof of purchase in case of warranty

Note- If you do return the product, please use the original packaging or other suitable packaging to protect it in transit.