

**finjers™**



# Quick Start Guide

Beauté  
Wireless BT Headset


# I. Important - Warnings and Safety

1. While placing the headphone in/on your ears, please keep the volume down and then gradually adjust the volume to an appropriate, comfortable level.
2. Prolonged use at high volumes might damage your hearing.
3. Focus on your safety and of others. We recommend to not to listen music while riding or driving, or at any time the inability to hear surrounding sounds may present a danger to yourself or others.
4. If you experience a warming sensation or loss of audio, do remove and disconnect immediately.
5. Do not place the headset near the heat sources such as fire, radiators, stoves, light candles and other apparatus that produces heat.
6. Use only those accessories supplied by Fingers.
7. Unplug the headphone once it is fully charged, when unused for long periods of time or during lightning/thunderstorms.
8. It is recommended to refer all servicing to qualified personnel. Servicing is required when the headset has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

## II. In the box


- 1 x Beauté BT Headphone
- 1 x AUX Cable
- 1 x USB Cable
- 1 x Quick Start Guide

## III. On-board Controls




- <sup>1</sup> Short press to switch to different modes; Long Press to switch on/off the headset
- <sup>2</sup> Short press for increasing volume; Long press for next track
- <sup>3</sup> Short press for decreasing volume; Long press for previous track

## IV. Connections



1. Mic 2. LED Indicator 3. Micro USB for charging  
4. AUX port 5. MicroSD Card slot

## V. Charging



- A red light indicates that it is in charging mode. Once it is completely charged, the red LED glow disappears.
- Allow up to one and half hours to completely charge the headset.


## VI. Modes

You can enjoy your music in the following ways

i. BT ii. FM Radio iii. MicroSD iv. AUX

### i. BT




- Press on the mode button till the voice prompt is heard.
- The LED indicator starts flashing in blue, signifying that it is ready to pair a device.
- As it flashes blue, make sure that Bluetooth is enabled on your device. Find the device list and select *Fingers Beauté*. The Bluetooth button turns solid blue for a moment, a sound prompt of “Connected” is heard and it is ready to play.



- Repeat above steps to pair another device.
- The headset remembers previously connected device. When turned on, it attempts to reconnect to previously paired device.

### *Receiving calls*

Can receive/end calls from the Headset, if your mobile device is connected to the Headset.

- Short press the  button to receive the call.
- To end the call, again press the same button
- If you wish to reject the incoming call, long press the  button.
- Press the  twice to call-back the phone.

### ii. FM Radio

- Press on the mode button till the voice prompt of the word “FM Mode” is heard.
- Once FM radio is tuned, you can press + and - to select the desire FM channel.

## VIII. Product Specifications

<b>Wireless Protocol</b>	BT v5.0
<b>BT Profiles Supported</b>	HSP, HFP, A2DP and AVRCP
<b>Output Power Rating</b>	35 mW
<b>Driver unit</b>	Φ 40 mm
<b>Effective Frequency Response</b>	20 Hz ~ 20,000 Hz
<b>Effective Frequency Range</b>	2.402 GHz ~ 2.480 GHz
<b>Impedance</b>	32 Ω
<b>Sensitivity</b>	110 ± 3 dB
<b>Distortion</b>	0.01%
<b>Effective Range</b>	Up to 10 meters
<b>Battery</b>	240 mAh Polymer battery
<b>Charging Time</b>	About 1.5 hours
<b>Playback Time*</b>	Up to 9 hours
<b>Standby Time</b>	Up to 17 hours
<b>On Device Controls</b>	Play/Pause/Call   Power/Mode   Volume Up/Next Track/CH+   Volume Down/Previous Track/CH-
<b>Playback Options</b>	BT   FM Radio   MicroSD   AUX
<b>Dimensions</b>	166 (L) x 186 (W) x 78 (H) mm
<b>Weight</b>	150 g
<b>Colours</b>	Emerald Green   Gun Grey   Mocha Maroon   Mauve Brown
<b>Supplementary Features</b>	- Built-in Microphone - Voice prompts

### iii. MicroSD

- Insert the Micro SD card in the desired port.
- You can then play your favourite tracks directly from the Micro SD Card.

### iv. AUX

- If you wish to listen to music from mobile devices, plug in the AUX cable in the Aux port.
- You can then stream music directly from your mobile devices.

## VII. Care and Maintenance

1. Switch off the headset before cleaning it.
2. Use soft, damp cloth (water only) to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.



[www.fingers.co.in](http://www.fingers.co.in)

\*Tested under ideal conditions and varies depending on the usage and volume levels.

• Images shown may vary from actual product. • Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on [www.fingers.co.in](http://www.fingers.co.in) • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website [www.fingers.co.in](http://www.fingers.co.in)

Ver.: 1.0.1