



## Just Play!

### Manual Setup Guide



## AirDopes 148

Get ready to immerse yourself in musical bliss with your very own pair of boAt AirDopes 148. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss.

Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

### PACKAGE CONTENTS

- 1x Pair of TWS Earbuds
- 1x Charging Case
- 1x Type-C Charging Cable
- 2x Pair of Extra Earmuffs
- 1x User Manual
- 1x Warranty Card
- 1x Catalogue

### POWER ON (First Time User)

**Step 1:** To switch the earbuds on (Smart Power On) simply open the lid of the charging case (when earbuds are inside). Courtesy our IWP™ technology, the earbuds power on automatically, get connected and enter into the connection mode

OR

Long touch the CTC on both earbuds for 8 seconds to manually power on the earbuds

**Step 2:** After powering on, the earbuds enter into the Connection Mode, indicated by red and white LED flashes

### CONNECTION MODE

**Step 3:** Turn on the Bluetooth functionality on your phone/media device and scan

**Step 4:** Search for 'Airdopes 148' and pair accordingly.

Congratulations! Your earbuds are now connected successfully via Bluetooth

*Note:*

- Pairing mode lasts for 3 minutes. If the pairing time is missed then you will need to reconnect the ear-buds and follow the above mentioned procedure
- Airdopes 148 remembers previously connected devices; once switched on, the ear-buds automatically reconnect to the previously connected devices



### SINGLE EARBUD USAGE

**Step 1:** Please note that both the earbuds can be used in mono mode. Use Smart / Manual Power On for switching on the desired earbud

**Step 2:** The selected earbud will automatically enter the connection mode indicated by red and white LED flashes


**Step 3:** Turn on Bluetooth on your phone/media device and search for 'Airdopes 148' to connect

*Notes:*

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage
- You cannot skip tracks or return to the previous tracks in Mono mode

### QUICK GUIDE ON FUNCTIONALITIES

- 3 Seconds ○ Long touch either CTC for 3 seconds to activate voice assistant
- 8 Seconds ○ Long touch both CTCs for 8 seconds to manually power on
- 5 Seconds ○ Long touch both CTCs for 5 seconds to manually power off



### CHARGING THE EARBUDS

**Step 1:** Please insert the earbuds back inside the charging case in correct orientation.

**Step 2:** A solid red LED on earbuds indicates that the earbuds are being charged. Once fully charged the LED turns off

**Step 3:** Once the earbuds are fully charged, the charging case automatically switches off to save power.

*Note:*

- Before using the ear-buds for the first time, it is recommended to fully charge the ear-buds. Also, please keep the lid of the charging case closed while charging
- If battery is 20% or below then the red LED blinks every few seconds to indicate the same

### CHARGING THE CASE

**Step:** To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/ powerbank, etc.

White LED flashes while the case is on charging. When the charge gets full, it gets indicated by solid white LED.




### Charging norms & Precautionary Guidelines:

1) Charger/Brick/Adapter	: 5V/2A
1) Cable/Wire	: Standard Cable (35 Strands @0.10mm diameter/strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

### BASIC FUNCTIONS

- Voice Assistant: Long touch the CTC on either earbud for 3 seconds to activate the voice assistant
- Answer: Single tap the CTC on either earbud to answer an incoming call
- Hang Up / Reject Call: Double tap the CTC on either earbud to end or reject call
- Play/Pause Music: Single tap on either earbud's CTC to play or pause music
- Next Track: When playing music, double tap the right CTC to skip to the next song
- Previous Track: When playing music, double tap the left CTC to return to the previous song



*Note:*

- Volume can only be controlled via the media device


### VOICE ASSISTANT

**Step 1:** Long touch the CTC on either earbud for 3 seconds to activate the smart voice assistant

**Step 2:** The respective voice assistant screen pops up and you may place your commands at ease

**Tips:** You may try out the following commands,

- What is the weather?
- Play a song
- Set a reminder



### SMART POWER OFF

**Step 1:** After usage, remove both the earbuds from your ears

**Step 2:** Place the earbuds back into the charging case in correct orientation and close the lid

The earbuds automatically switch off (and enter into charging mode).



### MANUAL POWER OFF

**Step 1:** Long touch both CTCs for 5 seconds to manually power off

**Step 2:** Once the earbuds get turned off, place them back inside the case and close the lid



### MANUAL FACTORY RESET

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 148  
*\*Note: Before performing reset, clear "Airdopes 148" from pairing device history by forgetting device.*

**Step 1:** Take both earbuds out from the charging case

**Step 2:** While in pairing mode (White and Red LED Flashes on earbuds), Tap 5 times on both earbuds CTC area, Red and White LED flash to indicate the same then Red LED flash before Turning OFF

**Step 3:** Keep both earbuds inside the charging case

**Step 4:** Once you open charging case lid, they automatically restart.

**Step 5:** Congratulations! Your Airdopes 148 has been reset

### AUTO - RESET

Airdopes 148 comes equipped with our cutting edge IWP™ technology along with the Auto-Reset feature, which means that you would not require to do the factory reset manually. Now, every time while the earbuds are kept inside the case and the lid gets opened, the earbuds reset automatically.

*Note:*

The Auto-Reset mechanism helps to refresh the earbuds and troubleshoot operation issues, if any.

### SPECIFICATIONS

Bluetooth Version	V5.0
Music Playtime	Up to 6HRS per charge; Up to 36HRS additional with Case (at 60% volume)
Standby Time	100H
Talktime	5HRS
Transmission Range	10m
Driver Size	8mm*2
Bluetooth Profiles	HFP/ HSP/ A2DP/ AVRCP
Frequency	20Hz-20kHz
Battery	600mAh (Case) 30mAh*2 (Earbuds)
Charging Time	1H (Earbuds) ; 2H (Case)
Charging Interface	Type C
Water Resistance	IPX4

### WARNING

- Please follow the instructions to operate
- Please don't use the ear-buds in extreme temperatures
- Please don't use the product near water
- Please keep the product away from heat sources, as the heat may damage it
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life

