


SAREGAMA
CARVAAN[®]
— mini+ —


TOP VIEW: BUTTONS ON CARVAAN MINI+



**answer/disconnect/reject calls when in BT mode*

LEFT SIDE VIEW: MODES ON CARVAAN MINI+

To choose a mode, press the corresponding mode button on the unit



modes

SAREGAMA

1000 pre-loaded evergreen songs by legends. This is the default mode on first power on/reset

Complete list of songs:

www.saregama.com/carvaanmini

FM/AM**

Listen to local FM/ AM stations.

To tune to FM, press FM/AM mode button

To tune to AM, press FM/AM mode button again

To tune to AM from any other mode, press FM/AM mode button twice

***AM station will play as per broadcast timings*

To auto tune FM/AM stations, follow the steps:

Step 1: Press play/pause button for 5 seconds

Step 2: Searching for all FM/AM signals will start. You will hear a searching sound and each FM/AM station will play for approx. 3-4 seconds till all stations are tuned

Step 3: Press next/previous button to go to next/previous station

FM frequency: 87.5 to 108 MHZ; AM frequency: 520 to 1710 KHZ

Note: Avoid charging the unit while listening to FM/AM as it will interrupt the signal

Refer to the insert in the box for detailed process to auto tune FM/AM stations.

BLUETOOTH***

Pair your mobile phone/ tablet with Carvaan Mini+. Enjoy songs stored on your personal device or go handsfree on Carvaan Mini+ speakers.

When in Bluetooth mode & the status light blinks blue, it indicates that the unit is ready to be paired. Once paired, the steady blue light indicates that you need to play a song.

When in Bluetooth mode & a call comes in, it will ring on the speaker. Song playback if any, will be paused.



Calling mode


- Answer a call: Press play/pause once
- Disconnect the call: press play/pause once/again
- Reject a call: Press the play/pause for 3 seconds

Once the call has been disconnected/rejected, the song playback will resume.

****support for BT version 5.0*

FRONT VIEW: STATUS LIGHT

status
light




This light indicates the status as follows:



- i. Steady blue light: song paused
- ii. Blinking red light: battery low; put the unit to charge
- iii. Blinking blue light: bluetooth pairing mode

BACK VIEW: PORTS ON CARVAAN MINI+

Pull out the antenna from the back panel of Carvaan Mini+ for improved reception of local FM stations



RIGHT SIDE VIEW: AUX OUT



USB to Type-C charging cable

Frequency: 220V AC 50Hz for input and DC 5V 1.0 AMP for output



Full battery charge time 3-4 hours

Battery usage: Approximately 5-6 hours once the battery is fully charged

Battery charging indicator:

- i. Steady red light: Unit is being charged
- ii. No light: Unit fully charged

SAFETY HANDLING

1. CARE FOR PRODUCT

- Keep Carvaan Mini+ away from dust and excessive heat (heat registers, stoves etc.)
- Prevent spillage of water/liquid as this can cause failure of product or could prove to be a potential fire hazard
- Clean the unit with a dry cloth only
- Do not walk on or pinch the power cord close to the plug
- Do not immerse Carvaan Mini+ into water

2. CARE FOR BATTERY

- Do not expose the battery to heat sources greater than 60°C
- Recycle or dispose the battery when essential. Please ensure proper battery handling and disposal methods
- Do not subject the battery pack to a mechanical shock
- In the event of a battery leak, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with water and seek medical advice
- For prolonging battery life, avoid discharging the battery completely
- To ensure optimum battery condition, the unit should be charged for atleast 4 to 5 hours, once a month. If the unit is unused for over a month, battery will get completely discharged

3. OTHERS

- Use attachments / accessories as specified by the manufacturer
- Please contact an authorized service center for any repair/servicing requirements or call the toll free no. 1800-102-7799


WARRANTY OVERVIEW

Carvaan Mini+ comes with a 6 months Warranty on all parts, excluding accessories. This includes servicing/ repair or replacement of damaged parts.

The warranty does not apply and does not cover the following:

- Liability for loss of data/content loaded in the product due to misuse or tampering
- Damage caused due to force majeure events; events caused by fire, water, electrical disturbances etc.; events beyond the control of Saregama; acts of negligence or mishandling; usage for commercial, business, industrial, educational or rental purposes

For detailed warranty: www.saregama.com/carvaanmini

 Waste electrical products should not be disposed of with household waste. Please follow disposal and recycling instructions issued by the concerned local authority.

WARRANTY CARD

Customer's Name: _____ Customer's Address: _____

Product Serial No.: _____ Date of Purchase: _____ Expiry Date: _____

I accept the terms and conditions of the warranty.

Retailer's Name: _____ Retailer's Signature/Seal: _____

Customer's Signature