


Automatic Electric Dry Iron





USER MANUAL

GD205



GENERAL DESCRIPTION

TEMPERATURE CONTROL KNOB

With this knob you can set the correct temperature for each kind of fabric.

SWIVEL

It gives freedom of movement and prevents wear and tear of the cord.

SOLEPLATE

The base of the iron which comes in contact with fabric.

INDICATOR LIGHT

When the light goes off, the iron is ready to use.

HEEL

While not in use and for storage, the iron should be placed on its heel.

CORD

It allows easy & free movement of the iron.

Cloth Material	Temperature Setting
Nylon/Synthetic Fiber	•
Rayon / Manmade Fabric	•
Silk	••
Wool	••
Cotton	•••
Linen	•••

The data & drawing shown here are indicative & may be revised without proper intimation.

WIPRO GD-204 DRY IRON

Thank you for choosing Wipro Dry Iron. Every Wipro Iron adheres to the highest quality standards. Not only are the irons efficient but are also loaded with safety features and are equipped with cutting-edge technology for your safety and for a superior and efficient performance.

KEY FEATURES

- Weilburger non-stick coated soleplate.
 Uniform heating with G-shaped heating element.
 Ease of use with swivel cord with cotton braided thread.
 Indicator lamp for power indication.
 Longevity assured with silver-layered thermostat contacts.
 Fire safety with high-temperature-grade PBT insulator.
- 7. Added safety with bimetallic thermostat with thermal fuse.

Do's & Don'ts

DO'S

- 1. Read instructions carefully before operating your iron.
- Always connect the iron to a properly earthed 3-pin-plug power supply socket.
- 3. Before connecting the appliance, please ensure that the voltage indicated on the label corresponds to the local mains voltage.

DON'Ts

- 1. Never leave the iron unattended while connected to the main supply.
- 2. Always ensure that the hot Iron does not touch fabrics or cord or an int inflammable surface
- 3. Never touch the appliance with wet or damn hands.
- 4. Do not operate the iron if the cord is damaged or if the iron has been dropped or damaged. Get it examined / repaired from the authorised service centre.
- 5. Avoid use of extension boards as this could be hazardous.
- 6. Do not let the mains cord come into contact with the hot soleplate of the iron.
- 7. Avoid touching hot surfaces.

OPERATIONAL INSTRUCTION



- 1. Remove the packaging/sticker pasted on the soleplate.
- 2. Plug the mains cord of the iron to the power socket and keep the iron on heel (rest position).
- 3. Using the thermostat knob, set the temperature, corresponding to the type of fabric.
- When the indicator light goes off, the Iron Is ready to use.
 Before plugging or unplugging from outlet, the iron should always be turned to "Off" position.
- 6. Always keep the iron moving while ironing.
- 7. Pressing onto the iron is not necessary, provided the temperature has been set correctly.
- 8. In case of silk, wool or synthetic material, always iron the reverse side of the fabric.

CARE AND MAINTENANCE

- 1. Remove the mains plug and allow the iron cool down.
- 3. Avoid scratching the soleplate with steel wool or metallic objects.
- 4. To clean the iron soleplate, take a handful of salt on a clean sheet of paper. Turn the iron on at maximum thermostat setting, and rub/move the Iron over the salt till the residue gets removed. Switch off the iron and wipe It with a damp cloth.

TECHNICAL SPECIFICATIONS

Model Name	GD101
Swivel Cord	360°
Temperature Control	Yes
Power Consumption	1000 Watts
Body	Plastic
Soleplate Coating	Weilburger Non-Stick
Product Warranty	2 Years

Model Name	GD204
Swivel Cord	360°
Temperature Control	Yes
Power Consumption	1000 Watts
Body	Heavy metallic body with plastic handle
Soleplate Coating	Weilburger Non-Stick
Product Warranty	2 Years

Model Name	GD205
Swivel Cord	360°
Temperature Control	Yes
Power Consumption	1000 Watts
Body	Plastic
Soleplate Coating	Weilburger Non-Stick
Product Warranty	2 Years

TROUBLESHOOTING

07

Problem	Possible Cause	Remedy
	There is no power supply	Check for power supply or try plugging the iron in a different power socket.
Iron is not working properly	Fabric selection dial is at minimum/cool position.	Rotate the dial on to the desired fabric setting, depending on the cloth fabric.
	If none of the above suggestions work, then there may be an internal defect.	Contact the toll-free helpline number for assistance.
Soleplate Is not clean/ residue stuck on soleplate.		Switch off and unplug the Iron, then clean the soleplate as per the instructions mentioned under "Care & Maintenance" section.
Low Heating	Fabric selection dial is at minimum/cool position.	Rotate the dial on to desired fabric setting, depending on the cloth fabric.
	If none of the above work, then there may he an internal defect.	Contact the toll-free Helpline no for assistance.
Cloth Sticking	Soap/detergent residue in washed clothes.	Select the appropriate fabric setting from the fabric dial and allow the iron to cool down once before using it again.
	Residue stuck on the iron's soleplate.	Switch off and unplug the iron, then clean the soleplate as per the instructions mentioned under "Care & Maintenance" section.

Wipro acknowledges the customer/ purchaser or this product with a warranty of 24 months. From the date of purchase, the Company will repair or replace free of charge any part of the product, should the company be fully satisfied at its sole discretion that the defect/s is/are due to faulty material or manufacturing detect only. The warranty will be subject to the following clauses

- 1. The warrant is valid only it this warranty card is duly signed and stamped by our authorised dealer/retailer and is produced along with the original customer's invoice copy.
- 2. The warranty starts from the date or purchase from our authorised dealers/retailers only.
- 3. The company or their authorised service agent/dealer will repair/replace all parts failing due to faulty material or manufacturing defect pertaining to the product.
- 4. Only the company's authorised service agents/dealers can service/repair/attend to the product.
- 5. All expenses incurred in collecting the units or parts thereof from the Company's authorised service stations or the dealer of the Company, as well as expenses incurred in connection with deputing or service personnel/technician towards to and from travel conveyance and other incidentals, etc.... will be borne by the customer/purchaser.

- 6. The warranty extended herein is in lieu of all implied conditions and warranties under the law and is confined to the repair or replacement or me defective part and does not cover any consequential or resulting liability, damage or loss, whether direct or indirect, arising from such detects. Furthermore, the warranty, in no case shall extend to the payment or any monetary consideration whatsoever for the replacement or return of the product.
- 7. This warranty does not cover corrosion, replacement or plastic or glass components which add decorative value to the product.
- 8. The decision of the Company is final and binding on all matters arising out of this warranty.
- 9. The warranty stands null and void in case the product is struck by a force majeure event which shall include, but not he limited to, acts of God, including floods, earthquakes, any other natural calamity, accidents, war, fire, or an act or government or other component authority
- 10. Any attempt made to rectify, dismantle or alter the product may lead to electrical shock or may destroy the product for which the Company is not responsible. The Company is also not responsible for any consequential loss or damage or installation costs arising out of the same.
- 11. Limitation of liability: Company shall not be liable for any special, indirect, incidental or consequential damages what so ever including but not limited to loss of profit, revenue or data (whether or indirect or commercial loss for breach of any express or implied warranty on your product even if the Company has been advised of the possibility of such damages.
- 12. This warranty is applicable in India only.

WARRANTY

In addition to the terms and conditions stated above, this warranty is not valid in case of any of the following events:

1.	The product is not used according to the instructions given in the instruction/user manual.
2.	The warranty specifically excludes any problems arising out of mishandling, wilful damage, improper storage of the product/ its parts.
3.	The electricalpower supply voltages are not within the stipulated norms (supply voltage 230V AC - 50Hz).
4.	Any repair work/installation carried out by a person other than Company Authorised Service Centre.
5.	Normal wear and tear of the product.
6.	Damage due to chipping, peeling of plating, denting.
7.	The serial number is deleted, defaced or altered.
8	The original purchase receipt/ invoice is not available.

WARRANTY CARD

Model Name: GD101 / GD204 / GD205 Automatic Electric Dry Iron1000W	
Serial No. :	wipro
Bill No. :	
Date of Purchase :	
Customer's Name & Address:	
	Phone No. :
Dealer's Name & Address:	
Marketed By: Wipro Enterprises (P) Ltd. #8, Wipro House, 80 Ft Road, Koramangala, Bengaluru-560034, Karnataka	Manufactured For: Wipro Enterprises (P) Ltd. At:#81,Harohalli Industrial Area, Kanakapura Taluk, Ramanagara District 562112 Karnataka
Model Name: GD204 Automatic Electric Dry Iron 1200W Serial No. :	
Bill No.: Date of Purchase:	
Customer's Name & Address:	
Phone No. :	
Dealer's Name & Address :	

For more information please visit
Wipro Smart light: www.wiproconsumerlighting.com