

NIRVANA LUCID



NIRVANA LUCID

Immerse in your favorite tunes with your personal pair of boAt Nirvana Lucid. Please consider this manual as your guiding map to navigate the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boAt. Therefore, we strongly recommend that this manual is read thoroughly. You can even refer to it at times when you face difficulties.



BASIC FUNCTIONS

- Answer Calls: Single tap the CTC on either earbud to answer incoming calls
- Hang Up Calls: Double tap the CTC on the right earbud to end an ongoing call
- Reject Calls: Double tap the CTC on the left earbud to reject incoming calls
- Play/Pause Music: Simply plug in the earbuds inside your ears to start playback and remove them to pause music

OR

- Single tap the CTC on either earbud to play or pause a track
- Next Track: Double tap the CTC on the right earbud to skip to the next track
- Previous Track: Double tap the CTC on the left earbud to return to the previous track

AMBIENT, ANC, AND NORMAL (ANC OFF) MODES

Long Touch the CTC on the right earbud for 3 seconds to toggle between Normal (ANC Off), Ambient, and ANC modes of music. Ambient mode is for transparency towards the audible surroundings; while ANC mode cancels out the external noise up to 32 dB so that you can immerse fully in your playlists.

Note:

- By default, the ANC OFF (Normal) mode is active.
- The operational cycle is ANC OFF (Normal mode) → Ambient Mode → ANC Mode
- Your earbuds will remember the mode you last used & will enable the respective noise cancellation mode when its powered on next time

BEAST™ MODE

Triple tap the left earbud CTC to switch to Low Latency gaming mode, also known as the BEAST™ Mode. Once switched on, it gets notified via a sound prompt. Triple tap the left CTC once again, to turn it off and return to Music Mode. Made for the Gamers - By Gamers, BEAST™ Mode reduces the latency significantly and improves the overall gaming experience.

boAt ADAPTIVE EQ:

boAt Adaptive EQ in these earbuds generates custom profiles tailored to your hearing profile. As a result, you can hear unintelligible dialogue and sound elements without straining as the audio adapts to your profile automatically. The EQ level can be set up on the boAt Hearables app, attuned to your listening comfort.

AI ENx™ TECH

Our AI-powered ENx™ tech algorithm cancels out the background noise so that you can be heard crystal clear on voice calls. You don't have to activate AI ENx™ as the quad mics are equipped with the same and activated by default. The AI is trained in all possible atmospheres - Office, Home, Traffic, Railway stations & airports to get the best call quality.

SMART POWER OFF


- Step 1: After usage, remove both the earbuds from your ears.
- Step 2: Place the earbuds back into the charging case in correct orientation and close the lid.
- Step 3: The earbuds will automatically switch off (and enter charging mode)

MANUAL POWER OFF

- Step 1: Long touch the CTC on both the earbuds for 7 seconds and release to switch off manually.
- Step 2: Once the earbuds get turned off, place them back inside the case and close the lid.

PACKAGE CONTAINS:

- 1x Pair of TWS Earbuds
- 1x Type-C Charging Cable
- 1x Charging Case
- 2x Pairs of Extra Earmuffs



POWER ON (FIRST TIME USER)

Step 1: To switch the earbuds on (Smart Power On), simply open the lid of the charging case (when earbuds are inside) & remove protective film. Our IWP™ (Insta Wake N' Pair) technology enables the earbuds to power on automatically, get connected, and enter into the connection mode.

OR

Long touch the CTC (Capacitive Touch Control) on both earbuds for 3 secs to manually power on the earbuds

Step 2: Once powered on, the earbuds enter the Connection Mode, indicated by white LED flashing for 1 second on the earbuds.

SPEAKTHRU MODE:

Long touch the left earbud CTC for 3 seconds to switch on SpeakThru Mode. Once activated, it gets notified via a sound prompt. Long touch the left earbud CTC for 3 seconds again and release to de-activate this function. SpeakThru Mode simplifies engaging with conversations in your surroundings by lowering the in-ear audio volume when you start speaking into the microphone. Download & update the device software through the boAt Hearables App to enable this smart feature.

Note:- You can increase/decrease the volume using your mobile in SpeakThru Mode. Once modified, it stays the same even after switching off SpeakThru Mode.

OTA (OVER-THE-AIR) UPDATE COMPATIBILITY

Using the boAt Hearables app, you can tap into a host of dedicated services. Enjoy periodic software upgrades for up to 1 year, easy troubleshooting fixes, personalized modes, etc. What's more, by tuning in you can keep an eye out for our upcoming features around the corner!

CONNECTION MODE

Step 3: Turn on the Bluetooth functionality on your phone/media device to start scanning.

Step 4: Search for 'Nirvana Lucid' and pair accordingly.

Congratulations! Your earbuds are now connected successfully via Bluetooth

Note:

- Pairing mode lasts for 5 minutes. If the pairing duration is missed, you need to reconnect the earbuds and follow all the steps mentioned above.
- Nirvana Lucid remembers previously connected devices for your ease; once switched on, the earbuds will automatically reconnect to the previously connected devices when in the working range.



MONO (SINGLE EARBUD) MODE:

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart/ Manual Power On for switching on the desired earbud.

Step 2: The selected earbud will automatically enter the connection mode indicated by alternate LED flashes.

Step 3: Turn on Bluetooth on your phone/media device and search for 'Nirvana Lucid' to connect.

Notes:

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage.
- You can only skip to the next track while using the right earbud or play the previous track using the left earbud in Mono (single earbud) mode.

SPECIFICATIONS

Headphone Type	ANC TWS Earbuds
Bluetooth Version	V5.3
Water Resistance	IPX5
IWP™ Technology	Yes
ANC	Up to 32dB
AI-ENx™ Equipped Microphones	4
Latency with BEAST™ Mode	60ms
Music Playtime	Up to 12H per charge, Up to 48H additional Case playtime (Non-ANC mode) Up to 9 H per charge, Up to 36 H additional Case playtime (ANC mode)
Standby	100H
Charging Technology	ASAP™ Charge
Transmission Range	10m
Driver Size	10mm
Google Fast Pair	Yes
Codec Support	SBC and AAC
Frequency	20Hz-20kHz
Battery	480mAh (Case); 40mAh*2 (Earbuds)
Charging Time	30min (Earbud) & 90min(Case)
Charging Interface	Type C

QUICK GUIDE ON FUNCTIONALITIES

- 3 Seconds Left Earbud: Long touch the left CTC for 3 seconds to enable/disable SpeakThru Mode. (Software needs to be updated via boAt Hearables App to enable this feature)
- 3 Seconds Right Earbud: Long touch the right CTC for 3 seconds to toggle between ANC OFF, Ambient, and ANC ON modes.
- 3 Seconds: Long touch both CTCs for 3 seconds to manually power on.
- 7 Seconds: Long touch both CTCs for 7 seconds & release to manually power off.
- 10 Seconds: Long Press the reset button on the charging case for 10 seconds to perform a factory reset.

MULTI POINT CONNECTIVITY

Step 1: Switch on the Bluetooth on your first phone/media device and search for 'Nirvana Lucid'. After the selection is done, the earbuds are paired with your phone/media device.

Step 2: Turn off the Bluetooth function of your first phone/media device. The earbuds are ready to be paired again.

Step 3: Now switch on the Bluetooth function on your second phone/media device. Scan and select 'Nirvana Lucid' to connect.

Step 4: Switch on the Bluetooth of the first phone/media device again. The earbud is reconnected to the first phone/media device.

Step 5: Congratulations! Your earbuds are now connected to both your devices successfully via Bluetooth.

Note:- Your Nirvana Lucid will auto re-connect to last 2 paired devices if bluetooth in the 2 devices in turned ON

FACTORY RESET

Perform the Factory Reset in case you face any difficulty while operating your Nirvana Lucid. NOTE: Before performing reset, clear "Nirvana Lucid" from the pairing device history by forgetting the device.

- Step 1: Place the earbuds inside the case.
- Step 2: While the earbuds are inside the case, long press the Reset Button for 10 seconds.


After successful factory reset:

- Red LED flashes 5 times on the charging case
- White LED flashes 3 times on the earbuds

Step 3: Close the lid and then re-open it again after a few seconds.

Step 4: Perform a fresh connection attempt and enjoy!

Congratulations! Your Nirvana Lucid has been Reset.



WARNING

- Please follow the instructions to operate
- Please don't use the earbuds in extreme temperatures
- Please don't use the product near water
- Please keep the product away from heat sources, as the heat may damage it
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the earbuds' service life

Advisable: The earbuds may start at a high volume and it may need to be reduced when they are switched on at first. This can be done by using volume control on media device.

CHARGING THE EARBUDS

Step: Please insert the earbuds back inside the charging case in correct orientation.

Earbuds Remaining Battery	LED Indication
Less than 30%	White light blinks thrice when the case is opened
30%-100%	White light remains solid for 0.5 seconds when the case is opened

Note:

- Before using the earbuds for the first time, it is recommended to fully charge the earbuds. Also, please keep the lid of the charging case closed while charging.

CHARGING THE CASE

Step: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/ powerbank, etc.

Case Remaining Battery	Charging State	Normal (Non-Charging) State
Less than 30%	Red LED flashes 3 times rapidly to indicate the battery level and then blinks slowly	Red LED blinks 3 times on opening the case lid
30%-70%	White LED flashes 3 times rapidly to indicate the battery level and then blinks slowly	White LED blinks 3 times upon opening the case lid
More than 70%	Green LED flashes 3 times rapidly to indicate the battery level and then blinks slowly	Green LED blinks 3 times upon opening the case lid

Case LED indication when the earbuds are charging inside with the lid closed:

- If either of the earbuds is charging inside the case, the purple LED flashes for 5 seconds.
- When both the earbuds are fully charged, the blue LED flashes for 5 seconds.

TROUBLESHOOTING

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection/ scan mode	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case & try using them again or perform the Factory Reset
If Touch Controls don't seem to respond	After long usage, residual stains and perspiration can affect the touch controls. Please use a clean cloth to wipe the touch control area gently.

Charging norms & Precautionary Guidelines: -

1) Charger/Brick/Adapter	: 5V 2A
2) Cable/Wire	: Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.