App Downloading

Find and download the Vivamo app on the App store (iOS version) or Google Play (Android version) or B-Band app. (Bluetooth version B-Band is Above one bracelet)

Note: For the Bluetooth version, the APP may not work properly.

Please use www.mywearable.com/mywearable to register your watch and download the APP. Please use the latest version of the operating system, advanced and regular firmware updates will be provided in upgrade software.

Switching ON the MAX PRO TURBO watch

1.Watch & APP Connecting

1. Turn on your watch (Bluetooth and GPS, Make sure the watch is not connected to other Bluetooth devices)
2. Open APP, Tap the top left button, the APP's top left and top right corners.
3. Please set www.mywearable.com/mywearable to register your watch and download the latest version of the APP and firmware, advanced and regular firmware updates will be provided in upgrade software version.

2.Battery

Your watch has a low power optimized battery for extended operation.

Normal usage scenario:
B-Band (Without Calling function GPS): Standard use, Bluetooth connection, 24 hours heart rate monitoring, 1 hour sports mode, 1 hour GPS positioning, 1 hour screen lighting, 1 hour vibration, 1 hour Bluetooth connection, 1 hour Bluetooth Notifications, 1 hour Bluetooth, Hour call using watch speakers for other apps, 30S Brightness, Manual sleep monitoring, 30 Sport Mode Entries, 5 Alarm Clocks.

Watch (Without Calling function):
5-Days (With Calling function GPS): Conversation, 24 hours heart rate monitoring, 1 hour sports mode, 1 hour GPS positioning, 1 hour screen lighting, 1 hour vibration, 1 hour Bluetooth connection, 1 hour Bluetooth Notifications, 1 hour Bluetooth, Hour call using watch speakers for other apps, 30S Brightness, Manual sleep monitoring, 30 Sport Mode Entries, 5 Alarm Clocks.
3-Days (With Calling function): Conversation, 24 hours heart rate monitoring, 1 hour sports mode, 1 hour GPS positioning, 1 hour screen lighting, 1 hour vibration, 1 hour Bluetooth connection, 1 hour Bluetooth Notifications, 1 hour Bluetooth, Hour call using watch speakers for other apps, 30S Brightness, Manual sleep monitoring, 30 Sport Mode Entries, 5 Alarm Clocks.

30-Days (Standby: Bluetooth off, using watch for normal

3.Connecting For Calling Feature

Go to your Smartphone's Settings and go to Bluetooth option. Find Mobile (TW_Watch), pair it to the Bluetooth device to connect the watch.

As per default settings, the voice will go to the watch speaker. You can change it to your phone speaker by tapping on the call button on the watch and then tapping on the call mode icon. Now you can hear the caller through your phone's speaker. Alternatively, you can pair your watch and enjoy hands-free Calling. Please turn off the Calling function if your watch and enjoy hands-free Calling. Please turn off the Bluetooth function.

Please ensure the volume is turned up on both the watch and your phone for optimal calling experience.

4.Charging

Place the watch on the Base for the first time, please charge it fully to ensure the Watch has sufficient power & optimal functions.

Place the watch on the charging base, the charging base will show the Watch for at least 2 hours to be charged. The Indicator **Red** signifies ongoing charging, while the Watch, overcharging will shorten the battery working time.

Note: Use the Watch with USB charging base only, overall wear is not covered by the warranty. Using other charging bases may damage the watch and pose a power saving mode. All functions will be disabled.

Note: Please use the charging base provided with the watch, choose a charger with an output voltage/current of 5V/500mA or 1A.

Note: Please ensure the charging base and the watch are in close contact when the watch is charging, to avoid short circuit or the **DO NOT USE A DEVICE THAT CHARGES**

5. Using Calling Feature

Steps:

1. Ensure the watch is paired with your smartphone's screen when you lift the wrist.
2. Tap on the phone icon on the watch's home screen to access the call interface. The interface **Red** signifies ongoing call, while **Green** signifies incoming call.
3. Tap the call button to initiate a call. The watch will automatically connecting the watch for Bluetooth connection. Ensure your phone is ready to dial the number.
4. During a call, the watch will display the call duration. You can mute/unmute and use the keypad if needed.
5. To end a call, simply press the call button again.
6. Incoming Call Notification: When a call comes in, the watch will display the caller's number. You can choose to accept or decline the call directly from the watch.
7. Call History: Access your call history directly from the watch to review recent calls.

Note: Ensure your phone has the function by setting enabled for "Voice Dial" function.

6.Heart Rate Watch

7.Customizing Watch Faces

8.About Your Watch

9. Customizing Watch Faces

10. Heart Rate

1. Ensure the watch is connected to your phone.
2. Navigate to the heart rate icon on the watch's home screen.
3. Tap the heart rate icon to initiate the measurement.
4. The watch will start measuring your heart rate.
5. Wait for a few seconds for the watch to display the heart rate reading.
6. Review your heart rate data on the watch screen.
7. Optional: Enable continuous heart rate monitoring in the app for ongoing heart rate tracking.

Note: Ensure the watch is worn snugly and the sensor is in contact with your skin for accurate readings.

11. Sleep

You can anti-wake 5 Minutes reminders. Add notices from the Vivamo Smart Fit App for "Sedentary Contacts" and add contacts of your Vivamo Fitness Watch. Sedentary reminders will be sent to your watch when you have disabled Do not Disturb Mode (turning the contact sensor in the "Phone")

12. Notifications

Click on notification access on the App and allow Vivamo Smart Fit App for notifications access. Turn on your Bluetooth and turn on your Vivamo watch.

You can activate and Turn Off Notifications of the Vivamo Watch from the App. You can also personalize the watch face with your favorite photo and customize the watch face. Watch faces can be selected from watch faces, watch faces - editor, watch faces - gallery. Take pictures from phone & drag to desired and click. (the size of the "right" screen. Once done press OK. Watch faces can be deleted from the App. Watch faces can be also synced from other APP, APP Store, and APP Store, and all Internet records are available in the APP.

13. Sport

Sport Modes (Walking, Running, Cycling, Climbing, Swimming, Yoga, Dancing, Gym, Football, Basketball, Tennis, Volleyball) Sport Mode Entries: Up to 30 Sport Modes Entries Sport Mode Entries Sport Mode Entries Sport Mode