
ULTIMA VOGUE
USER MANUAL
boAt
ULTIMA VOGUE
Thank you for choosing the boAt Ultima Vogue as your fitness transformation companion.
Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.
Package Contains:
• boAt Ultima Vogue x1
• Wireless Charger x1
• User Manual x1
• Warranty Card x1
CHARGING THE WATCH
The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.
TURNING THE WATCH ON/OFF
To restart or turn the watch on/off, long-press the upper side button for 3-5 seconds.
You can wake up the screen by lifting your wrist.
CONNECTING TO THE APP
1. Download the boAt Crest app on your phone. Available on both App Store (iOS 12.0 and above) and Google Play Store (Android 7.0 and above)
OR
Scan (OR CODE) (Also available on the watch)
2. Connect the device with the boAt Crest app; ensure that the phone's Bluetooth, as well as the GPS functionalities, are turned on
3. Select Ultima Vogue on the app's home screen and click pair to connect.
4. Once connected, you will get an alert to connect with ULTIMAVOGUEBT, click pair if need to receive or make calls from the watch
5. To use all features of your Ultima Vogue seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.
6. Disable battery optimization
GET IT ON Google Play
Download on the App Store
Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.
SYNCING YOUR SMARTWATCH TO THE APP
Data Synchronization
• Open the app on your phone.
• Make sure your Ultima Vogue is connected to the app.
• Synchronization will start automatically once you enter the app interface.
Note:
Synchronise data at least once every day to avoid data loss in the watch.
NAVIGATING THROUGH THE FUNCTIONS
SHORT PRESS THE UPPER SIDE BUTTON FOR THE MAIN MENU
Call
Contacts
Add up to 10 contacts from boAt Crest app. You can select any contact to directly dial from the watch.
Call History
You can find recently received, missed, and outgoing call logs in the call history of the watch.
Dial
Use a dialer to dial any number from the watch.
Sports
Choose from multiple sports modes like Running, Treadmill, Walking, Cycling, Climbing, Basketball, Badminton, Football, Yoga, and Free Movement. You can also add or replace the activities according to your preference through the watch.
Tap on any sport mode to start the activity; click the go button, and the watch will start recording the duration of the activity. Short press the upper side button to pause or stop the activity. The activity will not be recorded if it is less than 3 mins.
Record
Sync your smartwatch to the app to get a detailed record of your activities.
Activities
Click on this to check your daily activity data like step count, calories, and distance covered.
Heart Rate Monitor
Wear the watch on your wrist, then click on the icon to start measurements. You can view the Current HR, Resting HR, and Average HR data on the watch. You can also view the data on the app.
Note: Measurements are for reference only and not for medical purposes.
SpO2 monitoring
Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.
Note: Measurements are for reference only and not for medical purposes
Stress monitoring
Click this option to start the stress monitoring. Make sure you wear your watch on your wrist properly to get accurate results.
Analysis of the measurement is
Relax: 1-29
Normal: 30-59
Medium: 60-79
High: 80-100
Note: Measurements are for reference only and not for medical purposes
Stopwatch
Click on this to start the stopwatch on your watch.
Notifications
You can check all the notifications from here
Sleep Monitor
Tap on the icon to review the sleep data of the previous night.
Once the asleep criteria are met, your smartwatch will start recording the sleep data.
It will be displayed on the app the next day.
Once you lie down and watch detects no movement for 30 minutes, it will start recording; and
will stop recording if it detects excessive movement.
You can check the data on the app only after the awake criteria is met.
You can also track sleep scores on the boAt Crest app.
Note
*For accurate sleep data recording, the asleep criteria have to be met which includes limited movement, wrist positions and angles, and more.
*The awake criteria will be met only after it records some noticeable movement
Timer
Tap on this to turn on the timer.
Find My Phone
Tap on this icon to find your phone. Once enabled, your phone will start ringing and vibrating. Tap again to stop it.
Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work.
Games
Tap on this to access the built-in game.
Calendar
Tap on the icon to access the calendar.
Voice Assistant
Tap on this to enable the voice assistant feature and give the command from the watch
Note: Make sure the watch is connected with the app.
Calculator
Tap on this to do the calculations.
Camera
Tap on the remote camera icon on your smartwatch to click a selfie from your phone.
Note: Turn the camera on from your phone to use this feature.
QR Code
Tap on this and scan the bar code from mobile to connect the smartwatch.
SETTING
Watch Faces
Tap on this icon to change the watch faces. You can also rotate the upper side button to change the watch faces.
GENERAL
Wrist Gesture
Tap on this to enable wake gesture
DND Mode
Tap on this icon for DND mode.
Password
Tap on this to set a password.
Always on Display
Click on this to enable always on display. You can also select from Digital or Analog
Note: The battery will drain quickly once this mode is enabled.
Bedside Clock
Click on this to enable the bedside clock.
Notification Settings
Tap on this to enable the notification. You can select from light up and vibration mode while receiving a notification.
Brightness
Tap on this to adjust the brightness.
Theme
Tap on this to select from 4 different themes. You can also change the theme by pressing the upper side button twice on the menu screen.
Power Off
Tap on this to switch your watch off.
Reboot
Tap on this to reboot the watch.
Factory Reset
Tap on this to reset watch data.
Note: All data will be erased if watch is reset
About
Shows the device details.
Swipe Up to access the shortcut menu
You can access Screen on, Wipe Gesture, Flashlight, DND, Brightness, Settings, Phone, Calculator, Vibration, Battery, Stopwatch, Password, Anytime mode and Calendar
Swipe down to access the notifications
You can check all the notifications from here.
Swipe left to access all data.
You can access heart rate, daily activity, stress, and SpO2. You can also customize the data according to your preferences.
Swipe right to access Widget Control
You can access the widget control feature from here.
Upper side button Functionality
You can change the watch faces by rotating the upper side button. Short press the button to enter the main menu and double press to change themes
Short press the bottom side for shortcut to Sports Mode
You can go to the sports mode by pressing the bottom side button.
PRODUCT PARAMETERS:
Model boAt Ultima Vogue
Screen type 1.96" AMOLED Display
Battery capacity 240mAh
Net weight 55.9g
Bluetooth version 5.3
Working temperature -10°C~ 45°C
Charging time up to 2 Hours
Working time up to 5 Days
Water Resistance IP67
Frequency band 2402-2480MHz
MAINTENANCE:
Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.
Do not wash the strap with a household cleaner. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.
For sports or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.
FAQ:
Search for the app to connect keeps failing.
1. Keep the boAt Crest app updated to the latest version.
2. Close all the programs on the watch --Hold and restart Bluetooth and GPS --> Connect again
3. Check and enable the notification functions of your phone and keep the phone and watch in close contact.
Note: Make sure your phone system meets Android 7.0 and above and iOS 10.0 and above
My Watch Ultima Vogue is receiving no alerts, texts, or phone calls.
Make sure smart reminders on the app are on and synced to Ultima Vogue
Also make sure your notification center of the phone is displaying messages. Only then will your smartwatch also display those notifications.
Make sure app is running in the background and battery optimization feature on the phone is disabled.
My Bluetooth keeps getting disconnected.
1. Make sure there is not more than 7m distance between Bluetooth on the phone and the watch.
2. There is no obstacle between the watch and the phone.
3. Make sure the app is running in the background.
Which functions of Ultima Vogue need Bluetooth to work?
Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud and custom watch faces and Bluetooth calling need Bluetooth connectivity to work.
Will it be okay to take a bath wearing Ultima Vogue?
The IP67 water resistance will only work under the following conditions:
(1) Maximum depth of water: 1 bm (2) Maximum time for exposure to water: 10 minutes
Do not wear the watch while bathing, showering, swimming, snorkeling, diving, water skiing and other wading or deep-water activities, with high-speed water flow.
SAFETY & PRODUCT INFORMATION
Battery
• Do not disassemble, bore or damage the battery.
• Do not disassemble the built in batteries of non-replaceable battery devices.
• Do not use sharp objects to remove the battery.