boAt

NIRVANA ION

Get ready to immerse yourself in musical bliss with your very own pair of boAt Nirvana Ion. Please consider this manual as your guiding map towards the shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual, also, you may refer to the same at times when you face any sort of difficulty in future.

PACKAGE CONTAINS:

- 1x Pair of TWS Earbuds
- 1x Charging Cable
- 1x Type-C Charging Cable
- 2x Pairs of Extra Earmuffs
- 1x User Manual
- 1x Warranty Card
- 1x Catalogue
- 1x FAQ Card

POWER ON (FIRST TIME USER):

Step 1: To switch the earbuds on,Insert Power On(simply open the lid of the charging case.)When earbuds are inside, Our IWP™ (Insta Wake N Pair) Technology enables the earbuds to power on automatically, get connected and enter the connection mode.
Step 2: Both the earbuds automatically pair with each other. The earbuds enter the Connection Mode, indicated slow breathing white LED on the master earbud.

CONNECTION MODE

Step 2: Turn on the Bluetooth functionality on your phone/media device & scan Step 4: Search for "Nirvana Ion" and pair accordingly.

Congratulations! Your earbuds are now connected successfully via Bluetooth.

Note:
• Pairing Mode: It lasts for 2 minutes, if the pairing time is crossed, then you will need to reconnect the earbuds and follow the above-mentioned procedure.
• Subsequent Usage: When/as per convenience, previously connected devices, once switched on, the earbuds automatically reconnect to the previously connected devices.

SINGLE EARBUD USAGE

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart / Manual Power On for switching on the desired earbud.
Step 2: The selected earbud automatically enters the connection mode indicated by slow white LED flashes.
Step 3: Turn on Bluetooth on your phone/media device and search for "Nirvana Ion" to connect.

Notes:
• To switch to stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud. Hence enabling Stereo usage.
• You cannot skip tracks or return to the previous tracks in Mono mode.

QUICK GUIDE ON FUNCTIONALITIES

1 Tap	Volume up: 3 taps on right earbuds increases volume by 25%
2 Taps	Volume Down: 3 taps on left earbuds decreases volume by 25%
4 Taps	Tap the right earbud's touch control 4 times to activate voice assistant
2 Seconds	Long touch left earbud's touch control for 2 seconds to change EQ mode
2 Seconds	Long touch right earbud's touch control for 2 seconds to switch on/off BEAST™ mode
20 Seconds	Long press the Reset Button on the case for up to 10 seconds for the factory reset

CHARGING THE EARBUDS

Step 1: Please insert the earbuds back inside the charging case in correct orientation and close the case lid.
Step 2: Once the earbuds are fully charged, the charging case automatically switches off to save power.

LED INDICATORS

Item	(Charging State)
Earbuds – Charging	LED stays white
Earbuds - Fully Charged	LED stays OFF

CASE LED INDICATION: EARBUDS REMAINING BATTERY

• When earbud's battery is <28%, the charging case LED shows red for 8 seconds whenever the earbuds are taken out or put into the case.
• When earbud's battery is 30%-70%, the charging case LED shows red for 8 seconds whenever the earbuds are taken out or put into the case.
• When earbud's battery is >70%, the charging case LED shows green for 5 seconds whenever the earbuds are taken out or put into the case.

Note:
• Before using the earbuds for the first time, it is recommended to fully charge the ear-buds. Also, please keep the lid of the charging case closed while charging.

CHARGING THE CASE

Step: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/ powerbank, etc.

REMAINING CASE BATTERY INDICATOR

(when earbuds are outside the case and the case lid gets opened)
• If the battery >28%, red LED flashes 3 times
• If the battery 30%-70%, white LED flashes 3 times
• If the battery >70%, green LED flashes 3 times
• If the battery is fully charged, the case LED stays solid green for 5 seconds

BASIC FUNCTIONS

• Voice Assistant: Tap the right earbud's touch control 4 times to activate default voice assistant
• Answer Call: Put on either earbud to answer an incoming call
• Hang Up Call: Double tap the CTC on either earbud
• Reject Call: Double tap the CTC on either earbud
• Play/Pause Music: Put on the earbuds to play a song, whereas remove them from your ears to pause one. The In-Ear Detection feature triggers a seamless play or pause.

OR

Single tap on either earbud's CTC to play or pause music
• Next Track: When playing music, double tap the right earbud's touch control to skip to the next song.
• Previous Track: When playing music, double tap the left earbud's touch control to return to the previous song.
• Volume Up: 3 taps on right earbuds increases volume by 25%
• Volume Down: 3 taps on left earbuds decreases volume by 25%

CRYSTAL BIONIC SOUND WITH DUAL EQS

Nirvana Ion comes equipped with Crystal Bionic Sound that stays activated by default.
You can choose either of the two EQ modes, i.e., Bass mode for bass-heavy sound or Basic mode for a more balanced auditory experience.
Simply long touch the left earbud's touch control for 2 seconds to change the EQ mode.

BEAST™ MODE

Long touch the right earbud's touch control for 2 seconds to switch to Low Latency mode also known as the BEAST™ Mode. Made for the Gamers - By Gamers, BEAST™ Mode reduces the latency significantly and improves the overall gaming experience. With BEAST™ mode, the earbuds activate low latency mode especially made for gaming.

To turn off the BEAST™ mode and return to Standard mode, long touch for 2 seconds again.

ENx™ TECH

Our ENx™ tech algorithm senses and the background noise so that you can be heard crystal clear via voice calls. One need not activate ENx™ as the mics are equipped with the same and activated by default.

Deliver your voice without interruptions anywhere - traffic, railway stations, airports, work space, literally anywhere!

SMART POWER OFF

Step 1: After usage, remove both the earbuds from your ears
Step 2: Place the earbuds back into the charging case in correct orientation and close the case lid
Step 3: The earbuds will automatically switch off (and enter charging mode)

FACTORY RESET

Perform the Factory Reset in case you face any difficulty while operating your Nirvana Ion

**NOTE: Before performing reset, clear "Nirvana Ion" from pairing device history by forgetting device.*

Step 1: Place the earbuds inside the case
Step 2: While the earbuds are inside the case, long press the Reset button located outside the case for 10 seconds, until the LED flashes 6 times on the earbuds as well as the case
Step 3: Close the case lid, wait for 5 seconds and then reopen it again.

Congratulations! Your Nirvana Ion has been Reset, now you may perform a fresh pairing procedure to establish connection.



WARNING

• Please follow the instructions to operate
• Please don't use the earbuds in extreme temperatures
• Please don't use the product near water
• Please keep the product away from heat sources, as the heat may damage it
• Don't pin the ports such as charger port, LED port, etc.
• It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life

Advisable: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first.

TROUBLESHOOTING

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection /even inside	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case and try using them again or perform the Factory Reset
If the Touch Controls don't seem to respond	After long usage, residual stains & perspiration can affect the touch control area, please use a clean cloth to wipe those areas softly.

SPECIFICATIONS

Headphone Type	TWS Earbuds
Bluetooth Version	V5.0
Water Resistance	IPX4
ENx™ Technology	Yes
Music Playtime	24H (Earbuds)- Approx 96H (Case) Total 120H at 40% volume
ASAP Charge	Yes
No. of Mics	2 per Earbud (4x)
BEAST Mode™	Yes
Low Latency	65ms
Mic™ Tech	Yes
Transmission Range	10m
Driver Size	10mm D
Bluetooth Profiles	HFP1.7(CT), A2DP1.3(SNK)AVRCP
Frequency	20Hz-20kHz
Battery	70mAh (Earbuds) 400mAh (Case)
Charging Time	1H Earbuds, 2.5H Case
Standby Time	200H
Weight	4.6g*2 Earbuds, 45.4g Case
Charging Interface	Type-C