

Tap on this to know weather forecasts.

Tap on this to view your notifications.

Tap on this to access Al Voice Assistance.

watch is connected with the app.

*Enable weather feature from the app first

WAVE SPIN VOICE

Thank you for choosing the boAt Spin Voice as your fitness transformation

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well



CHARGING THE WATCH

PACKAGE CONTAINS

USB magnetic charging cable :

boAt Wave Spin Voice x1

Warranty Card x1

The smartwatch must be charged before initial use. It takes 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



Note: Once your watch is at 10% battery, it will automatically switch to power-saving mode which will disable all functions.

TURNING THE WATCH ON/OFF

To turn the watch on/off, long-press the side button for 3-5 seconds You can wake the screen by lifting your wrist



CONNECTING TO THE APP

1. Download the boAt Wearables app on your phone. Available on both App Store (iOS 12.0 and above) & Google Play Store (Android 7.0 and above)

Scan [QR CODE] (Also available on the watch) 2. Connect the device with the boAt Wearables app

3. Select Spin Voice on the home screen of the app and click pair to connect.

- 4. Click on "pair" when you get a prompt to connect with SPINVOICEBT. This is required if you want to attend calls on your watch. 5. Alternatively, you can go to your phone's setting and pair SPINVOICEBT manually.
- 4. To use all features of your Wave Spin Voice seamlessly, tap on 'yes' to the 'connection' and
- 'grant access' system prompt.
- 5. Turn your phone's Bluetooth and GPS on. 6. Disable battery optimization



Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times. iPhones will not prompt any information unless you complete Bluetooth pairing with Wave

SYNCING YOUR SMARTWATCH TO THE APP Data Synchronization

- · Open the app on your phone.
- Make sure your Wave Spin Voice is connected to the app
- Synchronization will start automatically once you enter the app interface.

Synchronize data at least once a day to avoid data loss in the watch.

Tap on this to access guided breathing mode to relax

Tap on this to access Timer.



Voice to play music from your phone.

Tap on this to access stop watch.

Tap on the remote music player icon on your Wave Spin

Note: Some apps with different protocols might not work

Tap on this to access alarms



Tap on this to access Display (watch faces, brightness and auto sleep), DND, Ring/Vibrate, Power Saving Mode, Phone Call, Phone Reset, System, About



Tap this to turn your watch into a flashlight.

Tap on this to vibrate your phone when you're looking for it. Note: Your phone and watch must be connected via Bluetooth for this feature to work.



Tap this to access built-in games. You can play 2048, thunder battleship and young bird.



SWIPE UP RIGHT TO ACCESS SPLIT SCREEN FOR RECENTLY USED APPS



SWIPE LEFT TO ACCESS ALL DATA

You can access activity tracker, phone call, heart rate, spO2, sleep, music control, relax mode, games. You can add more options from the '+' sign as well.

SWIPE DOWN FOR SHORTCUT MENU You can access DND, Brightness, Timer, Camera, Flashlight &



PRODUCT PARAMETERS

Model	boAt Wave Spin Voice	
Screen type	1.85" Big Display	
Battery capacity	210 mAh	
Net weight	47.5g	
Bluetooth version	5.1 + BT 3.0	
Working temperature	-10°C-50°C	
Charging time	2 hours	
Working time	up to 2 days on with BT calling, up to 7 days on normal mode	
Water Resistance	IP68	

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may et stuck on the other end of the product.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

Search for the app to connect keeps failing

2. Close all the programs on the watch ➤ Stop and restart Bluetooth and GPS➤ Connect again

Note: Make sure your phone system meets Android 7.0 and above and iOS 12.0 and above

NAVIGATING THROUGH THE FUNCTIONS

Tap on this to access Favorite contacts, Call History & Dialer from he

Add your contacts on the phonebook from the boAt Wearables app.

SWIPE UP FOR MAIN MENU

Tap on this to manage and track your activities

Activity Tracker

Phone Call

You can add up to 10

Model	boAt Wave Spin Voice	
Screen type	1.85" Big Display	
Battery capacity	210 mAh	
Net weight	47.5g	
Bluetooth version	5.1 + BT 3.0	
Working temperature	-10°C-50°C	
Charging time	2 hours	
Working time	up to 2 days on with BT calling,	
	up to 7 days on normal mode	
Water Resistance	IP68	

MAINTENANCE

Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

Keep the boAt Wearables app updated to the latest version

Do not disassemble, bore or damage the battery. 3. Check and enable notification functions of your phone and keep the phone and watch in Do not disassemble the built in batteries of non-replaceable battery devices. Do not use sharp objects to remove the battery.

You can acces BT calling feature from the shortcut menu

(slide right from the home screen) or the main menu. To use the BT Calling feature, open the boAt Wearables app and pair the watch.

Once paired you will get the pop up on the app home screen to connect with Phone's Bluetooth.

Click on "pair" to connect with phone's Bluetooth Alternatively, you can go to phone's Bluetooth settings and

pair "SPINVOICEBT" to start the calling feature on your

*Note: Enable call alerts from the setting to get calls on the watch Up to 10 contacts can be saved in the phonebook

Call history will show the latest call details. Use a dialer to dial any number

Note: To optimize the battery performance, BT calling will be on standby mode if not in use.

Tap on the icon to review the sleep data of the previous night.

Once the asleep criteria is met, your Wave Spin Voice will start

recording from 8 pm at night to 10 am in the morning the next day. Once you lie down and watch detects no movement for 30 minutes, It

will start recording, and will stop recording if it detects excessive You can check the data on the app only after the awake criteria is met.

smartwatch also display those notifications.

My Bluetooth keeps getting disconnected

3. Make sure the app is running in background.

You can also track sleep scores on the boAt Wearables app

Make sure smart reminders on the app are on and synced to the Wave Spin Voice.

Make sure Spin Voice_BT is connected from the phone to receive calls on the watch

Make sure app is running in the background and battery optimization feature on the phone is

Call & Text Notifications, music control, camera control, weather forecast, cloud and custom

1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 10 minutes

1. Make sure there is not more than 7m distance between Bluetooth on the phone and the watch.

My Wave Spin Voice is receiving no alerts, texts, or phone calls

2. There is no obstacle in between the watch and the phone.

Will it be okay to take a bath wearing the Wave Spin Voice?

How to use Bluetooth calling feature on the watch?

3. Click on "pair" to connect with phone's Bluetooth

SAFETY & PRODUCT INFORMATION

Open App-> devices -> device info-> contacts

calling feature on your watch

the number from the dialer

How to add contacts in the watch?

other wading or deep-water activities with high-speed water flow.

Open the boAt Wearables app, pair the watch with the app first.

Which functions of the Wave Spin Voice need Bluetooth to work?

watch faces and Bluetooth calling need Bluetooth connectivity to work.

The IP68 water resistance will only work under the following conditions:

efore using the heart rate monitor of the watch ne optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking ht sources, please consult your physician before wearing this device.

The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is

top using the watch and consult the doctor.

Vater Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and

her corrosive liquid. The damage or defects caused by misuse or improper use are not covered w the warranty

4. Alternatively, you can go to phone's Bluetooth settings and pair "Spin Voice_BT" to start the

eep your arm still while measuring data for accurate measurement.


We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.


You can select up to 10 contacts from your phonebook which will be synced with the watch.

old electrical appliances must not be disposed of together with the residual waste, but have be disposed of separately. The disposal at the communal collecting point via private rsons is for free. The owner of old appliances is responsible to bring the appliances to ese collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances.











Heart Rate Monitor

medical purposes.

angles, and more.





end the exercise. You can also access Sports Mode by swiping right on your home

Wear the watch on your wrist, then click on the icon to start

Wear the watch on your wrist, then click on the icon to start

be met which includes limited movement, wrist positions and

Tap on the sports icon to choose from 100+ sports modes: Run.

measurements. You can also view the data on the app.

measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for

Notes: All records will be available on the app if you keep it



he device tracks your daily activities through sensors. This data is intended to tell you about your laily activities such as steps, sleep, distance, heart rate and calories, but may not be completely

lesigned for fitness and not for medical purposes. They are not applicable to the diagnosis,

onitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood essure data is for reference only. We're not responsible for any deviation in data. void wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in ontact with the watch. If symptoms such as redness or swelling appear on your skin, immediately

nc data everyday days to avoid data loss. The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and

ports modes support up to 6 hours of exercise at a time.

2. Once paired you will get the pop-up on the app home screen to connect with Phone's Bluetooth

Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.

claimer: This product is an electronic monitoring product and is not intended as a medical reference.

Once you initiate the call from the watch, you can select caller name from the list or directly dial ISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.