

PRIMIA ACE

Thank you for choosing the boAt Primia Ace as your fitness transformation

functioning of your smartwatch. Please read it use as well.




Allow this manual to guide you through the thoroughly before using it for a smooth sail. You may refer to these instructions for later

PACKAGE CONTAINS:

oAt Primia Ace x1 User Manual x1 Warranty Card x1

CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged. connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



TURNING THE WATCH ON/OFF

To restart or turn the watch on/off, long-press the side button for 3-5 seconds. You can wake up the screen by lifting your wrist.



CONNECTING TO THE APP


1. Download the boAt Crest app on your phone. Available on both App Store (IOS 12.0 and above) and Google Play Store (Android 7.0 and above)


Scan [QR CODE] (Also available on the watch)

2. Connect the device with the boAt Crest app; ensure that the phone's Bluetooth as well as the GPS functionalities are turned on 3. Select Primia Ace on the home screen of the app and

click pair to connect. 4. Once connected, you will get an alert to connect with PRIMIA ACE, click pair if need to receive or make calls from the watch

4. To use all features of your Primia Ace seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.





SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization

- Open the app on your phone.
- Make sure your Primia Ace is connected to the app Synchronization will start automatically once you enter the app interface.

Synchronize data at least once a day to avoid data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS

SWIPE LEFT FOR MAIN MENU

Activity Tracker

Click on this to check your daily activity data like step count, calorie, active minutes, no. of times you were standing, distance covered.



7 8 9 :

To use the BT Calling feature, open the boAt Crest app and pair the

Alternatively, you can enable watch BT and go to phone's Bluetooth settings and pair "PRIMIA ACE" to start the calling feature on your

Call history will show the latest call details. User can have 20 contact numbers in the watch itself

Click on "pair" to connect with the phone's Bluetooth.

Spo2 Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app. Note: Measurements are for reference only and not for medical



Choose from multiple sports modes like outdoor run, outdoor walk, indoor walk, indoor walk, long jump, indoor run, strength training, football, basketball, table tennis, badminton, indoor cycle, elliptical, yoga, cricket,

mountaineering, golf. Tap on any sport mode to start the activity, you can pre-set your goal as well for each activity. Press the side button to pause or stop the activity. If the activity is less than 3 mins, it will not be recorded.

Note: Sync your smartwatch to the app to get the detailed analysis

Heart Rate Monitor Wear the watch on your wrist, then click on the icon to start measure-

ments. You can also view the data on the app. Note: Measurements are for reference only and not for medical

Tap on the icon to review the sleep data of the previous night.

Watch is default to record user's sleep of 24 hours (the whole day). If app can set the monitoring duration, it will update accordingly Once you lie down and watch detects Less/No movement and meets the sleep patterns, it will start recording, and will stop recording if it detects excessive movement You can check the data on the app only after the awake criteria is met. You can also track sleep scores on the boAt Crest app.

*For accurate sleep data recording, the asleep criteria have to be met which includes limited movement, wrist positions and angles, and more. *The awake criteria will be met only after it records some noticeable movement

boAt Primia Ace

1.43" AMOLED Display

up to 2 days on with BT calling,

up to 10 days on normal mode

Workout records

PRODUCT PARAMETERS

Screen type

Net weight

Battery capacity

Bluetooth version

Charging time

Working time

Water Resistance

Frequency band

Working temperature

You can view the records of your workouts here



Tap on this to set an alarm on your watch.

Analysis of the measurement is

Normal: 30-59

Medium: 60-79

Event reminders

alerts on the watch

High: 80-100

Click on the breath training icon to regulate your breathing with the instructions given to relax.

Click this option to start the stress monitoring. Make sure you wear

your watch on your wrist properly to get the accurate results.

Note: Measurements are for reference only and not for medical

You can create event reminders from the app and get the

My Watch Primia Ace is receiving no alerts, texts, or phone calls

2. There is no obstacle in between the watch and the phone.

Which functions of the Primia Ace need Bluetooth to work?

Will it be okay to take a bath wearing the Primia Ace?

SAFETY & PRODUCT INFORMATION

Do not use sharp objects to remove the battery.

martwatch also display those notifications

My Bluetooth keeps getting disconnected

5. Make sure the app is running in background

Make sure smart reminders on the app are on and synced to the Primia Ace.

ilso make sure your notification center of the phone is displaying messages. Only then will your

Make sure app is running in the background and battery optimization feature on the phone is

. Make sure there is not more than 7m distance between Bluetooth on the phone and the watch.

Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud

The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and

and custom watch faces and Bluetooth calling need Bluetooth connectivity to work.

The IP68 water resistance will only work under the following conditions:

other wading or deep-water activities with high-speed water flow.



Women Health

Connect with the boAt crest app to get daily weather updates on the watch



Enable and set the details on the boAt crest app and get the

alerts of your period and ovulation dates on the watch

Frequent Contacts

Connect with the bluetooth and get all the frequently contacted numbers and contact on the watch



You can find recently received, missed and outgoing call



Note: Some apps with different protocols might not work

a photo from your phone *Note: Turn the camera on from your phone to use this

Tap on the remote music control icon on your watch to play

Tap again to stop it





Tap on this to turn your dial into a flashlight.



Click on this to start the stopwatch on your watch



Watch Faces

Tap on this icon to change your watch face.



Tap on this to adjust the brightness, set the screen on time, AOD and enable wake gesture. *Note: The battery will last up to 2 days once the AOD is



Tap on this to adjust vibration levels



Click on calendar to check the date, day and month



Do Not Disturb

Tap on this to disable all notifications except alarms.



GENERAL

Tap on this to restart your watch



Power off Tap on this to switch your watch off.



Factory Reset Tap on this to reset watch data.

*Note: All data will be erased if watch is reset



Shows the device details



SWIPE DOWN FOR SHORTCUT MENU You can access DND, Brightness, power saving mode, wake

gesture, flashlight, Settings, etc.



weather, music player from here.

SWIPE UP TO ACCESS ALL DATA

You can access daily activity, heart rate monitor, stress, sleep,



You can check all the notifications from here. Click delete icon to delete all the notification.

You can awake the screen and can be uses as a back button.

Click for 3-4 seconds to turn on/off the smart watch.



Regularly clean your wrist and the strap of the smartwatch, especially after sweating

during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product. Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

V5.1

0-45°C

Less than 2H

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

2402MHz~2480MHz

Search for the app to connect keeps failing

1. Keep the boAt Crest app updated to the latest version

2. Close all the programs on the watch -> Stop and restart Bluetooth and GPS -> connect again. 3. Check and enable notification functions of your phone and keep the phone and watch in close contact.

The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to

completely accurate. Note: Make sure your phone system meets Android 7.0 and above and iOS 12.0 and above




Sync data everyday days to avoid data loss.

by the warranty.

Keep your arm still while measuring data for accurate measurement.

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.



Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Do not disassemble, bore or damage the battery. Do not disassemble the built in batteries of non-replaceable battery devices.

HEALTH WARNING

doctor before using the heart rate monitor of the watch.

The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be

The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis,

stop using the watch and consult the doctor.

THINGS TO KEEP IN MIND

other corrosive liquid. The damage or defects caused by misuse or improper use are not covered

Sports modes support up to 6 hours of exercise at a time.

· Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.

We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances.

If you are wearing a pacemaker or other implanted electronic devices, please consult your

blinking light sources, please consult your physician before wearing this device.