

ULTIMA CALL


Thank you for choosing the boAt Ultima Call as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.



CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using 5V/2A adapter.





CONNECTING TO THE APP

1. Download the boAt Crest app on your phone.

Available on both App Store (iOS 12.0 and above) and Google Pla Store (Android 7.0 and above)

Scan [QR CODE] (Also available on the watch)

2. Connect the device with the boAt Crest app: ensure that the phone's Bluetooth as well as the GPS functionalities are

3. Select Ultima Call on the home screen of the app and click pair to connect.

4. Once connected, you will get an alert to connect with ULTIMACALLBT, click pair if need to receive or make calls from the watch

5. To use all features of your Ultima Call seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.

6. Disable battery optimization



Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.

SYNCING YOUR SMARTWATCH TO THE APP

Open the app on your phone

connect with Phone's Bluetooth

Click on "pair" to connect with phone's Bluetooth.

Up to 10 contacts can be saved in the phonebook.

Call history will show the latest call details.

Synchronization will start automatically once you enter the app interface.

Synchronize data at least once a day to avoid data loss in the watch. NAVIGATING THROUGH THE FUNCTIONS

Click on this icon and you can access Dialpad, Call History, and

To use the BT Calling feature, open the boAt Crest app and pair

Alternatively, you can go to phone's Bluetooth settings and pair "ULTIMACALLBT" to start the calling feature on your watch.

SHORT PRESS THE SIDE BUTTON FOR MAIN MENU

Sync your smartwatch to the app to get the detailed record of the activities

Choose from multiple sports mode like walking, treadmill,

dancing, indoor cycling, bowling, table tennis, Kabaddi,

running, badminton, football Basketball, tennis, yoga, workout,

Tap on any sport mode to start the activity. Press the side

button to pause or stop the activity. If the activity is less than



Heart Rate Monitor

skipping, cricket.

Activity Record

3 mins, it will not be recorded.

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

*Note: Measurements are for reference only and not for medical



SpO2 monitoring Wear the watch on your wrist, then click on the icon to start

Breathe exercises

measurements. You can also view the data on the app.

Tap on the icon to review the sleep data of the previous night.

from 8 pm at night to 10 am in the morning the next day.

You can also track sleep scores on the boAt Crest app.

Once the asleep criteria are met, your smartwatch will start recording

Once you lie down and watch detects no movement for 30 minutes, it will

start recording, and will stop recording if it detects excessive movement.

You can check the data on the app only after the awake criteria is met.

Note: "For accurate sleep data recording, the sleep criteria have to be met

Click on the breath exercises icon to regulate your breathing by doing breathing exercise. You can set the time and level of exercise.

which includes limited movement, wrist positions and angles, and more.

*The awake criteria will be met only after it records some noticeable

Note: Measurements are for reference only and not for medical



Stopwatch

Notification

Click on this to start the stopwatch on your watch

You can check all the notifications from here

Tap on this to set an alarm on your watch.



Tap on this to turn your dial into a flashlight.




Tap on the remote camera icon on your smartwatch to click

a photo from your phone.



music from your phone.



Tap on this icon to find your phone. Once enabled, your phone will start ringing and vibrating. Tap again to stop it.

Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work.



Wake Gesture



Tap on this to adjust vibration levels

Watch Faces Tap on this icon to change your watch face.



Tap on this and adjust the screen sleep time



Tap on this to choose the ringtone and put the watch on



Tap on this to enable wake gesture





Screen Sleep

Tap on this and scan the bar code from mobile to connect

Tap on this to disable all notifications except alarms



Shows the device details

Shows the device regulatory details



Al voice Assistant

Tap on this to enable "Ok google" and "siri" on the app and give the command from the watch.



Swipe down for shortcut menu You can access DND, Brightness, Alarm, Find my phone

Note: Make sure the watch is connected with the app

Swipe up to access the sports score You can check the live scores from here.

Swipe left or right to access all data

You can access steps, SpO2 monitoring, heart rate monitor, sleep and notifications from here

PRODUCT PARAMETERS

Use a dialer to dial any number

Model	boAt Ultima Call
Screen type	1.83" HD Display
Battery capacity	220mAh
Net weight	55g
Bluetooth version	BLE5.0+ BT3.0
Working temperature	-20°C-60°C
Charging time	1h
Working time	up to 7 days in normal mode, up to 2 days on BT calling
Water Resistance	IP68
Frequency band	2402-2480Mhz

Regularly clean your wrist and the strap of the smartwatch, especially after sweating

during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product. Do not wash the strap with a household cleanser. Please use soap less detergent, rinse

thoroughly and wipe with a piece of soft towel or napkin.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

Search for the app to connect keeps failing

2. Close all the programs on the watch→Stop and restart Bluetooth and GPS→Connect again 3. Check and enable notification functions of your phone and keep the phone and watch in

Note: Make sure your phone system meets Android 7.0 and above and iOS 9.0 and above. My Watch Ultima Call is receiving no alerts, texts, or phone calls Make sure smart reminders on the app are on and synced to the Ultima Call.

your smartwatch also display those notifications Make sure app is running in the background and battery optimization feature on the phone

Make sure there is not more than 7m distance between Bluetooth on the phone & the watch There is no obstacle in between the watch and the phone. 3. Make sure the app is running in background

Which functions of the Ultima Call need Bluetooth to work? Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud and custom watch faces and need Bluetooth connectivity to work.

Will it be okay to take a bath wearing the Ultima Call? The IP68 water resistance will only work under the following conditions:

My Bluetooth keeps getting disconnected

(1) Maximum depth of water 1.5m (2) Maximum time for exposure to water 10 minutes The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing

and other wading or deep-water activities with high-speed water flow.

SAFETY & PRODUCT INFORMATION

· Do not disassemble, bore or damage the battery. • Do not disassemble the built in batteries of non-replaceable battery devices.

· Do not use sharp objects to remove the battery.

Health Warning

· If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.

• The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device. . The device tracks your daily activities through sensors. This data is intended to tell you about

your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

. The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis. monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood pressure data is for reference only. We're not responsible for any deviation in data. . Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin,

Things to keep in mind

Sync data everyday days to avoid data loss.

· Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents & other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.

Sports modes support up to 6 hours of exercise at a time.

· Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch

· Keep your arm still while measuring data for accurate measurement.

immediately stop using the watch and consult the doctor.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances







