

**pTron**



***Tangentbeat Wireless Neckband***

**Instruction Manual**

## Button Operations:



- 1. Power On:** Press & hold the Power/ Call Answer Button for 3sec to turn On the headset. You will hear the voice prompt "Power On".
- 2. Power Off:** Press & hold the Power/Call Answer Button for 5sec followed by Red light flashing for 3 times to turn Off the headset. You will also hear the voice prompt "Power Off"
- 3. Next Song:** Long press the "+" button
- 4. Previous Song:** Long press "-" button
- 5. Play/Pause Music:** Click once the Power/Call Answer button

6. **Volume Increase:** Short Press the volume “+” button in regular interval
7. **Volume Decrease:** Short Press the Volume “-” button in regular interval
8. **Call Receive/Hangup:** Click once the Power/Call Answer button
9. **Reject Call:** Press & hold the Power/- Call Answer button for 2sec
10. **Call Back/Redial:** Double click the Power/Call Answer button
11. **Voice Assistant:** Long press Power On/Call Answer button for 2sec  
(for 3-Button Remote Control)  
Press Mic button Once  
(for 4-Button Remote Control)

## **Bluetooth Connection :**

1. Turn ON the pTron Bluetooth Headset & wait until it flashes Blue & Red Light alternatively. That means the Bluetooth Headset in “pairing Mode”.
2. Turn On the Bluetooth of your phone or device.
3. Search for “pTron BT” in your available Bluetooth device list and click to connect.

4. After successful connection you will hear the voice prompt “pTron BT is Connected”.

### **Re-connection:**

After turned ON, headset will reconnect to the last paired device. If there's no prior connection history, or if it fails to reconnect to any device, the headset will enter standby mode and wait for connection.

### **Connection Lost:**

When your phone turns off Bluetooth feature or is out of wireless range, the headset will enter into standby mode. If connection is not restored within 5 minutes, the unit will Turn OFF automatically.

### **Auto-power Off:**

The device will become automatic shut down if there is no connection for 5 minutes or the headset's battery gets discharged. Once the battery level of headset becomes low up-to 10% it will prompt as “Low Battery” and the red light will flash in every 5sec.

**Note:** Keep the headset on charging when you hear “Please Charge” voice prompt

## **Troubleshooting:**

- 1. Bluetooth Not Searching:** If your phone doesn't find the "pTron BT" in your device then make sure that it must be nearer to the device at 1-Meter of range. And check it must be flashing Blue & Red light alternatively and if it is flashing only Blue light for once in regular intervals that means unit is already connected with some other device. So first un-pair it from old device & make new device.
- 2. Auto-disconnection:** Charge the headset 100% & reconnect your device after restarting your phone or the headset is in standby mode for more than 5 minutes.
- 3. Device Connected but No Music/Calls:** Check the settings of your Bluetooth connection and make sure that Call & Music function must be activated.
- 4. Support/Compatibility:** "pTron BT" is compatible with all iOS/Android phones & all other devices with Bluetooth function.



5. Neck Fitment: "pTron BT" Bluetooth headset is completely flexible and can be twisted or bent at any angles to fit into your neck.

6. Water Resistant: "pTron BT" is IPX4 rating water resistant/sweat-proof & dust proof so it can withstand against light water drizzle or during gym/exercise.

**Caution:** Using incompatible USB cable or high voltage chargers can damage the product & void the product warranty. We strongly recommend using DC5V-1A chargers & the USB cable included in the package.

## **Disclaimer:**

The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.