

■ **CAUTIONS:**

1. This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. The fan should be installed at 2.3m above the ground.
4. When the ventilating fan is connected with the power circuit, all-polarity switch with at least 3mm contact gap must be in the charging line. Green and Yellow color wire of power supply should be earthed.
5. Precautions must be taken to avoid the back-flow of gases into the room from the open flue of gas or other open-fire appliance.
6. The fan is intended for mounting in outside windows.
7. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
8. Ensure that the fan is switched off from from the supply mains before removing the guard.
9. Before installation, should breathe some gumwater into the gap, which between the fan body and panel.



GM ELEKTRA PVT. LTD.

303, Shalimar Morya Park, New Link Rd, Andheri (W), Mumbai- 400053, Maharashtra, India.
Customer Care No.:080 6905 6805 | Email: care@gmelektra.com
WhatsApp No.: 99203 54444 (Send 'Hi' to connect with us instantly)


www.gmmodular.com

Instruction/ Installation Manual

Fresho
VENTILATING FAN



Delivering
Fresh Air




■ **SPECIFICATIONS**

Model	Size (in/mm)	Volt (V)	Freq (Hz)	Input Power (W)	Air Volume (m ³ /min)	Noise dB(A)
Fresho (100)	4/100	240	50	12	1.08	44
Fresho (150)	6/150	240	50	13	2.5	44

■ **Table 1**

DIMENSION (mm)



Model	A	B	C	D	Installation Space \varnothing a mm	Applicable Area m ²
Fresho (100)	150	30	50	98	99	4~6
Fresho (150)	200	32	60	146	147	7~10

■ **MAINTENANCE:**

1. Before beginning any maintenance, be sure to remove the power cord from the power source.
2. Never use petrol, benzene, thinner or any other chemicals for cleaning the fan.
3. The fan should be installed at 2.3m above the ground.
4. Precautions must be taken to avoid the backflow of gases into the room from the open flue of gas or other open-fire appliances.
5. The fan is intended for mounting in outside windows.
6. Connect the power cord. When power comes from socket, the plug must accord with IEC-335. When the power cord is connected with charging line directly, all-polarity switch with contact gap of 3mm at least, must be installed in the charging line.

