

MOZA NANO SE Selfie Stick Gimbal User Manual

Home » Moza » MOZA NANO SE Selfie Stick Gimbal User Manual







Contents

- 1 Instructions
- **2 Power Button**
- 3 Mobile Phone Bluetooth

Connection

- 4 Download the App
- **5 Protect The Environment**
- **6 FCC Warning**
- 7 Documents / Resources
- **8 Related Posts**

Instructions

While the gimbal is off, slide the mobile phone into the center of the phone holder according to the sticker and make sure the phone is well balanced.



Power Button



Long press for 3s: Power On/Off

Short press for 0.5s: Sleep Mode/Wake Up



M Button (Top Button)

Click: Switch between horizontal and vertical shooting modes

Double click: Switch between Follow and Lock mode Triple-click: Switch between front and rear camera

Button (Left Button)

Click: Switch shooting templates in Magic Video

Hold: Zoom out

Double click: Automatically zoom out



Button (Right Button)

Click: Switch shooting templates in Magic Video

Hold: Zoom in

Double click: Automatically zoom in



Record Button (Down Button)

Click: Shooting/Recording

Double click: Switch between Shooting and Recording

Mobile Phone Bluetooth Connection

Search for the device Hi-NanoSE-12BB4004XXXX on your mobile phone Bluetooth, click pairing, after the connection is completed, you can control your phone camera via the gimbal.

Technical Support: support@gudsen.com



Follow us

Download the App

Please scan the QR code to download the MOZA Genie App prior using the MOZA NANO SE.



Protect The Environment

Paperless complete manual available online

To reduce the resources consumption and protect the environment, the completed user manual will not be provided on paper. You can download it from the official website or check it on the MOZA App.



FCC Warning

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources



MOZA NANO SE Selfie Stick Gimbal [pdf] User Manual

NANOSE, 2AMJR-NANOSE, 2AMJRNANOSE, NANO, 2AMJR-NANO, 2AMJRNANO, NANO SE Selfie Stick Gimbal, Selfie Stick Gimbal

Manuals+, home

privacy