

ATTENTION! Your Rico home appliance has been manufactured with utmost care and under strict quality control. If, for any reason, you are not satisfied, please contact your local dealer or the Rico Customer Relations Department for immediate action on your query / problem at :

Customer Relations Department

Rico Appliances Pvt. Ltd.

8th Floor, Sapphire Bldg., S.V. Road, Khar (W), Mumbai - 400 052.

Tel.: (91-22) 2410 2926 Fax.: (91-22) 2410 2927

Email.: service@rico.in

Website: www.rico.in

Please ensure that the Warranty Card is filled in by the Dealer at the time of purchase. Detach the card below and mail it within 7 days of the purchase to Rico.

POST CARD



RICO APPLIANCES PVT. LTD.

8th Floor, Sapphire Bldg.,
S.V. Road, Khar (W),
Mumbai - 400 052.
INDIA

**HOME APPLIANCES WARRANTY CARD
WARRANTY CONDITIONS & SERVICE PROCEDURE**

Please preserve this warranty card and the cash memo and ensure that it is duly stamped (with the date stamped) and signed by the dealer. A warranty card or cash memo which is not stamped and signed by the dealer will be treated as invalid.

Kindly ensure you post the half portion to Rico Head office or update your details on our website www.ricoappliances.com.

Conditions of the Warranty:-

Your Rico product is warranted against manufacturing defects for 12 months from the date of purchase. The product is warranted against manufacturing defects only. This product is designed for domestic use only.

This warranty does not apply to

- Normal Wear and tear of parts or surface coating
- Faults which may be due to wrong usage, faulty handling, damage in transit, usage of spurious parts, neglect or accident are not covered by this warranty
- Damages resulting from accidents, mishandling or negligence on the part of the customer and fluctuation in supply voltage.
- Surface Coating, body aesthetics, plastic parts, neon lamps, bakelite parts, rubber/nylon parts, push buttons & bulb.
- Damages resulting due to usage of power supply other than specified 220/230 Volts, AC, 50 Hz. eg: inverters generators etc.
- For humming noise generated due to usage of electronic fan regulators of any make.

Should your Rico product become un-operational during the warranty period, Kindly contact your nearest authorized Rico Dealer / Service Centre. (List is available on www.ricoappliances.com)

Subject to the above - The defective part will be repaired / replaced free of charge for labour or materials, at our discretion & option, provide that:

- The unit is returned at your cost to our Authorized Service Centre along with the stamped and signed Cash Memo and Warranty Card.
- The unit is installed, used and maintained strictly in accordance with the instructions provided.
- The unit is not opened or tampered with by anyone except our Authorized Service Centre or technician.

CONSEQUENTIAL DAMAGE

Liability for consequential loss or damages is neither accepted nor is it implied. The warranty extended herein is in lieu of all implied conditions and warranties under the law and is confined to the repair or replacement of defective parts and does not cover any consequential or resulting liability, damage or loss. The warranty in no case shall extend to payment of any monetary consideration whatsoever or the replacement or return of the products as whole, liability for consequential loss or damage is neither accepted nor is implied.

SERVICE AND REPAIRS

Please get the product repaired only from our authorised service centre.

This warranty is confined to the repair or replacement of defective parts. Any expenses incurred on collecting and returning the product to the customer and/or on the service personnel who will visit the customer, such as to and fro conveyance, incidentals etc., shall be borne by the customer.

Please note that this warranty is issued subject to the jurisdiction of the competent courts in Mumbai INDIA only.

The company's liability under this warranty shall in no event, and under no circumstances, exceed the price paid by the customer.

In the event of repairs of any parts of the water filter, this warranty will there after continue and remain in force only for the unexpired period of the warranty.

To avoid unnecessary repairs, please study the instruction manual carefully before operation.

Rico®

Immersion Rod-Water Heater

SHOCK PROOF



Instruction Manual
Cum Warranty Card

POWERFUL • EFFICIENT • LONG LASTING

Dear Customer,

Thank you for selecting Rico.

You have just bought yourself one of the finest Product help in the form of Rico Immersion Rod-Water Heater.

Your Rico Immersion Rod-Water Heater has been manufactured for you under the most stringent quality control procedures.

You are assured of the best quality, performance and after sales service. If, however, for any reason, you feel something is lacking, we are always there at your service.

A list of Rico service centres is also enclosed seperately. If you require any further assistance, please do not hesitate to contact us, for immediate action on your query/ problem, at:

CUSTOMER RELATIONS DEPARTMENT

Rico Appliances Pvt. Ltd.,

Sapphire Bldg, 8th floor, S.V. Road, Khar (W), Mumbai-400 052.

Tel : (91-22) 24102926, Fax : (91-22) 24102927

Email : service@rico.in

Website : www.rico.in

Thank you once again for buying Rico.

C. Thakur

Chairman,

Rico APPLIANCES PVT. LTD.


Features:

1. Elegant looks.
2. Shock Proof.
3. Sealed plastic body with epoxy filling for enhanced safety.
4. Superior copper element to ensure heat conduction and rust prevention.
5. Water level indicator

Operating Instructions:

1. The heater is provided with 3 core wire & a plug.
2. It is recommended that the heater should be with a three pin socket with proper earthing.
3. First fill the water in bucket then put the heater in bucket then connect the plug to 3 pin plug to socket switch ON the button then water will start heating , you can observed bubbles in water.
4. The level of the water should be in between the indicated maximum and minimum marks and care should be taken that the handle is not immersed in water.
5. The current should be switched off before the heater is removed from water.
6. The heater should be removed from the water only a minute or two after the current is switched off.
7. The heater is meant for water heating only and it is not recommended for use in other liquid such as milk, as it will have corroding effect on the heater surface.
8. The heater should be immersed at least up to the minimum marking otherwise the element will fuse due to dry heating.
9. "While using the immersion heater with plastic-ware please ensure the immersion rod should not touch the plastic surface – that can damage the heater as well as plastic-ware ”.
10. If you are using plastic bucket then , put the immersion heater at the centre of the bucket and hang the heater to wooden stick.

Precaution : Do not put your hand in bucket when immersion water heater is ' ON' condition.



12 Months Warranty

Rico®

HOME APPLIANCES WARRANTY CARD

(To be retained by the purchaser)

Important : Before mailing the Warranty Card, please read all the terms and conditions of the warranty.

Rico Product : RICO IMMERSION ROD-WATER HEATER

Serial No. : _____ Date of Purchase : _____

Dealer's Name & Address :

Please fill in the following post card, cut along the dotted line, and mail to Rico within 7 days of purchase.

(This portion is to be mailed to Rico)

You can also register Warranty Card online at www.ricoappliances.com

Rico Product : RICO IMMERSION ROD-WATER HEATER

Serial No. : _____ Date of Purchase : _____

Dealer's Name _____
Address & _____
Rubber Stamp : _____

Customer Name _____

Address: _____

City: _____ **Pin Code:** _____ **State/Country:** _____

E-mail: _____

Tel./Mobile : _____

(Please make sure your Dealer completes this card at the time of purchase)

12 Months Warranty