

# ColorFit Thrill

Please refer to this manual before using the product

## TABLE OF CONTENT

- What's in the box and Watch Overview 01
- Using and Charging the watch 02
- Messages 03
- Turn the watch On and Off 04
- Watch navigation
- Rotating Crown
- Home Screen Navigation
- Set-up 05
- App set-up
- Pair the watch
- Watch Features 06-09
- Settings and Quick Settings 10-12
- General device information and tips 13
- Disposal and recycling information 14
- Regulatory information 14-15
- Maintenance instructions 16
- Safety instructions 16-17
- Customer support 17


User Manual for Thrill

## WATCH OVERVIEW


- Noise Health
- Sports
- Noise Buzz
- Scan easy
- Weather
- Camera
- Music
- Clock
- Breathe
- AI Voice
- Calculator
- Settings

User Manual for Thrill

## PACKAGE CONTAINS



ColorFit Thrill Smartwatch x 1



Charging cable x 1

User Manual for Thrill

## USING THE COLORFIT THRILL SMART WATCH

Before using your ColorFit Thrill for the first time, charge the battery to its full capacity. Use the charging cable provided with the watch to charge. On a full charge, ColorFit Thrill can last up to 15 days.  
Note: The battery life and time to fully charge your device may vary as per usage and other factors.

## CHARGING THE COLORFIT THRILL

- Plug the USB cable into a power adaptor. Plug the power adaptor into an electrical socket. (Power adaptor not included).
- Place the wireless charger on the charging points of the watch.
- Once the battery is fully charged, remove the charger.

User Manual for Thrill

## POWER ON

Press and hold the side button for a few seconds to turn on the watch.

## POWER OFF

Long press the side button. Select 'Power off' to confirm.

## WAKING UP THE WATCH

To preserve battery, the watch screen turns off when not in use. You can wake up the watch by pressing the side button.



Press and Hold Side Button to Power ON

User Manual for Thrill



Press and Hold Side Button to Power OFF

User Manual for Thrill

## WATCH NAVIGATION

The ColorFit Thrill smartwatch has a 2" TFT touchscreen. Navigate the watch by tapping on the screen, swiping side to side, swiping up and down, and pressing the side button.


## SIDE BUTTON NAVIGATION

Press the side button to turn on the watch display.

## HOME SCREEN NAVIGATION

The home screen is the watch face. From the home screen:

- Swipe left to check your main menu.
- Swipe right to check your steps taken.
- Swipe up to access quick settings.
- Swipe down to check your messages.



User Manual for Thrill

## APP SETUP



Before pairing, make sure that your smartphone and smartwatch are next to each other. The app will ask for personal information such as height, weight and sex to calculate your stride length, distance covered, calorie burn rate and metabolic rate. When you set up your account, your name and profile picture will be visible to other users.

- Turn on the Bluetooth and location on your mobile device.
- On your smartphone, download the NoiseFit app from the Play Store or the App Store and install it.
- Create an account or log in using an existing account.

Note: Ensure that your smartphone is running on Android 9.0+ or iOS 11.0+ and is connected to mobile data or a Wi-Fi network.

## PAIR THE WATCH

Open the NoiseFit app and allow the Bluetooth and GPS positioning to be turned on. Feed in your personal information and health goals in the app. Go to the 'Device' section in the app, tap on 'Add Device' then 'Search'. Select ColorFit Thrill and link the watch.



User Manual for Thrill

## DIAL PAD

Access the dial pad to make calls.

## CONTACTS

This feature allows you to view your stored contacts and make calls.

## RECENT CALL

Tap on 'Recent call' to access your recent call logs.

## ACTIVITY


Tap on 'Activity' to get a detailed daily activity report on calories burned, steps taken and distance covered. You can set or edit your daily activity goals on the NoiseFit app while setting up the watch.

## HEART RATE

ColorFit Thrill supports 24/7 heart rate tracking. Tap on 'Heart rate' to start measuring. Ensure that there is no gap between the back panel of the watch and the wrist. Hold still while it measures your heart rate.

## SLEEP

Tap on 'Sleep' to view your previous sleep records. You can view your most recent sleep records and sleep quality in various sleep stages on the NoiseFit app.



User Manual for Thrill

## BLOOD OXYGEN

ColorFit Thrill supports viewing the highest and lowest values of blood oxygen levels throughout the day. Ensure that there is no gap between the back panel of the watch and the wrist. Tap on 'Blood oxygen' to track. Hold still while it measures your blood oxygen level.

## STRESS


Select Stress to start the measurement. Ensure that there is no gap between the back panel of the watch and the wrist. Hold still while it measures your stress levels.

## SPORT

Tap on 'Sport' to select your preferred form of exercise.

## MESSAGES

Tap on 'Messages' to view the received messages on the watch.



User Manual for Thrill

## SCAN EASY


Tap on 'Scan easy' to access your saved QR code. You can save QR code in the app.

## WEATHER

Tap on the Weather app on your watch to see the weather of your current location.

## CAMERA

Tap on camera to take a picture remotely from your phone.



User Manual for Thrill

## STOPWATCH

Tap on 'Stopwatch' to use the feature.

## ALARM

You can set alarms from the NoiseFit app.

## TIMER

You can set a countdown with a pre-set duration on the watch or set your own timer. The watch will remind you when the time is up.

## BREATHE

The breathe feature lets you adjust your breathing rhythm at your convenience. Choose the duration and start.

## AI VOICE

Use this feature to activate voice assistance and give commands.

## GAMES

Tap on games to try out some in-built games.

## CALCULATOR

You can use this feature to do basic calculations.

## Features might change after OTA upgrade

User Manual for Thrill

## SETTINGS

### WATCH FACE

Tap on 'Watch face' to choose the background of your choice. You can also customise the watch face in the NoiseFit app.

### VIBRATION & RING

You can use this feature to choose vibration levels and turn off the vibration on your watch altogether.

### BRIGHTNESS

Tap on 'Brightness' to adjust the brightness of your device.

### PASSWORD

You can use this feature to set and change your password on your watch.

### ABOUT

Tap on About to view the device information.

### POWER OFF

You can select this option to power-off the watch.

User Manual for Thrill

## RESET

You can choose this option to reset the watch. Note: If you choose to reset, all your data and settings will be erased.

## RESTART

You can choose this option to restart the watch.

## FIND PHONE

This feature helps you find your mobile device by making it ring. Just tap on 'Find phone', and your phone will start to ring, even if it is on Silent mode.

## APP

You can use this feature to access the QR code to download the NoiseFit app.

User Manual for Thrill

## QUICK SETTINGS

You can swipe up from the watch's home screen to gain quick settings access.

## DND

## BRIGHTNESS

## PASSWORD

## SETTINGS

## FLASHLIGHT

## VIBRATION & RING

User Manual for Thrill

## DEVICE INFORMATION AND TIPS

### DEVICE INFORMATION

The ColorFit Thrill smartwatch contains the following:

- 2" TFT display
- Blood oxygen monitor
- IP68 water resistance
- Heart rate monitor
- 22mm strap

### TIPS

#### How do I find my watch's current firmware version?

You can find the watch's current firmware on the watch. Go to 'Device' and tap on 'Firmware update' to view the current firmware version.

#### How does the watch estimate how many calories have been burned?

ColorFit Thrill estimates how many calories you've burned based on the physical activity data and your heart rate.

#### How do I change my activity goals?

You can do it through the NoiseFit Ace app. In the app, select 'Me' and go to 'Goal' to change your goals.

User Manual for Thrill

## REGULATORY INFORMATION

### USA: Federal Communications Commission (FCC) Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

### TIPS

#### How do I update my ColorFit Thrill?

You can update your ColorFit Thrill via the NoiseFit Ace app. In the app, select 'Me', go to 'Settings' & check for version updates.

User Manual for Thrill

## MAINTENANCE INSTRUCTIONS:

- Keep the device dry and clean regularly and especially after prolonged use as moisture and dirt can build up underneath the band and can cause skin irritation.
- Do not wear the device too tight but make sure that the bottom sensor is lightly in contact with your skin and there is a gap of about one finger's width between the wrist strap and your wrist.
- Do not use household cleaners to clean the device. Use soap-free cleaners instead.
- For stains that are difficult to remove, it is recommended to scrub with alcohol.
- The device is not suitable for diving, swimming in the sea or sauna; it is suitable for swimming pool, shower (cold water) and swimming in shallows.
- Keep it away from direct sunlight, high temperatures or humid conditions as it may damage the band over time.
- Do not disassemble the battery on your own.
- Do not expose ColorFit Thrill to extremely high or low temperatures. The excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion.
- Charge the battery in a cool, ventilated room.
- Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water (DO NOT RUB THE EYE) or seek medical help.
- Do not short-circuit. Short-circuiting may damage the battery. Short-circuiting can occur when a metallic object, such as coins, causes the direct connection of positive and negative terminals of the battery.

## SAFETY INSTRUCTIONS

### DO NOT DISASSEMBLE THE BATTERY ON YOUR OWN.

### CUSTOMER SUPPORT

If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at support.gonoise.com

User Manual for Thrill

## STOPWATCH

Tap on 'Stopwatch' to use the feature.

## ALARM

You can set alarms from the NoiseFit app.

## TIMER

You can set a countdown with a pre-set duration on the watch or set your own timer. The watch will remind you when the time is up.

## BREATHE

The breathe feature lets you adjust your breathing rhythm at your convenience. Choose the duration and start.

## AI VOICE

Use this feature to activate voice assistance and give commands.

## GAMES

Tap on games to try out some in-built games.

## CALCULATOR

You can use this feature to do basic calculations.

## Features might change after OTA upgrade

User Manual for Thrill

## SETTINGS

### WATCH FACE

Tap on 'Watch face' to choose the background of your choice. You can also customise the watch face in the NoiseFit app.

### VIBRATION & RING

You can use this feature to choose vibration levels and turn off the vibration on your watch altogether.

### BRIGHTNESS

Tap on 'Brightness' to adjust the brightness of your device.

### PASSWORD

You can use this feature to set and change your password on your watch.

### ABOUT

Tap on About to view the device information.

### POWER OFF

You can select this option to power-off the watch.

User Manual for Thrill

## RESET

You can choose this option to reset the watch. Note: If you choose to reset, all your data and settings will be erased.

## RESTART

You can choose this option to restart the watch.

## FIND PHONE

This feature helps you find your mobile device by making it ring. Just tap on 'Find phone', and your phone will start to ring, even if it is on Silent mode.

## APP

You can use this feature to access the QR code to download the NoiseFit app.

User Manual for Thrill

## QUICK SETTINGS

You can swipe up from the watch's home screen to gain quick settings access.

## DND

## BRIGHTNESS

## PASSWORD

## SETTINGS

## FLASHLIGHT

## VIBRATION & RING

User Manual for Thrill

## DEVICE INFORMATION AND TIPS

### DEVICE INFORMATION

The ColorFit Thrill smartwatch contains the following:

- 2" TFT display
- Blood oxygen monitor
- IP68 water resistance
- Heart rate monitor
- 22mm strap

### TIPS

#### How do I find my watch's current firmware version?

You can find the watch's current firmware on the watch. Go to 'Device' and tap on 'Firmware update' to view the current firmware version.

#### How does the watch estimate how many calories have been burned?

ColorFit Thrill estimates how many calories you've burned based on the physical activity data and your heart rate.

#### How do I change my activity goals?

You can do it through the NoiseFit Ace app. In the app, select 'Me' and go to 'Goal' to change your goals.

User Manual for Thrill

## REGULATORY INFORMATION

### USA: Federal Communications Commission (FCC) Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

### TIPS

#### How do I update my ColorFit Thrill?

You can update your ColorFit Thrill via the NoiseFit Ace app. In the app, select 'Me', go to 'Settings' & check for version updates.

User Manual for Thrill

## MAINTENANCE INSTRUCTIONS:

- Keep the device dry and clean regularly and especially after prolonged use as moisture and dirt can build up underneath the band and can cause skin irritation.
- Do not wear the device too tight but make sure that the bottom sensor is lightly in contact with your skin and there is a gap of about one finger's width between the wrist strap and your wrist.
- Do not use household cleaners to clean the device. Use soap-free cleaners instead.
- For stains that are difficult to remove, it is recommended to scrub with alcohol.
- The device is not suitable for diving, swimming in the sea or sauna; it is suitable for swimming pool, shower (cold water) and swimming in shallows.
- Keep it away from direct sunlight, high temperatures or humid conditions as it may damage the band over time.
- Do not disassemble the battery on your own.
- Do not expose ColorFit Thrill to extremely high or low temperatures. The excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion.
- Charge the battery in a cool, ventilated room.
- Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water (DO NOT RUB THE EYE) or seek medical help.
- Do not short-circuit. Short-circuiting may damage the battery. Short-circuiting can occur when a metallic object, such as coins, causes the direct connection of positive and negative terminals of the battery.

## SAFETY INSTRUCTIONS

### DO NOT DISASSEMBLE THE BATTERY ON YOUR OWN.

### CUSTOMER SUPPORT

If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at support.gonoise.com

User Manual for Thrill

## STOPWATCH

Tap on 'Stopwatch' to use the feature.

## ALARM

You can set alarms from the NoiseFit app.

## TIMER

You can set a countdown with a pre-set duration on the watch or set your own timer. The watch will remind you when the time is up.

## BREATHE

The breathe feature lets you adjust your breathing rhythm at your convenience. Choose the duration and start.

## AI VOICE

Use this feature to activate voice assistance and give commands.

## GAMES

Tap on games to try out some in-built games.

## CALCULATOR

You can use this feature to do basic calculations.

## Features might change after OTA upgrade

User Manual for Thrill

## SETTINGS

### WATCH FACE

Tap on 'Watch face' to choose the background of your choice. You can also customise the watch face in the NoiseFit app.

### VIBRATION & RING

You can use this feature to choose vibration levels and turn off the vibration on your watch altogether.

### BRIGHTNESS

Tap on 'Brightness' to adjust the brightness of your device.

### PASSWORD