


USER MANUAL



Thank you for choosing the boAt Enigma X600 as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well. .




PACKAGE CONTAINS

- boAt Enigma X600 x1
- USB magnetic charging cable x1
- User Manual x1
- Warranty Card x1

CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes up to 2.5 hours to be fully charged.

Connect and charge the watch with the image below as a reference, using 5V/2A adapter.



TURNING THE WATCH ON/OFF

To turn the watch on/off, long-press the upper side button for 3-5 seconds.

You can wake up the screen by lifting your wrist.

CONNECTING TO THE APP


1. Download the boAt Smartwear app on your phone. Available on both App Store (iOS 12.0 and above) and Google Play Store (Android 8.0 and above)



download & bind

Scan [QR CODE] (Also available on the watch)

2. Connect the device with the boAt Smartwear app; ensure that the phone's Bluetooth, as well as the GPS functionalities, are turned on
3. Select Enigma X600 on the home screen of the app and click pair to connect.
4. Once connected, you will get an alert to connect with ENIGMAX600_BT, click pair if need to receive or make calls from the watch
5. To use all features of your Enigma X600 seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.
6. Disable battery optimization



Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.

SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization

- Open the app on your phone.
- Make sure your Enigma X600 is connected to the app.
- Synchronization will start automatically once you enter the app interface.

Note: Synchronize data at least once every day to avoid data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS

Short Press the Upper Side Button for the Main Menu

Dial
Use a dialler to dial any number from the watch.

Contact
Add up to 10 contacts from boAt Smartwear app. You can select any contact to directly dial from the watch.

Call Records
You can find recently received, missed, and outgoing call logs in the recent calls of the watch.

Voice Assistant
Tap on this and pair the watch with the phone's Bluetooth and give the command from the watch.

Activity Data
Click on this to check your daily activity data like step count, calorie and distance covered.

Workout
Tap on the workout icon to choose from multiple sports mode: Walking, Running Treadmill, Hiking, Strength Training, Basketball, Badminton, Elliptical, Yoga, Table tennis, rope skipping, rower, Lazy Car, Exercise Bike, Tennis, Baseball, Rugby, Cricket, cycling and more. Tap on your preferred activity to begin

Tap on any sport mode to start the activity. Swipe right to pause or stop the activity. The activity will not be recorded if it is less than 3 mins.

Workout Records
Sync your smartwatch to the app to get a detailed record of your activities.

Heart Rate
Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes

Sleep
Tap on the icon to review the sleep data of the previous night. Once the asleep criteria are met, your smartwatch will start recording from 9:30 pm at night to 12 am in the morning the next day.

Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movement. You can check the data on the app only after the awake criteria is met. You can also track sleep scores on the boAt Smartwear app.

Note: *For accurate sleep data recording, the sleep criteria have to be met which includes limited movement, wrist positions and angles, and more. *The awake criteria will be met only after it records some noticeable movement.

Blood Oxygen
Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes.

Messages
Tap on this icon to check your messages.

Weather
Connect with the boAt Smartwear app to get daily weather updates on the watch..

Female
Enable and set the details on the boAt Smartwear app and get alerts of your period and ovulation dates on the watch.

Music
Tap on the remote music control icon on your watch to play music from your phone.

Note: Some apps with different protocols might not work.

Breathe
Click on the breath training icon to regulate your breathing with the instructions to relax.

Stopwatch
Click on this to start the stopwatch on your watch.

Timer
Tap on this to turn on the timer.

Alarm clock
Tap on this to set an alarm on your watch.

Game
Tap on this to access a variety of games. Select from 2048, and car.


Find My Phone
Tap on this icon to find your phone. Once enabled, your phone will start ringing and vibrating. Tap again to stop it.

Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work

SETTINGS

Menu Style

Change the menu style from here.



Display

Tap on this to adjust the brightness, set the screen on time, AOD clock and enable the wake gesture.

Battery

Tap on this to see the current battery percentage and to enable power-saving mode.

Vibration & Ring

Tap on this to choose from mute, ring and vibration and Vibration option.

APP

Tap on this and scan the bar code from mobile to connect the smartwatch.

Down Button Settings

Tap on this to change the functionality of side buttons

Set Time

Tap on this to set the date and time format.

Password

Tap on this to set a password for the watch.

Device Info

Shows the device details.

Power Off

Tap on this to switch your watch off.

Restart

Tap on this to restart the watch.

Reset

Tap on this to reset watch data.

*Note: All data will be erased if watch is reset

SWIPE UP TO ACCESS THE NOTIFICATIONS
You can check all the notifications from here. Click the delete icon to delete all the notifications.

SWIPE DOWN FOR THE SHORTCUT MENU
You can access Brightness, Setting, About, Flashlight, Phone, DND, and Power saving mode.

SWIPE LEFT TO ACCESS SHORTCUT DATA
You can access daily activity, heart rate, sleep, weather, and music. You can also add more features.

PRODUCT PARAMETERS

MODEL	Enigma X600
SCREEN TYPE	1.43" AMOLED
BATTERY CAPACITY	300 mAh
BLUETOOTH VERSION	5.2
WORKING TEMPERATURE	-30°C-45°C
CHARGING TIME	2.5 hours
WORKING TIME	3-7 days
WATER RESISTANCE	IP68
FREQUENCY BAND	No

Note: The net weight will differ according to different straps.

MAINTENANCE

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.

Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

SAFETY & PRODUCT INFORMATION

Battery

- Do not disassemble, bore or damage the battery.
- Do not disassemble the built-in batteries of non-replaceable battery devices.
- Do not use sharp objects to remove the battery.

Health Warning

- If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.
- The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.
- The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.
- The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood pressure data are for reference only. We're not responsible for any deviation in data.
- Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

Things to Keep in Mind

- Sync data everyday days to avoid data loss.
- Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.
- Sports modes support up to 6 hours of exercise at a time.
- Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.
- Keep your arm still while measuring data for accurate measurement.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and treatment of toxic substances.