

# Thank you for choosing the boAt Wave Sigma 3 as your fitness Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth

# SETTINGS Watch Faces

Tap on this icon to change your watch face.

Tap on this and adjust the screen sleep time

Tap on this to enable wake gesture

Tap on this to choose the ringtone and put the watch on silent

### Tap on the remote camera icon on your smartwatch to click a photo from your phone.

Note: Turn the camera on from your phone to use this feature.

Tap on the remote music control icon on your watch to play music from your phone.

Note: Some apps with different protocols might not work.

Tap on this icon to find your phone. Once enabled, your phone will start ringing and vibrating. Tap again to stop it.

Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work.




09:09 AM

transformation companion.

sail. You may refer to these instructions for later use as well.

The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



side button for 3-5 seconds. You can wake up the screen by lifting your wrist.


Tap on this to adjust vibration levels from strong, soft and

Tap on this to turn on the Do Not Disturb mode

### CHARGING THE WATCH

Package Contains:

boAt Wave Sigma 3 v1



### To restart or turn the watch on/off, long-press the

Voice Assistant

command from the watch.

Tap on this to access the built-in game.

You can select from 2048 and Hamster

### CONNECTING TO THE APP

1. Download the boAt Crest app on your phone.

Available on both App Store (iOS 12.0 and above) and Google Play

Store (Android 7.0 and above) Scan [QR CODE] (Also available on the watch)

### 2. Connect the device with the boAt Crest app; ensure that

the phone's Bluetooth as well as the GPS functionalities are

### 3. Select Wave Sigma 3 on the home screen of the app and click pair to connect. 4. Once connected, you will get an alert to connect with SIGMA3\_XXXX, click pair if need

- to receive or make calls from the watch 5. To use all features of your Wave Sigma 3 seamlessly, tap on 'yes' to the 'connection' and
- 'grant access' system prompt. 6. Disable battery optimization



Tap on this to enable the voice assistant feature and give the

Note: Make sure the watch is connected with the app

Note: To ensure connectivity throughout your journey, make sure the app is allowed to always run in the background of your phone.

Open the app on your phone.

Make sure your Wave Sigma 3 is connected to the app. Synchronization will start automatically once you enter the app interface.

Synchronize data at least once a day to avoid data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS

### SHORT PRESS THE SIDE BUTTON FOR MAIN MENU

You can use the dialer to dial any number

this feature:

clicking on get directions.

Add up to 20 contacts from boAt Crest app. You can select any contact to directly dial from the watch. Call History

SYNCING YOUR SMARTWATCH TO THE APP

Call History of the watch.

### Choose from multiple sports modes like Walking, treadmill,

Running, Badminton, Football, Basketball, Tennis, Yoga, Dancing, Cycling, Indoor Cycling, etc. The watch has 700+ activity modes. You can also add or replace the activities according to your preferences through boAt Crest app.

Tap on any sport mode to start the activity, click the go button, and the watch will start recording the duration of the activity. Swipe right to pause or stop the activity. The activity will not be recorded if it is less than 3 mins.

### **Activity Record**

Sync your smartwatch to the app to get a detailed record of the



### Wear the watch on your wrist, then click on the icon to start

SIDE BUTTON FUNCTIONALITY

· Navigate to the "Home Dashboard."

PRODUCT PARAMETERS:

MAINTENANCE:

the other end of the product

follow the above procedure.

SOS call. Follow these steps to activate the SOS feature:

Locate the "Top Features" section on the dashboard.

thoroughly and wipe with a piece of soft towel or napkin

**Heart Rate Monitor** 

measurements. You can also view the data on the app. Note: Measurements are for reference only and not for medical

Short-press the side button to go to the previous tab and long-press the side button to make an

In the "Top Features," you will find the "SOS" feature. Click on it to access the SOS functionality

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during

exercise or being exposed to substances such as soap or detergent, which may get stuck or

Do not wash the strap with a household cleanser. Please use soap less detergent, rinse



### Wear the watch on your wrist, then click on the icon to start

SpO<sub>2</sub> monitoring

Sleep Monitor

measurements. You can also view the data on the app.


Note: Measurements are for reference only and not for medical

Notification

You can check all the notifications from here

### Tap on the icon to review the sleep data of the previous night. Once the asleep criteria are met, your smartwatch will start recording from 8

pm at night to 10 am in the morning the next day. Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movement. You can check the data on the app only after the awake criteria is met. You can also track sleep scores on the boAt Crest app.



includes limited movement, wrist positions and angles, and more. The awake criteria will be met only after it records some noticeable movement

### Breathe exercises

Click on the breath exercises icon to regulate your breathing by doing breathing exercises. You can set the time and level of exercise.



# Stopwatch

Tap on this to set an alarm on your watch.



### your dally activities such as steps, sleep, distance, heart rate and calories, but may not be

The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is

designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate data is for reference only. We're not responsible for any deviation in data.

### . Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

Things to keep in mind Sync data everyday days to avoid data loss.

### & other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.

. Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch

### · Keep your arm still while measuring data for accurate measurement.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical

Do not disassemble, bore or damage the battery.

SAFETY & PRODUCT INFORMATION

and other wading or deep-water activities with high-speed water flow.

### Do not use sharp objects to remove the battery.

(1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 10 minutes

The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing

 If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch. · The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to

blinking light sources, please consult your physician before wearing this device.

### Search for the app to connect keeps failing

 Keep the boAt Crest app updated to the latest version. Close all the programs on the watch → Stop and restart Bluetooth and GPS → Connect again

My Bluetooth keeps getting disconnected

3. Check and enable notification functions of your phone and keep the phone and watch in Note: Make sure your phone system meets Android 7.0 and above and iOS 12.0 and above.

My Watch Wave Sigma 3 is receiving no alerts, texts, or phone calls Make sure smart reminders on the app are on and synced to the Wave Sigma 3. Also make sure your notification center of the phone is displaying messages. Only then will

your smartwatch also display those notifications. Make sure app is running in the background and battery optimization feature on the phone

1. Make sure there is not more than 7m distance between Bluetooth on the phone & the watch. There is no obstacle in between the watch and the phone.

### . Sports modes support up to 6 hours of exercise at a time. 3. Make sure the app is running in background Which functions of the Wave Sigma 3 need Bluetooth to work?

Call & Text Notifications, Find My Phone, music control, camera control, weather forecast,

### cloud and custom watch faces and need Bluetooth connectivity to work. Will it be okay to take a bath wearing the Wave Sigma 3?

The IP67 water resistance will only work under the following conditions: reference. We reserve the right to modify or improve any of the functions described in this manual

# without any prior notice. At the same time, we hold the right to continuously update the product

Do not disassemble the built in batteries of non-replaceable battery devices.

### Health Warning

### RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste,

but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances.

. The device tracks your daily activities through sensors. This data is intended to tell you about

· Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents

### Note: The navigation is not shown in maps instead it is shown by direction arrows. You can access the last alert from the watch

### To avoid receiving notifications on our smartwatch during navigation enable DND mode.

### You can access DND, Alarm, Find My Phone, Brightness, Navigation and

Tap on this to start navigating your route. Follow the steps to use

Then send navigation instructions to your boAt smartwatch by

Then follow step-by-step instructions on your smartwatch to reach

Search your desired destination on the boAt Crest app.

After clicking on it choose the navigate on watch option.

navigation menu or by swiping left from the home screen.

SWIPE DOWN FOR SHORTCUT MENU

## You can access daily activity, SpO2, Heart rate, sleep, phone and

# You can check the cricket live scores from here.

# SWIPE LEFT OR RIGHT TO ACCESS ALL DATA. notifications. SWIPE UP TO ACCESS THE LIVE SCORE

### transfer the QR code of metro ticket/pass, bus pass, UPI, social apps, and more into the smartwatch by adding the QR code in the boAt crest app. To add the QR code follow these steps: Click on "QR Tray" option in the boAt Crest app. • To add a QR code, capture a screenshot of the QR code of the app you want to include. · After this, you'll be able to find a collection of QR codes in the smartwatch under the QR Tray feature. Select the QR code you want to be scanned.

