

DASH 3

16W Portable Speaker
With Wireless Karaoke Mic




Products specifications

BT Name : Dash 3
 BT version : V5.3
 Transmission distance : ≤ 10m
 Output power : 2*8W
 Rated input : DC 5V 1A
 Battery capacity : 2500mAh
 Playing time : About 3-5 hours
 Charging time : About 4 hours
 Signal-to-noise ratio: ≥ 90dB
 Distortion rate: ≤ 1%
 Frequency response: 80Hz~18KHz
 File format: support MP3, WMA, WAV

Packing list

Portable Speaker	1N
Karaoke Mic	1N
Charging Cable	1N
User Manual	1N


Buttons and functions



- ① Short press to decrease the volume, long press the previous song.
- ② long press to turn on/off; Short press to play/pause.
- ③ short press to increase volume, long press to make one song.
- ④ Short press: mode switching, Long press: light on/off. & made change RGB

Shutdown: When the speaker is not in use, press and hold the "⏻" button to shut down to prevent power loss. Low battery alarm and automatic shutdown function: When the battery level is below 10%, the speaker will emit a prompt sound. At this time, the speaker should be charged in a timely manner. When the battery level is below 3%, the speaker will automatically shut down.

Back Interface Description



- ① DCSV Type-C charging port.
- ② TF card socket, insert TF card to automatically play music (supports TF card playback, up to 32G (supports MP3, WAV music formats).
- ③ AUX audio input ports, insert a 3.5mm cable to automatically enter AUX mode.

Microphone operation instructions

- + Short press the microphone to increase the volume; Long press and next song.
- Short press the microphone to reduce the volume; Long press to previous song.

Long press the power button to turn on/off; Short press the power button to select three sound effects modes: kareok mode and speech mode.

Short press the microphone button to cancel the original sound; Long press to switch between six magic sound modes: female to male, male to female, doll sound, monster sound, machine sound, and original sound.

Operation Instruction

1. Bluetooth mode

(1) Bluetooth connection: When turned on, the default setting is Bluetooth. Enter Bluetooth mode or press the "⏻/⏪" button to switch to Bluetooth mode. Open the Bluetooth scan on your phone, search for "Dash 3" and click pairing. After successful connection, there will be a prompt sound indicating that Bluetooth is connected.

(2) After connecting the machine to the phone once, Bluetooth has a memory function, which can be automatically or manually connected when turned on; If you need to disconnect, you can use your mobile Bluetooth device to disconnect.

2. TF card mode

(1) Insert the TF card, and the speaker will automatically perform a priority playback with a prompt sound. When all TF cards are inserted, you can switch by briefly pressing the "⏻/⏪" button.

3. AUX (external audio input) mode

(1) Insert the AUX external audio cable, and the audio system will automatically play back with priority and a prompt tone.
 (2) When both AUX and TF cards are inserted simultaneously, you can switch by briefly pressing the "⏻/⏪" button.

4. Four indicator light states

(1) Charging indicator: The charging red light is on, and the fully charged red light is off.

5. Music Lamp Description

(1) This product has five music light modes, namely: color running, gradient breathing (alternating red, blue, and green gradient breathing, red breathing, blue breathing, green breathing, and turn off the light effect; press and hold the "⏻/⏪" button once to switch between one light effect.

6. Wireless microphone usage

(1) The speaker and microphone are turned on simultaneously, and the 2.4G wireless signal is automatically paired. At this point, users can start shouting and adjust the buttons to their preferred style according to their preferences.