

Enter pairing mode

Automatic pairing mode

First use: Open the charging case and the earphone automatically enters the pairina mode.



Manual pairing mode

Take the two earphones out of the charging case and press the touch area with both hands for 5 seconds at the same time. The earphone can also enter the pairing mode manually.



Hold both hands for 5 seconds

2 Connect earphones

Turn on Bluetooth on smartphone, search and connect to realme Buds Air 3 Neo".





You can choose the most appropriate ear tips size. (M installed by default)









Music mode Single earphone Double-tap Play or pause


| | Single earphone | Triple-tap | Next track |
|---------|-----------------|---------------|-------------------|
| | Left earphone | Long press 3s | Decrease volume |
| | Right earphone | Long press 3s | Increase volume |
| Call mo | de | | |
| | Sinale earphone | Double-tap | answer or hand up |

Both earphones Long press 10s Reset

Single earphone Long press 2s Reject a call

Both earphones Long press 5s Enter pairing mode

nealme Link





Overview and packing list



Packina List

Earphone X User Guide X 1 Ear tips (M installed by default) X 6

Type-C charging cable

Basic Parameters

| Product name | realme Buds Air 3 Neo | |
|----------------------------------|---|--|
| Product model | RMA2113 | |
| Bluetooth version | Bluetooth 5.2 | |
| Bluetooth protocol | HFP/A2DP/AVRCP | |
| Bluetooth code | SBC , AAC | |
| Charging interface | Type-C | |
| Endurance (music) | About 7h (earbuds) About 30h (use with charging case) | |
| Charging time | About 2h | |
| Bluetooth communication distance | ≤10m | |
| Working frequency | 2402~2480 MHz | |
| Max power rate | <10dBm | |

1. Don't place the product into a liquid environment or avoid the product exposed to high humidity. 2. Avoid extrusion to avert the damage to the product.

3 Steps to

enjoy the buds

3. Don't attempt to dismantle the product. Put the product in a cool and dry place to keep it dry if stored for a long time.

4. Avoid touching the strong magnet to prevent the magnetic headset from being demagnetized.


5. Avoid the dusty, wet and dirty environment where the electronic circuit of the equipment may be damaged if being used.

6.Don't use the equipment at the moment of thunderstorm because the thunderstorm may incur equipment fault or shock hazard.

7. Don't use the equipment when riding a motorcycle or a bicycle, driving a car or crossing the road to ensure your safety.

8. Keep the equipment out of reach of children or pets to avert the damage.

9. Don't wash the equipment with chemical, cleanser or strong detergent. Oon't listen to the voice under high sound pressure and high volume for a long time to



This symbol (with or without a solid bar) on the device, batteries (included), and / or the packaging, indicates that the device and its electrical accessories (for example, a headset, adapter or cable) and batteries should not be disposed of as household garbage.

Battery warning

The built-in lithium battery of the product is forbidden to be disassembled, impacted, extruded or put

The battery under the very low air pressure may result in explosion or flammable liquid or gas leakage. Avoid the battery in a high-temperature environment or being exposed to strong sunlight to avert explosion.

Don't use the battery continuously in case of serious ballooning.

The battery shall be handled pursuant to the local regulations and shall not be disposed as household garbage.

Don't try to repair, remove or refit the battery. The explosion may happen if the battery is replaced by the one subject to incorrect model.

Don't compress or puncture the battery with hard object. The battery leakage, overheating or outbreak of a fire may occur if the battery is destroyed.

Temperature Description

1. This product contains a battery. If it is not used for a long time, please store it in the environment of 0°C-35°C, and charge the product at least every 3 months to prevent the battery performance from deteriorating.

2. Please use the earphones or charge it in a normal environment (ambient temperature 0°C-45°C, humidity 45%-85%). The earphones can be charged quickly at 15°C -45°C. If the product temperature is not within the safe temperature range, it may cause damage to the earphones and battery performance.

Recycling Initiative

At realme we understand that our responsibility doesn't end at selling you our products, realme has been working in the area of safe disposal of electronic waste. Since mobiles, tablets and other

electronic items are made of hazardous constituents. Under the Guidelines of Ministry of

Environment, Forest and Climate Change, Government of India, E-waste (Management) Rule, 2016 and Amendment E-waste Rule 2018.

realme will seek shared responsibility and cooperation from customers in reducing the environmental impact of their products, realme will comply with all the applicable laws related to

E-waste management. For more information on safe disposal, recycling and you may log on to

https://www.realme.com/in/legal/e-waste-management or write an email to service@realme.com or contact our Toll Free No. 1800-102-2777

Disposal and Recycling Information

This symbol (with or without a solid bar) on the device, batteries (included), and / or the packaging, indicates that the device and its electrical accessories (for example, a headset, adapter or cable) and batteries should not be disposed of as household garbage.

Warranty

Thank you for purchasing realme products. If any manufacturing defect problems occur within 12 months from the date of purchase, user can enjoy our company's warranty service.

Matters Needing Attention:

1. When you buy the product, the sales unit will issue a valid proof of purchase.

2. The warranty card and the proof of purchase should be kept by the user properly, and it will not be replaced if lost.

3. If the product fails due to non-human factors, the user can present the warranty card and proof of purchase to the realme customer service center for free maintenance during the warranty period.

Non-warranty situation:

This warranty does not cover the following cases: 1. Out of warranty period.

- 2. Damage caused by use not in accordance with the instructions.
- 3. Damage caused by man-made causes.
- 4. Failure caused by unauthorized disassembly, maintenance, or modification of the product. 5. Damage caused by force majeure factors (such as floods, earthquakes, lightning, etc.).
- 6. There is no warranty card, invoice, or warranty card that does not match the invoice information.
- 7. The product wears naturally. 8. Other failures and damages that are not caused by the quality of the product itself.

Website: www.realme.com

Warranty Card (Stub Copy)

Dear user, thank you for using the product of our company. Please read and keep properly the warranty card after purchasing the product so that we can provide better services to you.

User Information User's name ____ Phone Number

Touch area

Product Information Product Model _____ Product Serial Number ____

Sales Information Purchase Date ____

Invoice Number ____ Sales Unit _____ Phone Number

Warranty Card (Customer Copy)

Dear user, thank you for using the product of our company. Please read and keep properly the warranty card after purchasing the product so that we can provide better services to you.

User Information User's name ____

Phone Number Address

Product Information Product Model ____

Product Serial Number ____

Sales Information Purchase Date ____

Invoice Number _____ Sales Unit_____ Phone Number